



shaping tomorrow with you

FLASHWAVE[®] 7500

Metro/Regional Multiservice ROADM

Release 9.1
Issue 2, October 2013

Compatible with:

NETSMART[®] 1500 Version 8
NETSMART[®] 500 Version 5.2
NETSMART[®] 2000 Version 6

FNC-7500-0091-270A

System Turn-Up

Core Configuration

FLASHWAVE (and design)[®] is a trademark of Fujitsu Network Communications Inc. (USA). All Rights Reserved

Flexponder[™] is a trademark of Fujitsu Network Communications Inc. (USA). All Rights Reserved

NETSMART[®] is a trademark of Fujitsu Network Communications Inc. (USA). All Rights Reserved

CLEI[™], CLLI[™], and COMMON LANGUAGE[®] are trademarks or registered trademarks of Telcordia Technologies, Inc.

HyperTerminal[®] is a registered trademark of Hilgraeve Inc.

Microsoft[®], Windows[®], Windows NT[®], and Excel[®] are registered trademarks of Microsoft Corporation.

Mozilla[®] and Firefox[®] are registered trademarks of the Mozilla Foundation.

Netscape[®] is a registered trademark of Netscape Communications Corporation in the United States and other countries.

Pentium[®] is a registered trademark of Intel Corporation.

Telcordia[®], NMA[®], and OSMINE[™] are trademarks or registered trademarks of Telcordia Technologies, Inc.

All other products or services mentioned in this document are identified by the trademarks, service marks, or product names as designated by the companies that market those products or services or own those marks. Inquiries concerning such products, services, or marks should be made directly to those companies.

This document and its contents are provided by Fujitsu Network Communications Inc. for guidance purposes only. This document is provided "as is" with no warranties or representations whatsoever, either express or implied, without notice, to make including without limitation the implied warranties of merchantability and fitness for purpose. Fujitsu Network Communications Inc. does not warrant or represent that the contents of this document are error free. Furthermore, the contents of this document are subject to update and change at any time without notice by Fujitsu Network Communications Inc., since it reserves the right, changes in equipment design or components as progress in engineering methods may warrant. No part of the contents of this document may be copied, modified, or otherwise reproduced without the express written consent of Fujitsu Network Communications Inc.

Compliance

FCC

This equipment has been tested and found to comply with the limits for Class A digital devices, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interferences when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio energy and if not installed in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, which the user will be required to correct at his/her expense.

Industry Canada

This digital apparatus does not exceed the Class A limits for noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications to ICES-003.

Cet appareil numérique ne dépasse pas les limites d'émission de bruit pour les appareils numériques de Classe A tel que définit dans le document NMB-003 publié par le Département Canadien de Communications.

Important

Observe all warnings in the text or on equipment labels regarding high-voltage or high-temperature conditions. The following warnings and figures apply to most Fujitsu products.

Plug-In Unit Cautions



Observe the following precautions when handling plug-in units:

- Hold the plug-in unit only by its edges.
- Slowly and firmly push a plug-in unit into its slot to avoid damaging the unit. Do not force the unit. A slow insertion method minimizes power surges during installation. The longer ground connector pins ensure the ground circuit is connected first.

ESD Cautions

Units are stamped with anti-electrostatic markings (shown at right). Observe the following precautions to avoid damage from ESD:

- Always transport and store the unit in an ESD approved shipping bag.
- Always wear an ESD wrist strap, with a minimum 1-megohm resistance, that is connected to safety ground. Do not use a damaged wrist strap.




Anti-Electrostatic Markings

Fiber Warnings

Danger: Invisible laser radiation. Avoid direct exposure to the beam. Never look into the end of a fiber, fiber cord, or fiber pigtail. Permanent eye damage or blindness can occur quickly when laser radiation is present. The label on the right is attached to laser-emitting and receiving units as a reminder. Use of controls, adjustments, or procedures other than those specified may result in hazardous laser radiation exposure.

Danger: Never handle exposed fiber with your bare hands or touch it to your body. Fiber fragments can enter the skin and are difficult to detect and remove.



Laser Radiation Label

Avertissements de Fibre

La Danger: Le rayonnement laser Invisible. Eviter l'exposition directe au rayon. Jamais le regard dans la fin d'une fibre, une corde de fibre, ou la natte de fibre. Les dommages permanent d'oeil ou la cécité peut arriver rapidement quand le rayonnement laser est actuel.

La Prudence: L'Usage de contrôles ou d'ajustements ou l'exécution ou les procédures autrement que ces spécifié en ceci ont pour résultat l'exposition de rayonnement hasardeuse.

La Danger: Jamais la poignée a exposé la fibre avec vos mains nues ou le touche à votre corps. Les fragments de fibre peut entrer la peau et sont difficiles de détecter et enlever.

Installation Restrictions

The following guidelines apply when installing this equipment:

- Systems shall be installed only in restricted access areas (for example, dedicated equipment rooms or equipment closets) in accordance with the National Electrical Code, ANSI/NFPA 70.
- Equipment suitable for mounting over non-combustible surface ONLY.
- **Caution:** To de-energize the equipment, all input power circuits (-48Vdc battery) must be removed prior to maintenance/servicing or upgrading.
- Care should be taken not to compromise the stability of the rack by the installation of this equipment
- This equipment has a maximum operating ambient of 50 Deg C. The ambient temperature where the equipment is installed shall not exceed 50 Deg C.
- A minimum air clearance of 1.75" (1U) below the equipment must be maintained after the installation into the rack. the equipment can be installed at the very top location if desired.
- Care should be taken not to overload the supply circuit
- For the input power harness; Use only UL-Listed, dual closed loop, connectors.
- Suggested Vendor: Thomas and Betts - P/N:54205.
- Use Crimp Tool: Thomas and Betts P/N TBM25S for 6-AWG copper conductors.

Reliable earthing of the equipment must be maintained when installed in the rack. Use only UL-Listed, dual closed loop, connectors. Suggested Vendor and Part Number:

- Thomas and Betts - P/N: 256-30695-1070
- Use Crimp Tool: Thomas and Betts P/N TBM25S for 6-AWG copper connectors.

For the output distribution harness; Use only UL-Listed dual closed loop connectors. Suggested Vendor and Part Number:

- Thomas and Betts - P/N:256-30695-1298PH
- Use Crimp Tool: Thomas and Betts P/N TBM25S for 10-AWG copper connectors.

Restrictions d'Installation

Les indications suivantes s'appliquent en installant cet équipement:

- Les systèmes seront seulement installés dans les secteurs d'accès limités (par exemple, les pièces d'équipement dédié ou les placards d'équipement) conformément au Code Electrique National, ANSI/NFPA 70.
- L'équipement convenable pour monter par-dessus la surface incombustible seulement
- **La prudence:** A de-stimule l'équipement, toute pile de (-48Vdc de circuits de pouvoir d'entrée) doit être enlevé avant entretien/entretenir ou avant améliorer.
- Le soin devrait être pris pour ne pas compromettre la stabilité de l'étagère par l'installation de cet équipement.
- Cet équipement a un maximum fonctionnant ambiant de 50 Deg C. La température ambiante où l'équipement est n'installé dépassera pas 50 Deg C.
- Un dégagement minimum d'air de 1.75" (1U) au dessous de l'équipement doit être maintenu après l'installation dans l'étagère. l'équipement peut être installé tout en haut l'emplacement si désiré.
- Le soin devrait être pris pour ne pas surcharger le circuit de provision
- Pour l'harnais d'entrée de pouvoir; seulement UL-LISTED les connecteurs de boucle fermés doubles seront utilisés.
- Le Vendeur suggéré: Thomas et Betts - P/N:54205.
- L'outil: Thomas et Betts - P/N:TBM25S pour les conducteurs de cuivre 6-AWG.

Earthing fiable de l'équipement doit être maintenu quand installé dans l'étagère. Utiliser la boucle fermée, double et seulement UL-ENUMERE, les connecteurs. Le Vendeur suggérés et Nombre de Partie:

- Thomas et Betts - P/N:256-30695-1070
- et utilise l'outil: Thomas et Betts - numéro de partie TBM25S pour 6-AWG connecteurs de cuivre.

Pour l'harnais de distribution de production; seulement UL-LISTED les connecteurs de boucle fermés doubles seront utilisés. Le Vendeur et numéro de partie suggérés:

- Thomas et Betts - P/N: 256-30695-1298PH
- L'outil: Thomas et Betts P/N: TBM25S pour 10-AWG connecteurs de cuivre

Flammable Liquids Warning

Danger: Do not use flammable liquids or sprays, such as those used for cleaning optical connectors, around telecommunications equipment. Electrical fan motors and other potential ignition sources within the equipment might ignite the flammable material and cause personal injury or damage to the equipment. If uncertain about whether a liquid or spray is flammable, contact the manufacturer


Proper Disposal Procedures for Information Technology Equipment within the EU

All electrical and electronic equipment or units must be disposed of in accordance with European Directive 2001/96/EC for Waste Electrical and Electronic Equipment (WEEE).

Network communications or commercial equipment customers can dispose of Fujitsu equipment by contacting the Fujitsu regional office in their country. Customers can locate regional offices at <http://www.fujitsu.com/global/>.

Fujitsu will ensure the proper recycling, reuse, and other forms of recovery of WEEE. Potential hazardous substances in WEEE can harm the environment. You can contribute to the elimination of these effects through your cooperation.

Additional WEEE disposal information may be found at: <http://www.fujitsu.com/global/about/environment/approach/policy/>



Document Change Notice

This notice lists the reasons for, location of, and a description of document changes. When the changes are extensive, a general statement giving the nature of the revisions is provided.

Reason for Document Change: Not updated for Release 9.1, Issue 2

Location of Change	Description of Change
---------------------------	------------------------------

Contents

1	Introduction to System Turn-Up Core Configuration	p. 11
2	System Turn-Up	p. 13
2.1	About System Turn-up Core Configuration	p. 14
2.2	Slot Labels and AIDs	p. 28
2.3	Turn-Up Provisioning Hierarchy FLASHWAVE 7500–Core Configuration	p. 38
2.4	Verify Shelf Labeling, Verify LAN and RICC Cable Connections, Apply Power, and Install Fan Units	p. 42
2.4.1	Verify Shelf Labeling	p. 46
2.4.2	Verify LAN Connections	p. 47
2.4.3	Verify RICC Connections	p. 49
2.4.4	Apply Power, and Install Fan Plug-In Units	p. 55
2.5	Install Primary NE Management Units in Shelf OS1, and Configure Shelf OS1 as the Main Optical Shelf	p. 57
2.5.1	Install MPMA-SHPx Plug-In Unit	p. 58
2.5.2	Verify Software Version	p. 60
2.5.3	Change System Type	p. 61
2.5.4	Change HUBMODE to MANUAL	p. 65
2.5.5	Provision Shelf Location Identifiers	p. 66
2.5.6	Provision OSC Units	p. 66
2.6	Provision System-Level Parameters, LCN Port, and GOS	p. 69
2.6.1	Provision System-Level Parameters	p. 69
2.6.2	Provision LCN Port	p. 78
2.6.3	Provision GOS	p. 84
2.7	Create Subtending Shelves and Install Shelf Processors	p. 87
2.7.1	Install Shelf Processors	p. 87
2.7.2	Create Auxiliary Optical Shelf Equipment Entities	p. 88
2.7.3	Create Tributary Shelf Entities	p. 93
2.8	Provision Optical Shelf Equipment and Facilities	p. 102
2.8.1	Log On	p. 103
2.8.2	Autoprovision Optical Shelf Equipment and Facilities	p. 105
2.8.3	Manually Provision Optical Shelf Equipment	p. 111
2.8.4	Manually Provision WDM and OSC Facilities	p. 122
2.8.5	Place ODCC In Service	p. 125
2.9	Provision Synchronization and/or Tributary Shelf OSC Units	p. 129

2.9.1	Log On	p. 130
2.9.2	Autoprovision Synchronization and/or OSC Plug-In Units	p. 131
2.9.3	Manually Provision Synchronization and/or OSC Plug-In Units	p. 135
2.9.4	Provision Synchronization	p. 140
2.10	Install Intrashelf Fiber-Optic Cables	p. 146
2.10.1	Overview Installing Intrashelf Cables Core Configuration	p. 146
2.10.2	Examples of Intrashelf Cabling	p. 148
2.10.3	Installing Intrashelf Cables	p. 159
2.11	Install LAMs and MPO Connections	p. 183
2.11.1	Install LAMs and MPO Connections to Mux/Demux Units (WSS Core Configuration)	p. 183
2.11.2	Install LAMs and MPO Connections to 2D-ROADM Units (2D-ROADM Configuration)	p. 186
2.12	Connect DCMs or Install Loopback Cables	p. 191
2.12.1	Overview of DCM or Loopback Cabling Core Configuration	p. 191
2.12.2	Connect Amplifiers to DCMs or Install Loopback Cables	p. 193
2.13	Provision HUB Interconnections	p. 202
2.13.1	Provision HUB Interconnections—Symmetric HUB Node	p. 204
2.13.2	Provision HUB Interconnections—Asymmetric HUB Node	p. 233
2.14	Make Network Connections	p. 247
2.14.1	Connect Network Fiber-Optic Cables	p. 247
2.14.2	Verify Fiber Connections	p. 258
2.14.3	Reset the Span Loss Variation Alarm References	p. 267
2.15	Provision Control Plane	p. 277
2.15.1	Enable Auto Address Server for IP Address Provisioning	p. 279
2.15.2	Manually Provision IP Addresses	p. 283
2.15.3	Enable IP Routing by OSPF	p. 287
2.15.4	Enable IP Routing by Integrated IS-IS	p. 294
2.15.5	Launch Network Topology View	p. 297
2.15.6	Provision Optical Reach Data	p. 300
<hr/>		
3	Acceptance Testing	p. 313
3.1	Test Synchronization Reference Switching	p. 314
3.1.1	Testing Manual Switching of Externally Timed Tributary Shelf	p. 314
3.1.2	Testing Automatic Equipment Protection Switching of Synchronization Units	p. 317
3.2	Verify Network Operation	p. 319
<hr/>		
4	ILA Node Turn-Up	p. 320
4.1	About System Turn-up Core Configuration ILA Node	p. 321
4.2	Apply Power and Install Fan Units	p. 326
4.3	Install Primary NE Management Units, and Configure the ILA Shelf	p. 327
4.3.1	Install MPMA-SHPx Plug-In Unit	p. 328
4.3.2	Verify Software Version	p. 330

4.3.3	Change System Type	p. 331
4.3.4	Provision Shelf Location Identifiers	p. 335
4.3.5	Provision OSC Units	p. 336
4.4	Provision System-Level Parameters, LCN Port, and GOS	p. 338
4.4.1	Provision System-Level Parameters	p. 338
4.4.2	Provision LCN Port	p. 347
4.4.3	Provision GOS	p. 354
4.5	Provision ILA Shelf Equipment and Facilities	p. 356
4.5.1	Log On	p. 357
4.5.2	Autoprovision Equipment and Facilities—ILA Shelf	p. 358
4.5.3	Manually Provision Equipment—ILA Shelf	p. 363
4.5.4	Manually Provision WDM and OSC Facilities—ILA Shelf	p. 366
4.5.5	Place ODCC In Service—ILA Shelf	p. 368
4.6	Install Intrashelf Fiber-Optic Cables	p. 371
4.7	Connect DCMs or Install Loopback Cables	p. 379
4.7.1	Overview DCM or Loopback Cabling Core Configuration ILA Node	p. 379
4.7.2	Connect Amplifiers to DCMs or Install Loopback Cables	p. 381

5	Nodal Test Tool	p. 386
5.1	About the Nodal Test Tool	p. 387
5.2	Nodal Test Tool Prerequisites	p. 388
5.3	Using Nodal Test Tool for In-Service Testing	p. 403
5.4	Using Nodal Test Tool for System Turn-Up	p. 409
5.4.1	Prepare and Configure the Node for Fiber Testing (If Necessary)	p. 409
5.4.2	Install Loopback Cables on Slot 1 Amplifier (If Installed)	p. 411
5.4.3	Install Loopback Cables on Slot 19 or 11 Amplifier (If Installed)	p. 412
5.4.4	Start Nodal Fiber Test	p. 416
5.4.5	Remove Loopback Cables	p. 419

A	Data Record Forms	p. 420
A.1	Shelf Voltage Measurement Record	p. 421
A.2	Network-Side Optical Power Measurement Record	p. 422
A.3	Client-Side Optical Power Measurement Record	p. 423

Index	p. 426
-------	--------

1

Introduction to System Turn-Up Core Configuration

This practice contains turn-up and acceptance testing procedures for the FLASHWAVE® 7500 Core Configuration system.

This practice contains the following chapters:

- [Introduction to System Turn-Up Core Configuration](#)—Provides an overview to the practice and configuration guidelines for the core configuration
- [System Turn-Up](#)—Describes how to turn up a network of FLASHWAVE 7500 nodes without service
- [Acceptance Testing](#)—Describes how to verify correct operation of the network after turn-up
- [ILA Node Turn-Up](#)—Describes how to turn up an ILA node
- [Nodal Test Tool](#)—Describes how to use the Nodal Test Tool for fiber testing
- [Data Record Forms](#)—Provides data record forms

This practice does not cover:

- Shelf installation
- Service addition after turn-up

Note: For FLASHWAVE 7500 shelf installation, refer to [Core Configuration](#). To add service to a working system, refer to [Service Addition](#).

The flowchart in the following figure shows the turn-up procedure. The procedure assumes that the FLASHWAVE 7500 Core Configuration shelves have been installed at each site (refer to [Core Configuration](#)) and that fiber has been installed between the sites.

After each node in the ring is turned up (refer to [System Turn-Up](#)), correct operation of the ring is verified by acceptance testing (refer to [Acceptance Testing](#)). The system is then turned up and ready for services to be added (refer to [Service Addition](#)).

Note: Procedures for ILA node turn-up are provided in [About System Turn-up Core Configuration ILA Node](#) .




Figure 1: Turning Up FLASHWAVE 7500 Core Configuration System (Overall Flowchart)

2

System Turn-Up

In this chapter:

- | | | | |
|-----|---|------|--|
| 2.1 | About System Turn-up Core Configuration | 2.7 | Create Subtending Shelves and Install Shelf Processors |
| 2.2 | Slot Labels and AIDs | 2.8 | Provision Optical Shelf Equipment and Facilities |
| 2.3 | Turn-Up Provisioning Hierarchy FLASHWAVE 7500–Core Configuration | 2.9 | Provision Synchronization and/or Tributary Shelf OSC Units |
| 2.4 | Verify Shelf Labeling, Verify LAN and RICC Cable Connections, Apply Power, and Install Fan Units | 2.10 | Install Intrashelf Fiber-Optic Cables |
| 2.5 | Install Primary NE Management Units in Shelf OS1, and Configure Shelf OS1 as the Main Optical Shelf | 2.11 | Install LAMs and MPO Connections |
| 2.6 | Provision System-Level Parameters, LCN Port, and GOS | 2.12 | Connect DCMs or Install Loopback Cables |
| | | 2.13 | Provision HUB Interconnections |
| | | 2.14 | Make Network Connections |
| | | 2.15 | Provision Control Plane |

2.1

About System Turn-up Core Configuration


This chapter describes how to turn up a FLASHWAVE® 7500 Core Configuration network without service. After completing this process, you should perform acceptance testing ([Acceptance Testing](#)).

[System Turn-Up Flowchart](#) provides a flowchart of the turn-up process described in this chapter. [Slot Labels and AIDs](#) and [Slot Labels and AIDs](#) describe the shelves and plug-in units, including slot labels and AIDs.

The FLASHWAVE 7500 NE can be configured in several ways. Example equipment configurations are described in [Example Equipment Configurations](#). The work order should specify the configuration of shelves at each node and the configuration of plug-in units within each shelf.

System Turn-Up Flowchart

The flowchart shown in the following figure illustrates the sequence to turn up nodes without service. After all nodes are turned up, verifying that the network-level fiber connections are correct is important.



mt1718em_16

Figure 2: System Turn-Up (Procedure Flowchart)

Prerequisites

Before proceeding with node turn-up procedures, perform or verify the following:

- Obtain the work order, or equivalent, specifying:
 - The shelves and plug-in units required for the turn-up.
 - Network design requirements, including, but not limited to, expected span loss, attenuation requirements and DCM requirements.
 - Housekeeping alarm provisioning and cabling requirements. OSS considerations, including, but not limited to, data networking, IP addresses, default gateway, OSPF, SNMP, and control plane requirements.

Note: *The form of the work order depends on local practice.*

- Become familiar with the node requirements, including the following:
 - The equipment configuration needed at the site: whether or not the node is a HUB node (includes the Auxiliary Optical shelves) and the number and arrangement of Tributary shelves (if any) within the shelf hierarchy ([Figure 22](#)). Refer to [Example Equipment Configurations](#).
 - Which shelves, if any, require Synchronization plug-in units.

Note: *Synchronization units support timing and synchronization for Flexponder™ optical line cards. They are generally required in every shelf that include a Flexponder unit. However, the Synchronization unit is optional for shelves that include only single-unit applications of the IFMA-BXC1 Flexponder. If all STS cross-connects are within individual IFMA-BXC1 units (never between units), the Synchronization unit can be omitted from the shelf and timing accuracy will be ± 20 ppm for the IFMA-BXC1 units.*

- Acquire all plug-in units and cables required for the turn-up.
- Verify that the FLASHWAVE 7500 shelves are installed and that the acceptance procedures listed in [Introduction to Equipment Installation](#), have been completed.
- Ensure that fiber has been placed between the sites.
- Review the node turn-up procedure shown in the preceding figure.
- Familiarize yourself with the provisioning hierarchy for the FLASHWAVE 7500 Core Configuration system ([Turn-Up Provisioning Hierarchy FLASHWAVE 7500–Core Configuration](#)).
- Familiarize yourself with the FLASHWAVE 7500 system as described in [Introduction to the FLASHWAVE 7500 All-Optical Transport Platform](#).
- Familiarize yourself with the NETSMART® 500 Element Manager for provisioning the FLASHWAVE 7500 system. Refer to *FNC-0500-0311-010, NETSMART 500 User Guide*.
- Ensure that a terminal emulator (such as a HyperTerminal® emulator) is available, and familiarize yourself with its operation.

- Familiarize yourself with the FLASHWAVE 7500 access identifiers (AIDs) described in [Access Identifiers](#).
- Ensure that the craft interface device is connected, activated, and set up in the required interface modes as described in [Craft Interface Operations](#).
- Refer to [Introduction to Maintenance and Trouble Clearing](#), for general procedures and information on replacing plug-in units and handling optical units and optical fibers.
- Refer to [Introduction to TL1 Commands](#) for additional command and parameter information and typical response messages.
- Perform initial turn-up procedures locally through the craft interface (connectors TERM1 or TERM2) provided on the front of the Main Optical shelf (OS1).



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Warning: When handling FLASHWAVE 7500 plug-in units, wear an ESD wrist strap with a minimum resistance of 1000 kilohms to prevent possible damage to the units. Before using the strap, check it for opens, shorts, and minimum resistance value. If the strap does not pass these checks, do not use it.



Caution: Verify that you have received a completed (COMPLD) response to each command before going to the next step. If you are unable to complete a command after several tries, call Fujitsu Network Communications Inc. (FNC) at 1-800-USE-FTAC for technical assistance.



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to [Fiber Cable Handling](#).

Note: Until it is fully provisioned, the FLASHWAVE 7500 generates false alarms. These alarms clear as the system is provisioned. Any remaining alarms are cleared (other than LOS, if applicable) at the end of the turn-up procedure.

Example Equipment Configurations

The FLASHWAVE 7500 NE can be configured in several ways. The equipment required at each NE (shelves and plug-in units) depends on the role that the NE serves in the network. This subsection provides a few examples of the equipment required for some representative configurations.

For more information on network applications, refer to [Applications](#).

Terminal Node

At a terminal node, only one degree (WDM facility) of the NE is provisioned. The following figure shows the equipment required to support adds and drops to WDM facility OS1-1-PE1. The node includes the Main Optical shelf OS1 and up to 10 Tributary shelves.

Note: The following figure applies to the WSS Core Configuration. The 2D-ROADM Configuration is identical, except that the 2D-ROADM unit (SFMA-RDC1) is used in place of SFMA-CMC1 and filler panels are used in place of MDMA-RMC1.

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
APMA-xxxx		SFMA-CMC1		MDMA-RMC1		Filler Panel		Filler Panel		SCMA-SCC4		MPMA-SHP3		Filler Panel		Filler Panel		Filler Panel		Filler Panel	
FAN6		FAN6		FAN6		FAN6															
FAN-1		FAN-2		FAN-3		FAN-4															

Main Optical Shelf OS1

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20					
Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units									TCMA-ST31		MPMA-SHP3		Filler Panel		TCMA-ST31		Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units								
FAN6		FAN6		FAN6		FAN6																			
FAN-1		FAN-2		FAN-3		FAN-4																			

Tributary Shelf OSn

mt1714hc_10

Figure 3: Equipment for Terminal Node Supporting OS1-1-PE1 (WDM) Adds and Drops

The following figure shows the equipment required in a terminal node to support adds and drops to WDM facility OS1-19-PE1. The node includes the Main Optical shelf OS1 and up to 10 Tributary shelves.

Note: The following figure applies to the WSS Core Configuration. The 2D-ROADM Configuration is identical, except that the 2D-ROADM unit (SFMA-RDC1) is used in place of SFMA-CMC1 and filler panels are used in place of MDMA-RMC1.

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
Filler Panel	Filler Panel	Filler Panel	Filler Panel	Filler Panel	Filler Panel	Filler Panel	Filler Panel	Filler Panel	Filler Panel	MPMA-SHP3	Filler Panel	Filler Panel	Filler Panel	Filler Panel	MDMA-RMC1		SFMA-CMC1			APMA-xxxx	
FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6	
FAN-1		FAN-2		FAN-3		FAN-4		FAN-5		FAN-6		FAN-7		FAN-8		FAN-9		FAN-10		FAN-11	

Main Optical Shelf OS1

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units									TCMA-ST31	MPMA-SHP3	Filler Panel	TCMA-ST31	Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units								
FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6		FAN6	
FAN-1		FAN-2		FAN-3		FAN-4		FAN-5		FAN-6		FAN-7		FAN-8		FAN-9		FAN-10		FAN-11	

Tributary Shelf OSn

ml1714gy_8

Figure 4: Equipment for Terminal Node Supporting OS1-19-PE1 (WDM) Adds and Drops

Add/Drop Node

At nodes in ring networks, two degrees (WDM facilities) of the NE are provisioned. Likewise, at intermediate nodes (not a terminal node) in linear networks, two degrees of the NE are provisioned. The following figure shows the equipment required to support adds and drops to both WDM facilities: OS1-1-PE1 and OS1-19-PE1. The node includes the Main Optical shelf OS1 and up to 10 Tributary shelves.

Note: The following figure applies to the WSS Core Configuration. The 2D-ROADM Configuration is identical, except that 2D-ROADM units (SFMA-RDC1) are used in place of the SFMA-CMC1 units and filler panels are used in place of the MDMA-RMC1 units.

1	2	3	4	5	6	7	8	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20
APMA-xxxx		SFMA-CMC1		MDMA-RMC1		Filler Panel	Filler Panel	Filler Panel	MPMA-SHP3	Filler Panel	Filler Panel	Filler Panel	Filler Panel	MDMA-RMC1		SFMA-CMC1		APMA-xxxx	
								SCMA-SCC4			SCMA-SCC4								
FAN6				FAN6				FAN6				FAN6							
FAN-1		FAN-2		FAN-3		FAN-4													

Main Optical Shelf OS1

1	2	3	4	5	6	7	8	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units									TCMA-ST31	Filler Panel	TCMA-ST31	Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units								
								SCMA-SCC4			SCMA-SCC4									
FAN6				FAN6				FAN6				FAN6								
FAN-1		FAN-2		FAN-3		FAN-4														

Tributary Shelf OSn

mt1714gy_8

Figure 5: Equipment for 2-Degree Add/Drop Node

Express Node

If add/drop support is not currently needed at the site, the node configuration shown in the following figure can be used in place of the preceding figure. This Express node configuration allows only pass-through traffic but can be upgraded in the future to support adds and drops. The node includes only one shelf, the Main Optical shelf OS1.




Figure 6: Equipment for 2-Degree Express Node

ILA Node

The In-Line Amplifier (ILA) node configuration is used to increase the span length between add/drop NEs. The node includes only one shelf, the Main Optical shelf OS1. The following figure shows the equipment required.




Figure 7: Equipment for ILA Node

The ILA node configuration is functionally similar to the Express node configuration ([Express Node](#)). Both configurations support only pass-through traffic. Their main differences are:

- The Express node provides channel equalization and the ILA node does not.
- After turn-up, the ILA node passes traffic for all channels in both directions without additional provisioning. The Express node requires provisioning of WCH cross-connects for each channel that carries traffic.

HUB Node

A HUB node has more than one Optical shelf and at least one interconnect between network degrees residing on separate shelves.

Note: *The two network degrees on the same Optical shelf are automatically interconnected.*

The following figure shows the required equipment for a 4-degree add/drop HUB node. The node supports adds and drops to all four WDM facilities: OS1-1-PE1, OS1-19-PE1, OS2-1-PE1, and OS2-19-PE1. The node includes the Main Optical shelf OS1, the Auxiliary Optical shelf OS2, and up to 20 Tributary shelves.

Note: *This configuration supports Tributary shelves OSn (n=10...13, 20...23, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230). Synchronization units (TCMA-ST31) are needed only when Flexponder units are installed in the shelf. OSC units (SCMA-SCC4) are only installed in the Tributary shelf to support interoperability with Extension Configuration NEs.*

1	2	3	4	5	6	7	8	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20
APMA-xxxx	SFMA-CMC1	MDMA-RMC1	SFMA-CDC1	MCMA-RCS1		MPMA-SHP3	Filler Panel	MCMA-RCS1		SFMA-CDC1	MDMA-RMC1	SFMA-CMC1	APMA-xxxx						
				SCMA-SCC4	MPMA-SHP3			SCMA-SCC4											
FAN6				FAN6				FAN6				FAN6							
FAN-1				FAN-2				FAN-3				FAN-4							

Main Optical Shelf OS1

1	2	3	4	5	6	7	8	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20
APMA-xxxx	SFMA-CMC1	MDMA-RMC1	SFMA-CDC1	MCMA-RCS1		MPMA-SHP3	Filler Panel	MCMA-RCS1		SFMA-CDC1	MDMA-RMC1	SFMA-CMC1	APMA-xxxx						
				SCMA-SCC4	MPMA-SHP3			SCMA-SCC4											
FAN6				FAN6				FAN6				FAN6							
FAN-1				FAN-2				FAN-3				FAN-4							

Auxiliary Optical Shelf OS2

1	2	3	4	5	6	7	8	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20
Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units				TCMA-ST31		MPMA-SHP3	Filler Panel	TCMA-ST31		Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units									
				SCMA-SCC4	MPMA-SHP3			SCMA-SCC4											
FAN6				FAN6				FAN6				FAN6							
FAN-1				FAN-2				FAN-3				FAN-4							

Tributary Shelf OSn

mt1714ta_7

Figure 8: Equipment for 4-Degree Add/Drop HUB Node

The following figure shows the required equipment for a 6-degree add/drop HUB node. The node supports adds and drops to six WDM facilities: OS1-1-PE1, OS1-19-PE1, OS2-1-PE1, OS2-19-PE1, OS3-1-PE1, and OS3-19-PE1. The

node includes the Main Optical shelf OS1, the Auxiliary Optical shelf OS2, and the Auxiliary Optical shelf OS3, and up to 20 Tributary shelves.

Note: *This configuration supports Tributary shelves OSn (n=10...13, 20...23, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330). Synchronization units (TCMA-ST31) are only needed when Flexponder units are installed in the shelf. OSC units (SCMA-SCC4) are only installed in the Tributary shelf to support interoperability with Extension Configuration NEs.*

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
APMA-xxxx	SFMA-CMC1	MDMA-RMC1	SFMA-CDC1	SCMA-SCC4	MCMA-RCS1	MPMA-SHP3	Filler Panel	SCMA-SCC4	MCMA-RCS1	SFMA-CDC1	MDMA-RMC1	SFMA-CMC1	APMA-xxxx								
FAN6				FAN6				FAN6				FAN6									
FAN-1				FAN-2				FAN-3				FAN-4									

Main Optical Shelf OS1

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
APMA-xxxx	SFMA-CMC1	MDMA-RMC1	SFMA-CDC1	SCMA-SCC4	MCMA-RCS1	MPMA-SHP3	Filler Panel	SCMA-SCC4	MCMA-RCS1	SFMA-CDC1	MDMA-RMC1	SFMA-CMC1	APMA-xxxx								
FAN6				FAN6				FAN6				FAN6									
FAN-1				FAN-2				FAN-3				FAN-4									

Auxiliary Optical Shelf OSn (n = 2, 3)

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20		
Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units				TCMA-ST31	MPMA-SHP3	Filler Panel	TCMA-ST31	Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units														
FAN6				FAN6				FAN6				FAN6										
FAN-1				FAN-2				FAN-3				FAN-4										

Tributary Shelf OSn

m1714od_7

Figure 9: Equipment for 6-Degree Add/Drop HUB Node

The following figure shows the required equipment for an 8-degree add/drop HUB node. The node supports adds and drops to eight WDM facilities: OS1-1-PE1, OS1-19-PE1, OS2-1-PE1, OS2-19-PE1, OS3-1-PE1, OS3-19-PE1,

OS4-1-PE1, and OS4-19-PE1. The node includes the Main Optical shelf OS1, the Auxiliary Optical shelf OS2, the Auxiliary Optical shelf OS3, the Auxiliary Optical shelf OS4, and up to 20 Tributary shelves.

Note: This configuration supports Tributary shelves OSn (n=10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430). Synchronization units (TCMA-ST31) are only needed when Flexponder units are installed in the shelf. OSC units (SCMA-SCC4) are only installed in the Tributary shelf to support interoperability with Extension Configuration NEs.

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
APMA-xxxx		SFMA-CMC1		MDMA-RMC1		SFMA-CDC1		SCMA-SCC4	MCMA-RCS1	MPMA-SHP3	Filler Panel	SCMA-SCC4	SFMA-CDC1		MDMA-RMC1		SFMA-CMC1		APMA-xxxx		
									9			11									
FAN6				FAN6				FAN6				FAN6									
FAN-1				FAN-2				FAN-3				FAN-4									

Main Optical Shelf OS1

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
APMA-xxxx		SFMA-CMC1		MDMA-RMC1		SFMA-CDC1		SCMA-SCC4	MCMA-RCS1	MPMA-SHP3	Filler Panel	SCMA-SCC4	SFMA-CDC1		MDMA-RMC1		SFMA-CMC1		APMA-xxxx		
									9			11									
FAN6				FAN6				FAN6				FAN6									
FAN-1				FAN-2				FAN-3				FAN-4									

Auxiliary Optical Shelf OSn (n = 2...4)

1	2	3	4	5	6	7	8	9	10	MPMA-1	MPMA-2	12	13	14	15	16	17	18	19	20	
Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units									TCMA-ST31	MPMA-SHP3	Filler Panel	TCMA-ST31	Available for OLC or FLASHWAVE LIGHTGUARD Plug-In Units								
									9			11									
FAN6				FAN6				FAN6				FAN6									
FAN-1				FAN-2				FAN-3				FAN-4									

Tributary Shelf OSn

mt174oe_6


Figure 10: Equipment for 8-Degree Add/Drop HUB Node

2.2 Slot Labels and AIDs

Optical Shelf Slot Labels and AIDs

WSS Core Configuration

The following figures and table show and describe plug-in unit slot labels, AIDs, locations, and equipment type and AID mapping on the Main Optical shelf OS1 and an Auxiliary Optical shelf OSn (n = 2...4, 25, 26).



Note: n = 1...4

mt1714he_6

Figure 11: Optical Shelf Plug-In Unit Slot Labels and Slot AIDs (WSS Core Configuration)




Figure 12: Optical Shelf Plug-In Unit Slot Locations (WSS Core Configuration)

Table 1: Optical Shelf Equipment Type and Slot AID Mapping (WSS Core Configuration)

Slot Label	Slot AID ¹	Equipment	Type (Default in Bold)
n/a	OSn	Shelf	SHU3
1	OSn-1	Amplifier	APMA-L2C1
2	OSn-2 (AID not used)		APMA-M2C1 APMA-ULC1 APMA-M2U1 APMA-ULU1 APMA-MHU1
3	OSn-3	WSS Core Switch unit	SFMA-CMC1
4	OSn-4 (AID not used)		
5	OSn-5	Mux/Demux unit	MDMA-RMC1
6	OSn-6 (AID not used)		
7	OSn-7	WSS HUB Switch unit	SFMA-CDC1
8	OSn-8		

¹ n = 1...4, 25, 26


Table 1: Optical Shelf Equipment Type and Slot AID Mapping (WSS Core Configuration) (Cont.)

Slot Label	Slot AID ¹	Equipment	Type (Default in Bold)
9	OSn-9	OSC Processing unit	SCMA-SCC4
10	OSn-10	OSC HUB Interconnect unit	MCMA-RCS1
MPMA-1	OSn-MPMA-1	Shelf Processor unit	MPMA-SHP3 MPMA-SHP4
MPMA-2	Slot not used		n/a
11	OSn-11	OSC Processing unit	SCMA-SCC4
12	OSn-12	OSC HUB Interconnect unit	MCMA-RCS1
13	OSn-13	WSS HUB Switch unit	SFMA-CDC1
14	OSn-14		
15	OSn-15	Mux/Demux unit	MDMA-RMC1
16	OSn-16 (AID not used)		
17	OSn-17	WSS Core Switch unit	SFMA-CMC1
18	OSn-18 (AID not used)		
19	OSn-19	Amplifier	APMA-L2C1 APMA-M2C1 APMA-ULC1 APMA-M2U1 APMA-ULU1 APMA-MHU1
20	OSn-20 (AID not used)		
FAN-1	OSn-FAN-1	Fan unit	FAN6
FAN-2	OSn-FAN-2		
FAN-3	OSn-FAN-3		
FAN-4	OSn-FAN-4		

2D-ROADM Core Configuration


The following figures and table show and describe plug-in unit slot labels, AIDs, locations, and equipment type and AID mapping on the Optical shelf OS1.

¹ n = 1...4, 25, 26



mi1718iv_4

Figure 13: Optical Shelf Plug-In Unit Slot Labels and Slot AIDs (2D-ROADM Core Configuration)



mi1718iv_5

Figure 14: Optical Shelf Plug-In Unit Slot Locations (2D-ROADM Core Configuration)

Table 2: Optical Shelf Equipment Type and Slot AID Mapping (2D-ROADM Core Configuration)

Slot Label	Slot AID	Equipment	Type (Default in Bold)
n/a	OS1	Shelf	SHU3 ²
1	OS1-1	Amplifier	APMA-L2C1 APMA-M2C1
2	OS1-2 (AID not used)		APMA-ULC1 APMA-M2U1 APMA-ULU1 APMA-MHU1
3	OS1-3	2D-ROADM unit	SFMA-RDC1
4	OS1-4 (AID not used)		The default equipment type for this slot (SFMA-CMC1) is not applicable to the 2D-ROADM configuration.
5	OS1-5	OLC or Regenerator unit	Single-wide OLCs (any slot): IFMA-SB IFMA-U1/U2/U3/U4 IFMA-U52 IFMA-RG Double-wide OLCs (odd-numbered slots only): IFMA-8T/8T2 IFMA-GU IFMA-U12/U22/U32 IFMA-BX IFMA-SM IFMA-RG3 IFMA-QU/QU2 IFMA-QM/QM2 IFMA-QR/QR2
6	OS1-6		
7	OS1-7		
8	OS1-8		
9	OS1-9	OSC Processing unit	SCMA-SCC4
10	OSn-10	Synchronization unit	TCMA-ST31
MPMA-1	OS1-MPMA-1	Shelf Processor unit	MPMA-SHP3 MPMA-SHP4
MPMA-2	Slot not used	n/a	n/a
11	OS1-11	OSC Processing unit	SCMA-SCC4
12	OSn-12	Synchronization unit	TCMA-ST31
13	OS1-13	OLC or Regenerator unit	Same as slots 5...8
14	OS1-14		
15	OS1-15		
16	OS1-16		


² Non-issue shelf SHU3 does not fully support IFMA-BXC1. Cross-shelf STS grooming requires shelf SHU3 issue 2 or later.

Table 2: Optical Shelf Equipment Type and Slot AID Mapping (2D-ROADM Core Configuration) (Cont.)

Slot Label	Slot AID	Equipment	Type (Default in Bold)
17	OS1-17	2D-ROADM unit	SFMA-RDC1
18	OS1-18 (AID not used)		The default equipment type for this slot (SFMA-CMC1) is not applicable to the 2D-ROADM configuration.
19	OS1-19	Amplifier	Same as slot 1.
20	OS1-20 (AID not used)		
FAN-1	OS1-FAN-1	Fan unit	FAN6
FAN-2	OS1-FAN-2		
FAN-3	OS1-FAN-3		
FAN-4	OS1-FAN-4		


Tributary Shelf Slot Labels and AIDs

The following figures and tables show and describe plug-in unit slot labels, AIDs, locations, and equipment type and AID mapping on the Tributary shelf OSn (n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430).



mt1656vw_6

Figure 15: Tributary Shelf Plug-In Unit Slot Labels and Slot AIDs



mt1656vw_9

Figure 16: Tributary Shelf Plug-In Unit Slot Locations

Table 3: Tributary Shelf Equipment Type and Slot AID Mapping (WSS Core Configuration)

Slot Label	Slot AID ³	Equipment	Type (Default in Bold)
n/a	OSn	Shelf	SHU3 ⁴
1	OSn-1	OLC, Regenerator unit, FLASHWAVE LIGHTGUARD unit, or 1-Channel Amplifier	Single-wide (any slot):
2	OSn-2		IFMA-SB
3	OSn-3		IFMA-HG
4	OSn-4		IFMA-LL
5	OSn-5		IFMA-U1
6	OSn-6		IFMA-U2
7	OSn-7		IFMA-U3
8	OSn-8		IFMA-U4
			Double-wide (odd slots only):
			IFMA-HL
			IFMA-8T
			IFMA-8T2
			IFMA-BX
			IFMA-SM
			IFMA-GU
			IFMA-LE
			IFMA-U12
			IFMA-U22
			IFMA-U32
			IFMA-RG3
			IFMA-QU/QU2
			IFMA-QM/QM2
			IFMA-QR/QR2
9	OSn-9	OSC Processing unit	SCMA-SCC4
10	OSn-10	Synchronization unit	TCMA-ST31
MPMA-1	OSn- MPMA-1	Shelf Processor unit	MPMA-SHP3 MPMA-SHP4
MPMA-2	Slot not used	n/a	n/a
11	OSn-11	OSC Processing unit	SCMA-SCC4
12	OSn-12	Synchronization unit	TCMA-ST31
13	OSn-13	OLC, Regenerator unit, FLASHWAVE LIGHTGUARD unit, or 1-Channel Amplifier	Same as slots 1...8
14	OSn-14		
15	OSn-15		
16	OSn-16		
17	OSn-17		
18	OSn-18		
19	OSn-19		
20	OSn-20		
FAN-1	OSn-FAN-1	Fan unit	FAN6

³ n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430

⁴ Non-issue shelf SHU3 does not fully support IFMA-BXC1. Cross-shelf STS grooming requires shelf SHU3 issue 2 or later.

Table 3: Tributary Shelf Equipment Type and Slot AID Mapping (WSS Core Configuration) (Cont.)

Slot Label	Slot AID ³	Equipment	Type (Default in Bold)
FAN-2	OSn-FAN-2		
FAN-3	OSn-FAN-3		
FAN-4	OSn-FAN-4		

Table 4: Tributary Shelf Equipment Type and Slot AID Mapping (2D-ROADM Core Configuration)

Slot Label	Slot AID ⁵	Equipment	Type (Default in Bold)
n/a	OSn	Shelf	SHU3⁶
1	OSn-1	OLC, Regenerator unit, FLASHWAVE LIGHTGUARD unit, or 1-Channel Amplifier	Single-wide (any slot):
2	OSn-2		IFMA-SB
3	OSn-3		IFMA-HG
4	OSn-4		IFMA-LL
5	OSn-5		IFMA-U1
6	OSn-6		IFMA-U2
7	OSn-7		IFMA-U3
8	OSn-8		IFMA-U4
			Double-wide (odd slots only):
			IFMA-HL
			IFMA-8T
			IFMA-8T2
			IFMA-BX
			IFMA-SM
			IFMA-GU
			IFMA-LE
			IFMA-U12
			IFMA-U22
			IFMA-U32
			IFMA-RG3
			IFMA-QU/QU2
			IFMA-QM/QM2
			IFMA-QR/QR2
9	OSn-9	OSC Processing unit	SCMA-SCC4
10	OSn-10	Synchronization unit	TCMA-ST31
MPMA-1	OSn- MPMA-1	Shelf Processor unit	MPMA-SHP3 MPMA-SHP4
MPMA-2	Slot not used	n/a	n/a
11	OSn-11	OSC Processing unit	SCMA-SCC4
12	OSn-12	Synchronization unit	TCMA-ST31

³ n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430

⁵ n = 10...13, 100, 101, 110, 111, 120, 130

⁶ Non-issue shelf SHU3 does not fully support IFMA-BXC1. Cross-shelf STS grooming requires shelf SHU3 issue 2 or later.

Table 4: Tributary Shelf Equipment Type and Slot AID Mapping (2D-ROADM Core Configuration) (Cont.)

Slot Label	Slot AID ⁵	Equipment	Type (Default in Bold)
13	OSn-13	OLC, Regenerator unit, FLASHWAVE LIGHTGUARD unit, or 1-Channel Amplifier	Same as slots 1...8
14	OSn-14		
15	OSn-15		
16	OSn-16		
17	OSn-17		
18	OSn-18		
19	OSn-19		
20	OSn-20		
FAN-1	OSn-FAN-1	Fan unit	FAN6
FAN-2	OSn-FAN-2		
FAN-3	OSn-FAN-3		
FAN-4	OSn-FAN-4		

ILA Shelf Slot Labels and AIDs

Procedures for the in-line amplifier (ILA) shelf turn-up are presented in [ILA Node Turn-Up](#). For ILA Shelf slot labels and AIDs, refer to [About System Turn-up Core Configuration ILA Node](#).

⁵ n = 10...13, 100, 101, 110, 111, 120, 130

2.3

Turn-Up Provisioning Hierarchy FLASHWAVE 7500 Core Configuration

The various entities (equipment, facilities, cross-connects, and so on) within the FLASHWAVE 7500 Core Configuration must be provisioned in a certain order. This section contains provisioning hierarchy tables that indicates the order in which the entities can be added to or deleted from the system, along with the applicable TL1 root commands.

Shelf Entities, WSS Core Configuration

The following figure presents the provisioning hierarchy for shelves of the FLASHWAVE 7500 WSS Core Configuration system. Auxiliary Optical shelves OS2...OS4, OS25, and OS26 apply to HUB configurations only. Auxiliary Optical shelves OS25 and OS26 apply to asymmetric HUB configurations only. The WSS Core Configuration supports a maximum of 20 tributary shelves per node.




Figure 17: Turn-Up Provisioning Hierarchy–Shelves (WSS Core Configuration)

Optical Shelf Equipment, WSS Core Configuration

The following figure presents the hierarchy for provisioning equipment within optical shelves of the WSS Core Configuration system. It applies to the Main Optical shelf (OS1) and to the Auxiliary Optical shelves (OS2...OS4, OS25, OS26) if the node is a HUB node.




Figure 18: Turn-Up Provisioning Hierarchy–Optical Shelf (WSS Core Configuration)

Shelf Entities, 2D-ROADM Core Configuration

The following figure presents the provisioning hierarchy for shelves of the FLASHWAVE 7500 2D-ROADM Core Configuration system.




Figure 19: Turn-Up Provisioning Hierarchy–Shelves (2D-ROADM Configuration)

Optical Shelf Equipment, 2D-ROADM Core Configuration

The following figure presents the hierarchy for provisioning equipment within the Optical shelf of the 2D-ROADM Core Configuration system.




Figure 20: Turn-Up Provisioning Hierarchy–Optical Shelf (2D-ROADM Core Configuration)

2.4

Verify Shelf Labeling, Verify LAN and RICC Cable Connections, Apply Power, and Install Fan Units

In this section:

- 2.4.1 Verify Shelf Labeling
- 2.4.2 Verify LAN Connections
- 2.4.3 Verify RICC Connections
- 2.4.4 Apply Power, and Install Fan Plug-In Units

This is the starting point for turning up all types of Core Configuration nodes, except ILA nodes. If you are provisioning an ILA node, proceed to [ILA Node Turn-Up](#).

The following figure shows a flowchart identifying the subprocedures used to begin the node turn-up.





Figure 21: Begin Node Turn-Up (Procedure Flowchart)

The following figure shows the shelves that can be included in a WSS Core Configuration node and how they are related in the hierarchy of LAN connections.

System Turn-Up

Verify Shelf Labeling, Verify LAN and RICC Cable Connections, Apply Power, and Install Fan Units



ml1714qn_5

Figure 22: Shelf AIDs and Hierarchy of LAN Connections at HUB Node

The preceding figure shows each optical shelf that can support a maximum of 10 Tributary shelves. An additional constraint, not presented in the preceding figure, is the node as a whole can support no more than 20 Tributary shelves.

The following figure shows the shelves that can be included in a 2D-ROADM node. The AID structure and hierarchy of LAN connections matches the following figure, but only the Main Optical shelf (OS1) and associated Tributary shelves are included.





Figure 23: Shelf AIDs and Hierarchy of LAN Connections at Two-Degree ROADM Node

The following figure shows another special case. If the node is an asymmetric HUB node (Keyword HUBMODE=MANUAL in the ED-SYS command), the system can include two shelves in addition to those shown in [Figure 22](#). The additional shelves are Optical shelves OS25 and OS26. Both shelves connect to shelf OS2 in the hierarchy of LAN connections. Shelves OS25 and OS26 does not support subtending Tributary shelves.

System Turn-Up

Verify Shelf Labeling, Verify LAN and RICC Cable Connections, Apply Power, and Install Fan Units



m1718tb_2

Figure 24: Shelf AIDs and Hierarchy of LAN Connections at Asymmetric HUB Node

The following figure shows the Optical/Tributary shelf backplane.




Figure 25: Optical/Tributary Shelf Backplane

Note: The backplane shown above is an Issue 6 SHU3 shelf. The SHU3 Issue 6 shelf does not have the MPMA-2 port cluster (CN1...CN5 and CN12...CN17).

2.4.1

Verify Shelf Labeling

Note: This is the starting point for turning up all types of Core Configuration nodes, except ILA nodes. If you are turning up an ILA node, proceed to [ILA Node Turn-Up](#).

Verify shelf labeling as follows:

Step 1

Locate each shelf that is part of the node.

Step 2

Verify that each shelf is clearly marked or labeled according to local practice.

Note: *Optical and Tributary shelves are physically identical.*

Note: *The Fujitsu recommended labeling scheme is shown in Figures 22 through 24. In this scheme, each shelf is labeled with its shelf AID (for example, OS1 for the Main Optical shelf). The shelf AID is determined by shelf position within the hierarchy of LAN connections. Throughout this documentation, shelves are identified by its shelf AID.*

Step 3

Proceed to [Verify LAN Connections](#).

2.4.2

Verify LAN Connections

LAN connections are needed for all nodes that include more than one shelf.

Note: *If LAN cables are required at the node, they should already be installed as part of shelf equipment installation. Refer to [Installing LAN Cable \(Optical/Tributary Shelf\)](#).*

Step 1

Familiarize yourself with the backplane LAN connectors shown in [Figure 25](#).

Note: *The backplane contains two sets of LAN connectors. LAN connectors in the **INT SHF (MPMA-1) ports** area are used for LAN connections. LAN connectors in the **INT SHF (MPMA-2) ports** area are not used.*

Step 2

Verify that all LAN cables have been installed. Refer to [Figure 24](#) and the following table for a lists of all possible LAN cable connections.

Table 5: LAN Connections (Core Configuration)

From			To		
Shelf	Connector	Label	Shelf	Connector	Label
OS1 (Main Optical)	CN19	LAN2	OS10 (Tributary)	CN18	LAN1
	CN20	LAN3	OS11 (Tributary)	CN18	LAN1
	CN21	LAN4	OS12 (Tributary)	CN18	LAN1

Table 5: LAN Connections (Core Configuration) (Cont.)

From			To		
Shelf	Connector	Label	Shelf	Connector	Label
	CN22	LAN5	OS13 (Tributary)	CN18	LAN1
	CN23	LAN6	OS2 (Auxiliary Optical)	CN18	LAN1
	CN6	LAN7	OS3 (Auxiliary Optical)	CN18	LAN1
	CN7	LAN8	OS4 (Auxiliary Optical)	CN18	LAN1
OS10 (Tributary)	CN19	LAN2	OS100 (Tributary)	CN18	LAN1
	CN20	LAN3	OS101 (Tributary)	CN18	LAN1
OS11 (Tributary)	CN19	LAN2	OS110 (Tributary)	CN18	LAN1
	CN20	LAN3	OS111 (Tributary)	CN18	LAN1
OS12 (Tributary)	CN19	LAN2	OS120 (Tributary)	CN18	LAN1
OS13 (Tributary)	CN19	LAN2	OS130 (Tributary)	CN18	LAN1
OS2 (Auxiliary Optical)	CN19	LAN2	OS20 (Tributary)	CN18	LAN1
	CN20	LAN3	OS21 (Tributary)	CN18	LAN1
	CN21	LAN4	OS22 (Tributary)	CN18	LAN1
	CN22	LAN5	OS23 (Tributary)	CN18	LAN1
	CN23	LAN6	OS25 (Auxiliary Optical)	CN18	LAN1
	CN6	LAN7	OS26 (Auxiliary Optical)	CN18	LAN1
OS20 (Tributary)	CN19	LAN2	OS200 (Tributary)	CN18	LAN1
	CN20	LAN3	OS201 (Tributary)	CN18	LAN1
OS21 (Tributary)	CN19	LAN2	OS210 (Tributary)	CN18	LAN1
	CN20	LAN3	OS211 (Tributary)	CN18	LAN1
OS22 (Tributary)	CN19	LAN2	OS220 (Tributary)	CN18	LAN1
OS23 (Tributary)	CN19	LAN2	OS230 (Tributary)	CN18	LAN1
OS3 (Auxiliary Optical)	CN19	LAN2	OS30 (Tributary)	CN18	LAN1
	CN20	LAN3	OS31 (Tributary)	CN18	LAN1
	CN21	LAN4	OS32 (Tributary)	CN18	LAN1
	CN22	LAN5	OS33 (Tributary)	CN18	LAN1
OS30 (Tributary)	CN19	LAN2	OS300 (Tributary)	CN18	LAN1
	CN20	LAN3	OS301 (Tributary)	CN18	LAN1
OS31 (Tributary)	CN19	LAN2	OS310 (Tributary)	CN18	LAN1

Table 5: LAN Connections (Core Configuration) (Cont.)

From			To		
Shelf	Connector	Label	Shelf	Connector	Label
	CN20	LAN3	OS311 (Tributary)	CN18	LAN1
OS32 (Tributary)	CN19	LAN2	OS320 (Tributary)	CN18	LAN1
OS33 (Tributary)	CN19	LAN2	OS330 (Tributary)	CN18	LAN1
OS4 (Auxiliary Optical)	CN19	LAN2	OS40 (Tributary)	CN18	LAN1
	CN20	LAN3	OS41 (Tributary)	CN18	LAN1
	CN21	LAN4	OS42 (Tributary)	CN18	LAN1
	CN22	LAN5	OS43 (Tributary)	CN18	LAN1
OS40 (Tributary)	CN19	LAN2	OS400 (Tributary)	CN18	LAN1
	CN20	LAN3	OS401 (Tributary)	CN18	LAN1
OS41 (Tributary)	CN19	LAN2	OS410 (Tributary)	CN18	LAN1
	CN20	LAN3	OS411 (Tributary)	CN18	LAN1
OS42 (Tributary)	CN19	LAN2	OS420 (Tributary)	CN18	LAN1
OS43 (Tributary)	CN19	LAN2	OS430 (Tributary)	CN18	LAN1

Install the cables, if they are not already installed, as described in [Installing LAN Cable \(Optical/Tributary Shelf\)](#).

Step 3

Is this a symmetric HUB node?

Note: For an asymmetric HUB node, RICC cables are installed as needed, not as part of shelf equipment installation. For more information on symmetric and asymmetric HUB nodes, refer to [Core Configuration in Core Configuration](#).

IF YES:

Proceed to [Verify RICC Connections](#).

IF NO:

Proceed to [Apply Power, and Install Fan Plug-In Units](#).

2.4.3

Verify RICC Connections

This procedure applies to symmetric HUB nodes only. For more information on symmetric and asymmetric HUB nodes, refer to [Core Configuration in Core Configuration](#).

If this is a symmetric HUB node, RICC cables should already be installed as part of shelf equipment installation. Refer to [Installing RICC Cable \(Optical Shelf\)](#).

Step 1

Verify that all four RICC cables have been installed between Main Optical shelf OS1 and Auxiliary Optical shelf OS2. The connections are listed in the following table and shown in the following figure.

Install the cables, if they are not already installed, as described in [Installing RICC Cable \(Optical Shelf\)](#).

Table 6: RICC Connections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS2

From Backplane Connector			To Backplane Connector		
Shelf	Connector Group	Connector	Shelf	Connector Group	Connector
OS1	RICC (MCMA-2)	CN32 (PORT1)	OS2	RICC (MCMA-2)	CN32 (PORT1)
		CN33 (PORT2)		RICC (MCMA-1)	CN35 (PORT1)
	RICC (MCMA-1)	CN35 (PORT1)		RICC (MCMA-2)	CN33 (PORT2)
		CN36 (PORT2)		RICC (MCMA-1)	CN36 (PORT2)




Figure 26: RICC Connections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS2 Backplanes

Step 2

Does the node include Auxiliary Optical shelf OS3?

If YES:

Proceed to [Step 3](#).

If NO:

Proceed to [Apply Power, and Install Fan Plug-In Units](#).

Step 3

Verify that all four RICC cables are installed between Main Optical shelf OS1 and Auxiliary Optical shelf OS3. The connections are listed in the following table and shown in the following figure.

Install the cables, if they are not already installed, as described in [Installing RICC Cable \(Optical Shelf\)](#).

Table 7: RICC Connections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS3

From Backplane Connector			To Backplane Connector		
Shelf	Connector Group	Connector	Shelf	Connector Group	Connector
OS1	RICC (MCMA-2)	CN34 (PORT3)	OS3	RICC (MCMA-2)	CN32 (PORT1)
		CN24 (PORT4)		RICC (MCMA-1)	CN35 (PORT1)
	RICC (MCMA-1)	CN37 (PORT3)		RICC (MCMA-2)	CN33 (PORT2)
		CN28 (PORT4)		RICC (MCMA-1)	CN36 (PORT2)




Figure 27: RICC Connections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS3 Backplanes

Step 4

Verify that all four RICC cables have been installed between Auxiliary Optical shelf OS2 and Auxiliary Optical shelf OS3. The connections are listed in the following table and shown in the following figure.

Install the cables, if they are not already installed, as described in [Installing RICC Cable \(Optical Shelf\)](#).

Table 8: RICC Connections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS3

From Backplane Connector			To Backplane Connector		
Shelf	Connector Group	Connector	Shelf	Connector Group	Connector
OS2	RICC (MCMA-2)	CN34 (PORT3)	OS3	RICC (MCMA-2)	CN34 (PORT3)
		CN24 (PORT4)		RICC (MCMA-1)	CN37 (PORT3)
	RICC (MCMA-1)	CN37 (PORT3)		RICC (MCMA-2)	CN24 (PORT4)
		CN28 (PORT4)		RICC (MCMA-1)	CN28 (PORT4)




Figure 28: RICC Connections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS3 Backplanes

Step 5

Does the node include Auxiliary Optical shelf OS4?

If YES:

Proceed to [Step 6](#).

If NO:

Proceed to [Apply Power, and Install Fan Plug-In Units](#).

Step 6

Verify that all four RICC cables have been installed between Main Optical shelf OS1 and Auxiliary Optical shelf OS4. The connections are listed in the following table and shown in the following figure.

Install the cables, if they are not already installed, as described in [Installing RICC Cable \(Optical Shelf\)](#).

Table 9: RICC Connections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS4

From Backplane Connector			To Backplane Connector		
Shelf	Connector Group	Connector	Shelf	Connector Group	Connector
OS1	RICC (MCMA-2)	CN25 (PORT5)	OS4	RICC (MCMA-2)	CN32 (PORT1)
		CN26 (PORT6)		RICC (MCMA-1)	CN35 (PORT1)
	RICC (MCMA-1)	CN29 (PORT5)		RICC (MCMA-2)	CN33 (PORT2)
		CN30 (PORT6)		RICC (MCMA-1)	CN36 (PORT2)




Figure 29: RICC Connections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS4 Backplanes

Step 7

Verify that all four RICC cables have been installed between Auxiliary Optical shelf OS2 and Auxiliary Optical shelf OS4. The connections are listed in the following table and shown in the following figure.

If the cables are not installed, install as described in [Installing RICC Cable \(Optical Shelf\)](#).

Table 10: RICC Connections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS4

From Backplane Connector			To Backplane Connector		
Shelf	Connector Group	Connector	Shelf	Connector Group	Connector
OS2	RICC (MCMA-2)	CN25 (PORT5)	OS4	RICC (MCMA-2)	CN34 (PORT3)
	RICC (MCMA-1)	CN30 (PORT6)		RICC (MCMA-1)	CN28 (PORT4)
	RICC (MCMA-1)	CN29 (PORT5)		RICC (MCMA-2)	CN24 (PORT4)
	RICC (MCMA-2)	CN26 (PORT6)		RICC (MCMA-1)	CN37 (PORT3)




Figure 30: RICC Connections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS4 Backplanes

Step 8

Verify that all four RICC cables have been installed between Auxiliary Optical shelf OS3 and Auxiliary Optical shelf OS4. The connections are listed in the following table and shown in the following figure.

Install the cables, if they are not already installed, as described in [Installing RICC Cable \(Optical Shelf\)](#).

Table 11: RICC Connections between Auxiliary Optical Shelf OS3 and Auxiliary Optical Shelf OS4

From Backplane Connector			To Backplane Connector		
Shelf	Connector Group	Connector	Shelf	Connector Group	Connector
OS3	RICC (MCMA-2)	CN25 (PORT5)	OS4	RICC (MCMA-2)	CN25 (PORT5)
		CN26 (PORT6)		RICC (MCMA-1)	CN29 (PORT5)

Table 11: RICC Connections between Auxiliary Optical Shelf OS3 and Auxiliary Optical Shelf OS4 (Cont.)

From Backplane Connector			To Backplane Connector		
Shelf	Connector Group	Connector	Shelf	Connector Group	Connector
	RICC (MCMA-1)	CN29 (PORT5)		RICC (MCMA-2)	CN26 (PORT6)
		CN30 (PORT6)		RICC (MCMA-1)	CN30 (PORT6)




Figure 31: RICC Connections between Auxiliary Optical Shelf OS3 and Auxiliary Optical Shelf OS4 Backplanes

Step 9

Proceed to [Apply Power, and Install Fan Plug-In Units](#).

2.4.4

Apply Power, and Install Fan Plug-In Units

Note: The fan plug-in units are equipped with preinstalled fan filters.

Step 1

Apply power to each shelf as follows:

- a) Ensure that power is available at the rack as indicated by illumination of the green PWR indicators on the power distribution panel at the top of the rack.
- b) Set the appropriate circuit breaker at the distribution panel to the ON position to apply power to the shelf.

Step 2

Install fan plug-in units in each shelf as follows:

- a) Inspect the fan plug-in unit for possible damage or debris.
- b) Verify that a fan filter is installed in the fan plug-in unit. See the following figure for the fan filter location.




Figure 32: Fan Filter Location

- c) Slide the fan plug-in unit into one of the fan slots located at the bottom of the shelf.
- d) Ensure that the FAIL/SVCE indicator is lit green.
- e) Repeat until four fan plug-in units are installed in each shelf.

Step 3

Proceed to [Install Primary NE Management Units in Shelf OS1, and Configure Shelf OS1 as the Main Optical Shelf.](#)

2.5

Install Primary NE Management Units in Shelf OS1, and Configure Shelf OS1 as the Main Optical Shelf

In this section:

- 2.5.1 Install MPMA-SHPx Plug-In Unit
- 2.5.2 Verify Software Version
- 2.5.3 Change System Type
- 2.5.4 Change HUBMODE to MANUAL
- 2.5.5 Provision Shelf Location Identifiers
- 2.5.6 Provision OSC Units

Prerequisites:

If not already done, complete the procedures in [Verify Shelf Labeling](#), [Verify LAN and RICC Cable Connections](#), [Apply Power](#), and [Install Fan Units](#).

If you are using the NETSMART 500 Element Manager for provisioning, be sure the computer meets or exceeds the following system requirements (refer to *FNC-0500-0311-010, NETSMART 500 User Guide*):

- Microsoft® Windows® operating system:
 - Windows 2000 (Service Pack 4)
 - Windows XP Professional (Service Packs 1 and 2)
- 450 MHz Pentium® processor (1.2 GHz or faster recommended)
- 128 MB RAM (512 MB RAM recommended), approximately 30 MB of memory (random access or virtual) per NETSMART 500 session
- 400 MB disk space (minimum)
- CD drive
- LAN card and/or serial craft interface port and connection cable
- 8-bit color (256 colors) minimum (16-bit color recommended)

- 800×600 resolution (optimized for 1024×768 or larger resolution)
- Web browser:
 - Internet Explorer version 5.5 or later
 - Netscape® version 4.7 (complete installation) or later
 - Mozilla® Firefox® version 1.0 or later

Initially, due to factory default settings, shelf OS1 does not behave as the Main Optical shelf. Shelf OS1 becomes the Main Optical shelf after the system keyword TYPE has been changed from the default value (FW7500TRIB) to FW7500U_OADM (refer to [Step 7](#)).

The steps in [Verify Software Version](#) ensure the NEM Shelf Processor unit (MPMA-SHPx), installed in slot MPMA-1, is running the correct software version. When additional NEM Shelf Processors or OSC plug-in units are installed, the system will automatically update the software on these units, if necessary, to match the software running on this first NEM, installed the unit in slot MPMA-1.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Note: For plug-in unit slot locations, refer to [Slot Labels and AIDs](#).

Note: Default values are shown in bold.

This procedure shows how to install the primary NE management units, and configure shelf OS1 as the Main Optical shelf.

2.5.1

Install MPMA-SHPx Plug-In Unit

Step 1

Install the MPMA-SHPx plug-in unit in shelf OS1 as follows:

- a) Inspect the unit for possible damage or debris.
- b) Install the unit into slot MPMA-1 of shelf OS1.

The NOT READY and FAIL/SVCE indicators should immediately light amber.

Note: If the NOT READY and FAIL/SVCE indicators do not light amber, verify that wiring to the PWR terminal located in the back of the shelf is correct. Remove the plug-in unit and then repeat [Step 1](#).

After 5 to 20 minutes, the amber NOT READY and FAIL/SVCE indicators should go out, and the FAIL/SVCE indicator should light green.

Step 2

After waiting up to 20 minutes, did the FAIL/SVCE indicator on the MPMA-SHPx plug-in unit light green?

If YES:

Proceed to [Step 3](#).

If NO:

The NEM Shelf Processor unit may be defective. Remove the unit and set it aside for repair paperwork processing. Obtain another NEM Shelf Processor plug-in unit. Return to [Step 1](#) and repeat this procedure on that NEM Shelf Processor unit.

Step 3

Establish a craft interface connection through connector TERM1 or TERM2 on the front of the Main Optical shelf (OS1). Refer to the following table for a listing of set-up procedures.

Table 12: Craft Interface Set-Up Procedures

Type of User Interface	Craft Interface Connector	Set-Up Procedure
TL1 user interface	TERM1 (Serial)	Setting Up Craft Interface (TL1 Session through TERM1)
	TERM 2 (LAN, TCP/IP)	Setting Up Craft Interface (TL1 Session through TERM2)
NETSMART 500 user interface	TERM1 (Serial)	Setting Up Craft Interface (NETSMART 500 Session through TERM1)
	TERM 2 (LAN, TCP/IP)	Setting Up Craft Interface (NETSMART 500 Session through TERM2)

Note: A TERM1 (serial) connection allows continuous connectivity between the craft interface and the NE. With a TERM2 (TCP/IP) connection, the communication link between the craft interface and the NE is severed when the INIT-SYS and INIT-OIF commands are processed. The severing of the communication link requires you to reestablish your logon session with the NE.

Step 4

Log on the NE.

Note: At this stage, you can only log on the NE using the factory default values for the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface connection, which should have been completed in the previous step.

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p>														
<pre>ACT-USER:TID:UID:CTAG::PID; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value) Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</pre>	<p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT</td> <td>Password: ROOT</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default⁷</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT	Password: ROOT	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT	Password: ROOT														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

2.5.2

Verify Software Version

Step 5

Retrieve the software version information.

⁷ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
RTRV-VERSION:TID::CTAG; Example: RTRV-VERSION:FUJITSU::CTAG;	The Shelf Provisioning Mode dialog box opens. ⁸ Click OK. In the Current Values area of the Operations ⁹ dialog box, determine the value of the Active GISSUE. Do not close the Operations dialog box.

Step 6

Is the active GISSUE correct?

The correct GISSUE value for FLASHWAVE 7500 Release 9.1 software is 09-01-1.

IF YES:

Proceed to [Step 7](#).

IF NO:

Upgrade the system software as described in [Upgrading System Software Using TL1 Commands](#) or [Upgrading System Software Using NETSMART 500 Software Download Wizard](#), then repeat this subprocedure.

2.5.3

Change System Type

Step 7

Change system type from FW7500TRIB to FW7500U_OADM.

Note: This command terminates the communication session and restarts the NE.

TL1	NETSMART 500
ED-SYS:TID::CTAG::: TYPE=FW7500U_OADM; Example: ED-SYS:FUJITSU::CTAG::: TYPE=FW7500U_OADM;	In the Operations dialog box: <ul style="list-style-type: none"> Select the NE Type tab From the Type drop-down list, select FW7500U_OADM. Click Modify. The Confirmation dialog box opens. Click OK.

The NOT READY indicator on the NEM Shelf Processor plug-in unit lights amber and then goes out after 5 to 20 minutes. After the NOT READY indicator goes out, the FAIL/SVCE indicator lights green on the NEM Shelf Processor unit.

⁸ The Shelf Provisioning Mode dialog only appears when logging on to a factory default shelf.

⁹ Upon logging on a factory default shelf, the Operations dialog is automatically opened with the NE Type tab selected. However, if the Operations dialog box does not open automatically, select System Operations from the NE menu and, after the Operations dialog box appears, click the Attributes tab, then the NE Type tab.

Step 8



After the NOT READY indicator goes out and the FAIL/SVCE indicator lights green and stays green, proceed to [Step 9](#).

Step 9

Log on the NE.

Note: At this stage, you can only log on the NE using factory default values of the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Craft Interface Operations](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p></p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p></p>														
<pre>ACT-USER:TID:UID:CTAG::PID; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value) Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</pre>	<p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT</td> <td>Password: ROOT</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default¹⁰</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT	Password: ROOT	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT	Password: ROOT														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														
	<p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>														

¹⁰ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

Step 10

Reinitialize the system software.

Note: This command automatically logs the user off the NE.

TL1	NETSMART 500
<pre>INIT-SYS:TID:AID:CTAG:::LEVEL=WARM; AID: • ALL (null) Example: INIT-SYS:FUJITSU::CTAG:::LEVEL=WARM;</pre>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the Initialize tab. Click the NE tab. Select Level: WARM. Click Initialize.</p> <p>Click Yes in the pop-up window to continue.</p> <p>If a second pop-up window opens, the connection is lost, and you must log on the NETSMART 500 user interface again to continue by clicking Logon.</p>

The NOT READY indicator on the NEM Shelf Processor plug-in unit lights amber and then goes out after 5 to 20 minutes. After the NOT READY indicator goes out, the FAIL/SVCE indicator lights green on the NEM Shelf Processor unit.

Step 11

After the NOT READY indicator goes out and the FAIL/SVCE indicator lights green and stays green, proceed to [Step 12](#).

Step 12

Log on the NE.

Note: At this stage, you can only log on the NE using factory default values of the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Craft Interface Operations](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p>														
<pre>ACT-USER:TID:UID:CTAG::PID; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value) Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</pre>	<p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT</td> <td>Password: ROOT</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default¹¹</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT	Password: ROOT	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT	Password: ROOT														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

Step 13

Is this node to be provisioned as an asymmetric HUB node?

Note: For an asymmetric HUB node, keyword HUBMODE must be changed from AUTO (default) to MANUAL. For more information on symmetric and asymmetric HUB nodes, refer to [Core Configuration](#) in [Core Configuration](#).

If YES:

Proceed to [Step 14](#).

If NO:

Proceed to [Step 16](#).

¹¹ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

2.5.4

Change HUBMODE to MANUAL

Step 14

Change keyword HUBMODE from AUTO to MANUAL.

TL1	NETSMART 500
<pre>ED-SYS:TID::CTAG:::HUBMODE=MANUAL;</pre> <p>Example: <pre>ED-SYS:FUJITSU::CTAG::: HUBMODE=MANUAL;</pre></p>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab. Set HUBMODE to MANUAL. Click Modify.</p> <p>The Confirmation dialog box opens. Click OK.</p> <p>Do not close the Operations dialog box.</p>

Step 15

Verify that keyword HUBMODE is set to MANUAL.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the Current Values area of the Operations dialog box, verify that the value of HUBMODE is MANUAL.</p> <p>Close the Operations dialog box.</p>

Step 16

Following local practice, do you want to provision shelf location identifiers?

Note: Shelf location identifiers, *SHELFLBL* and *USERLBL*, are optional parameters that precisely identify the location of equipment. If provisioned, the values appear in equipment retrieval and alarm messages. The *SHELFLBL* value indicates the physical location of the bay and shelf. The *USERLBL* value indicates the frame identification code (FIC). Telcordia® NMA® OSMINE™ users should keep the *SHELFLBL* and *USERLBL* parameters values as NULL (default). For more information, refer to [Shelf Location Identifiers](#).

If YES:

Proceed to [Step 17](#).

If NO:

Proceed to [Step 19](#).

2.5.5 Provision Shelf Location Identifiers

Step 17

Edit the values of shelf location identifiers (SHELFLBL and/or USERLBL).

TL1	NETSMART 500
<pre>ED-EQPT:TID:AID:CTAG::: KEYWORD=DOMAIN; AID: • OS1 KEYWORD=DOMAIN: • SHELFLBL = Up to 13 characters with each character an uppercase letter (A...Z) or number (0...9) (null is default) • USERLBL = Up to 20 characters with each character an uppercase letter (A...Z), number (0...9), or hyphen (-) (null is default) Example: ED-EQPT:FUJITSU:OS1:CTAG::: SHELFLBL=MAINSHELF,USERLBL=PLANO;</pre>	<p>In the tree view, click the Equipment tab.</p> <p>Expand the appropriate shelf components.</p> <p>Select the equipment component.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>In the Command Parameters area type values into the SHELFLBL and/or USERLBL fields, if required.</p> <p>Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 18

Verify the values of the shelf location identifiers.

TL1	NETSMART 500
<pre>RTRV-EQPT:TID:AID:CTAG; AID: • As identified in previous step • ALL (null) Example: RTRV-EQPT:FUJITSU:OS1:CTAG;</pre>	<p>In the Current Values area of the Operations dialog box, verify equipment provisioning.</p> <p>Close the Operations dialog box.</p>

2.5.6 Provision OSC Units

Step 19

Depending on your work order, install one or two OSC (SCMA-SCC4) plug-in units in the appropriate slots (9 and 11) of shelf OS1. For each OSC plug-in unit to be installed, do the following:

The NOT READY indicators light amber and then go out after 5 to 20 minutes. Independently, the FAIL/SVCE indicators light green.

Note: The NOT READY indicator remains amber until the backup database is completely copied to the OSC unit. During this time, CPY-MEM and CPY-FILE functions are unavailable and the OSC unit should not be removed.

- a) Inspect the OSC plug-in unit for possible damage or debris.
- b) Slide the OSC plug-in unit into the Optical shelf slot.

Note: Because autoprovisioning is on (by default), the OSC units will begin provisioning when they are inserted into the shelf.

Step 20

Wait until both of the following conditions are met, then proceed to [Step 21](#).

- NOT READY indicators on the OSC plug-in units go out.
- FAIL/SVCE indicators on the OSC plug-in units light green.

Step 21

Ensure that OSC plug-in units are properly provisioned and that the equipment state is IS, Normal (STATE=IS-NR).

TL1	NETSMART 500
<pre>RTRV-EQPT:TID:AID:CTAG; AID: • OS1-9 (slot 9) • OS1-11 (slot 11) Example: RTRV-EQPT:FUJITSU:OS1-9&OS1-11:CTAG;</pre>	<p>In the Optical shelf OS1 graphic view or tree view area, select the equipment slot.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the PRIMARY_STATE is IS.</p> <p>Verify the PRIMARY_STATE_QUALIFIER is NR.</p> <p>Close the Properties dialog box.</p>

Step 22

Retrieve and verify software version information.

TL1

```
RTRV-VERSION:TID:AID:CTAG;
AID:
• ACT, STBY, ALL

Example:
RTRV-VERSION:FUJITSU::CTAG;
```

Step 23

Is the system running Release 8.1 or Release 8.1.2 system software?

Note: Release 8.1 introduces the Expansion Pack that addresses plug-in unit firmware storage limitations. The Expansion Pack should be loaded to the processor prior to installing the remaining plug-in units (optical line cards). The Expansion Pack should be downloaded on all Release 8.1 and later systems.

IF YES:

Go to [Download Firmware Expansion Pack Files Using TL1 Commands](#) or [Download Firmware Expansion Pack Files Using NETSMART 500 Expansion Pack Firmware Download Wizard](#) document to download the Expansion Pack firmware files. Then proceed to [Step 25](#).

IF NO:

Proceed to the next step.

Step 24

Does the system need to be upgraded to Release 9.1 system software?

Note: FLASHWAVE 7500 NEs loaded with Release 4.x software must be upgraded to Release 5.1 before being upgraded to Release 5.2, 5.2.2, or 6.x. After upgrading to Release 5.2 or 5.2.2, the FLASHWAVE 7500 NE can be upgraded to Release 6.x or 7.x. After upgrading to Release 6.x, the FLASHWAVE 7500 NE can be upgraded to 7.x, 8.x, or 9.x.

IF YES:


Upgrade the system software as described in [Upgrading System Software Using TL1 Commands](#) or [Upgrading System Software Using NETSMART 500 Software Download Wizard](#), then proceed to the next step.

IF NO:

Proceed to the next step.

Step 25

Go to [Provision System-Level Parameters, LCN Port, and GOS](#).

 This procedure is complete.

2.6

Provision System-Level Parameters, LCN Port, and GOS

In this section:

- 2.6.1 Provision System-Level Parameters
- 2.6.2 Provision LCN Port
- 2.6.3 Provision GOS

2.6.1

Provision System-Level Parameters

This subprocedure includes steps to set the NE target identifier (TID), change the date and time, and enter new users.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1



If not already done, complete the procedures in [Install Primary NE Management Units in Shelf OS1](#), and [Configure Shelf OS1 as the Main Optical Shelf](#).

Step 2

If not already done, log on the NE.

Note: At this stage, you can only log on the NE using factory default values of the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Craft Interface Operations](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X. For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p> <pre>ACT-USER:TID:UID:CTAG::PID; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value)</pre> <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p></p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p></p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT</td> <td>Password: ROOT</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default¹²</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT	Password: ROOT	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT	Password: ROOT														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

Step 3

Inhibit the autonomous messages.

Note: This step does not apply if you are using the NETSMART 500 user interface.



Caution: Ensure that the autonomous messages are allowed after these procedures have been completed. Failure to allow the autonomous messages could cause loss of traffic or the ability to detect remote troubles.

¹² The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<code>INH-MSG-ALL:TID::CTAG;</code> Example: <code>INH-MSG-ALL:FUJITSU::CTAG;</code>	n/a

Note: Autonomous messages are inhibited until [Step 3](#) of [Provision GOS](#), when the command is entered to allow autonomous messages.

Step 4

Change the system identifier (SID) from the default value, *FUJITSU*, to a unique identifier. This identifier acts as the shelf address in the network. The new SID must be from 7 to 20 alphanumeric characters. Hyphens are allowed.

Note: Allow approximately 20 seconds after completion of the command before verifying the new SID.

TL1	NETSMART 500
<code>SET-SID:TID::CTAG::SID;</code> TID: <ul style="list-style-type: none"> Existing system ID SID: <ul style="list-style-type: none"> New system ID Example: <code>SET-SID:FUJITSU::CTAG::FUJITSU1;</code>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">NE ▶ System Operations</div> The Operations dialog box opens. Click the Attributes tab. Click the System ID tab. In the Command Parameters area, enter the new system identifier (SID). Click Modify. Click Yes in the pop-up window to continue. A second pop-up window will indicate that the connection has been lost. You will have to log on the NETSMART 500 user interface again to continue. Note: If using <i>TERM1</i> (serial connection), the second pop-up window will not appear, you will not be logged off, and you will not need to log on again. In the tree view, verify the new SID. Proceed to Step 6 . Click Logon.

Step 5

Verify the new SID.

Note: NETSMART 500 users should wait approximately 20 seconds before attempting to log on the NE using the new SID.

TL1	NETSMART 500		
<p>RTRV-HDR:TID::CTAG; TID:</p> <p>New system ID</p> <p>Note: The TID is the same as the SID set in the previous step.</p> <p>Example: RTRV-HDR:FUJITSU1::CTAG;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows task bar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> For TERM1 (Serial): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: Serial Comm. Port: COMx (for example, COM2) </td> <td style="width: 50%; vertical-align: top;"> For TERM2 (TCP/IP): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024 </td> </tr> </table> <p>Configure: use default¹³</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 graphical user interface.</p> <p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the System ID tab. Verify the value of SID.</p> <p>Close the Operations dialog box.</p>	For TERM1 (Serial): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: Serial Comm. Port: COMx (for example, COM2)	For TERM2 (TCP/IP): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: Serial Comm. Port: COMx (for example, COM2)	For TERM2 (TCP/IP): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 6

Set the system date, time, and time zone.

Note: If TZONE is set to a value with DT (that is, xxxxDT), the time is adjusted automatically for Daylight Saving Time, and a REPT EVT COM message is generated when the adjustment occurs.

¹³ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

Note: Enter the date in the format YYYYMMDD (year/month/day) and the time in the 24-hour format HHMMSS (hour/minute/second).

TL1	NETSMART 500
<pre>SET-DAT:TID::CTAG::DATE,TIME: KEYWORD=DOMAIN; DATE: • YYYYMMDD TIME: • HHMMSS KEYWORD=DOMAIN: • Refer to the following table. Example: SET-DAT:FUJITSU::CTAG:: 990727,050958:TZONE=CST6CDT;</pre>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Time tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • Enter the date (YYYYMMDD). • Enter the time (HHMMSS). • Select a time zone (Refer to the following table). <p>Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Table 13: SET-DAT Keyword and Domain Input Parameters

Keyword	Domain ¹⁴ (Default in Bold)	Description	
TZONE	NODST	Disables the daylight savings time feature	
	NSTNDT	Newfoundland time zone	
	AST4	AST4ADT	Atlantic time zone
	EST5	EST5EDT	Eastern time zone
	CST6	CST6CDT	Central time zone
	MST7	MST7MDT	Mountain time zone
	PST8	PST8PDT	Pacific time zone
	AKST9	AKST9AKDT	Alaska time zone
	HST10		Hawaii time zone
	GMT		Greenwich mean time

Step 7

Verify the system date, time, and time zone.

¹⁴ Values to the right enable automatic daylight savings time adjustment

TL1	NETSMART 500
RTRV-DAT:TID::CTAG; Example: RTRV-DAT:FUJITSU::CTAG;	In the Current Values area of the Operations dialog box, verify that the updated information is correct. Close the Operations dialog box.

Step 8

Do you want to change from the default basic security mode to the enhanced security mode?

Note: For more information about the basic and enhanced security modes, refer to [Security](#).

Note: Changing the security level is allowed only by Level 4 users.

IF YES:
 Continue with [Step 9](#).

IF NO:
 Proceed to [Step 14](#).

Step 9

Change the basic security mode to the enhanced security mode.

TL1	NETSMART 500
ED-DFLT-SECU:TID::CTAG::: SECULVL=ENHANCED; Example: ED-DFLT-SECU:FUJITSU::CTAG::: SECULVL=ENHANCED;	<div style="background-color: #cccccc; padding: 2px; display: inline-block;">NE ▶ System Operations</div> The Operations dialog box opens. Click the Security tab. Click the Settings tab. Select Enhanced from the SECULVL drop-down list. Click Modify. Do not close the Operations dialog box.

Step 10

Verify that the security mode has changed to the enhanced security mode.

TL1	NETSMART 500
RTRV-DFLT-SECU:TID::CTAG; Example: RTRV-DFLT-SECU:FUJITSU::CTAG;	In the Current Values area of the Operations dialog box, verify that the updated information is correct.

Step 11

Do you want to change the default Fujitsu security warning message banner to a customized warning message banner?

If YES:

Continue with the next step.

If NO:

Proceed to [Step 14](#).

Step 12

Enter the customized warning message banner information.

TL1	NETSMART 500
<pre>ED-DFLT-SECU:TID::CTAG:::WARN=;</pre> <p>Example: <pre>ED-DFLT-SECU:FUJITSU::CTAG::: WARN=\"THIS COMPUTER IS FOR SECURITY PERSONAL ONLY, AUTHORIZED USE REQUIRED\";</pre></p>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">NE ▶ Security Administration</div> <p>The Security Administration dialog box opens. Click the Settings tab.</p> <p>Click the WARN box and then enter required banner warning message in text box. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 13

Verify the warning message banner has changed.

TL1	NETSMART 500
<pre>RTRV-DFLT-SECU:TID::CTAG;</pre> <p>Example: <pre>RTRV-DFLT-SECU:FUJITSU::CTAG;</pre></p>	<p>In the Current Values area of the Operations dialog box, verify that the updated information is correct.</p> <p>Close the Operations dialog box.</p>

Step 14

If required, enter additional security information (new users and privilege levels, updated security levels).

Note: The maximum number of UIDs in the system is 100. This command will be denied if the number of UIDs exceeds 100.

TL1	NETSMART 500
<p>ENT-SECU-USER:TID:UID:CTAG::PID,, UPC:KEYWORD=DOMAIN; UID:</p> <ul style="list-style-type: none"> User identifier for new user (4 to 10 alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> Private identifier: <ul style="list-style-type: none"> BASIC mode—6 to 10 characters, including at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. ENHANCED mode—10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID. <p>UPC:</p> <ul style="list-style-type: none"> User privilege code (1, 2, 3, or 4, with Level 4 allowing greatest access to commands) <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> TMOUTA = Y, N (Y enables automatic logoff after the specified number of minutes of user inactivity. N disables automatic logoff.) TIMEOUT = 5...10...30...60 (time-out period in minutes when TMOUTA=Y; defaults are 30 minutes for BASIC mode and 10 minutes for ENHANCED mode.) UAGE = 1...90, 99 (The UID aging interval expressed in days. UAGE=99 disables UAGE.) PAGE = 25...90, 99 (The PID aging interval expressed in days. PAGE=99 disables PAGE.) <p>Example: ENT-SECU-USER:FUJITSU:ROOT: CTAG::NEWPID9,,2:TMOUTA=N;</p>	<p style="background-color: #333; color: white; padding: 2px;">NE ▶ Security Administration ▶ User tab ▶ Create</p> <p>Enter the new user ID in the UID field.</p> <p>Enter the password in the PID field.</p> <p>Select the user privilege code (1...4) in the UPC field.</p> <p>In the TMOUTA field, select True to enable automatic time-out or False to disable automatic time-out.</p> <p>If automatic time-out is enabled, enter the time-out period (5...60 minutes) in the TIMEOUT field.</p> <p>Select the UID aging interval (1...90, 99) from the UAGE pull-down menu.</p> <p>Select the PID aging interval (25...90, 99) from the PAGE pull-down menu.</p> <p>Click Create.</p>

Step 15

If security information was added or changed in the previous step, verify the new users and privilege levels.

TL1	NETSMART 500
<p>RTRV-SECU-USER:TID:UID:CTAG; UID:</p> <ul style="list-style-type: none"> User identifier; 4 to 10 non-case sensitive alphanumeric characters <p>Example: RTRV-SECU-USER:FUJITSU:BILL:CTAG;</p>	<p>In the tree view, click the Users tab.</p> <p>If necessary, expand the tree view to show the new users added. Select the new user.</p> <p>Entity ▸ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the properties for the given user.</p> <p>Close the Properties dialog box.</p>

Step 16

Set the system contact and location information, if required.

TL1	NETSMART 500
<p>ED-SYS:TID::CTAG:::KEYWORD=DOMAIN; KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> CONTACT = \"up to 40 characters\" LOCATION = \"up to 40 characters\" <p>Example: ED-SYS:FUJITSU::CTAG::: CONTACT= \"BILLJONES\" , LOCATION= \"HINSDALE\" ;</p>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab.</p> <p>In the Command Parameters area, enter required information in CONTACT and LOCATION fields. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 17

Verify the system contact and location information.

TL1	NETSMART 500
<p>RTRV-SYS:TID::CTAG;</p> <p>Example: RTRV-SYS:FUJITSU::CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the updated information is correct.</p> <p>Close the Operations dialog box.</p>

Step 18

Do you wish to provision the LCN port to allow remote provisioning over the data network?

If YES:

Proceed to [Provision LCN Port](#).

If NO:

Proceed to [Provision GOS](#).

2.6.2

Provision LCN Port

Provisioning the local communications network (LCN) port involves setting the IP address of the operations support system (OSS) port, placing the LCN port in service (using the ED-LAN command), and finally issuing the INIT-OIF command to enable pending provisioning changes by the system.

The following LCN provisioning restrictions apply:

- The MASK cannot take the following values: 0.0.0.0 or 255.255.255.255.
- The following IP addresses cannot be assigned as the NE IP address:
 - 0.0.0.0 (use of this IP address is allowed but will delete the IP interface)
 - 255.255.255.255
 - 127.xxx.xxx.xxx
 - 224.xxx.xxx.xxx through 239.xxx.xxx.xxx (Class D—not for normal use)
- The NE IP address cannot be the same as the one provisioned by the ENT-CIDR-ROUTE command.
- When the LCN port is used as part of the default gateway (via the ENT-CIDR-ROUTE command), its IP address cannot be changed.

Step 1

If not already done, complete the system parameter provisioning procedures in [Provision System-Level Parameters](#).

Step 2

Set the IP address and mask of the LCN port.

Note: See your System Administrator for valid IP addresses that can be used on your network.

TL1	NETSMART 500
<pre>ED-IP-ADDR:TID:LCN:CTAG::: KEYWORD=DOMAIN; KEYWORD=DOMAIN:</pre> <ul style="list-style-type: none"> MASK = xxx.xxx.xxx.xxx (xxx = 0...255), 255.255.255.0 IP = xxx.xxx.xxx.xxx (xxx = 0...255), 0.0.0.0 PORT = 1024...2024...65535 <p>Example: ED-IP-ADDR:FUJITSU:LCN:CTAG::: MASK=255.255.255.128, IP=123.255.255.121,PORT=2024;</p>	<p>In the tree view, click the Communications tab. Select <i>LCN (IP)</i>.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Enter the IP address (IP) for the NE. Enter the IP subnet mask (MASK). Enter the Transmission Control Protocol (TCP) port number (PORT). <p>Click Modify.</p> <p>A confirmation dialog box opens.</p> <p>Click Yes to close the confirmation dialog box and continue.</p> <p>Close the Operations dialog box.</p>

Step 3

Place LCN port in service (IS state).

TL1	NETSMART 500
<pre>ED-LAN:TID:LCN:CTAG::: KEYWORD=DOMAIN:IS; KEYWORD=DOMAIN:</pre> <ul style="list-style-type: none"> TARP = Y, N SIZE = 86...1518 LSAP = FE OSI = Y, N IPFWD = Y, N NETID = User-defined network identifier. Character string of up to 20 alphanumeric delineated by escape quotes (""). <p>Example: ED-LAN:FUJITSU:LCN:CTAG:::SIZE=150:IS;</p>	<p>In the tree view, click the Communications tab.</p> <p>Expand the parent LCN component by clicking the plus sign (+) to the left of <i>LCN (IP)</i>.</p> <p>Select the LCN (LAN) component.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select IS from the STATE drop-down list. Make additional parameter modifications as required. <p>Click Modify.</p> <p>A confirmation dialog box opens.</p> <p>Click Yes to close the confirmation dialog box and continue.</p> <p>Close the Operations dialog box.</p>

Step 4

Enter default gateway if required.

Note: There are preconditions associated with the ENT-CIDR-ROUTE command. Refer to [Enter CIDR Route \(ENT-CIDR-ROUTE\)](#), for a list of preconditions, restrictions and keywords associated with the ENT-CIDR-ROUTE command.

TL1	NETSMART 500
<pre>ENT-CIDR-ROUTE:TID::CTAG::LCN: KEYWORD=DOMAIN; KEYWORD=DOMAIN: • DESTIP = 0.0.0.0 • DESTMASK = 0.0.0.0 • NEXTHOP = xxx.xxx.xxx.xxx (xxx = 0...255) • METRIC = 0...100...65535</pre> <p>Example: ENT-CIDR-ROUTE:FUJITSU::CTAG:: LCN:DESTIP=0.0.0.0, DESTMASK=0.0.0.0, NEXTHOP=128.167.154.170;</p> <p>Note: The NEXTHOP IP address is the same as the gateway IP address.</p>	<p>NE > Create</p> <p>Select the IP Routes tab. Select the Enter tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none">• Enter the destination IP address (DESTIP).• Enter the destination IP address mask (DESTMASK).• Enter the IP address of the next system on the route (NEXTHOP).• Enter the cost metric of the route (METRIC).• Select LCN from the PORT drop-down list. <p>Click Enter.</p> <p>A confirmation dialog box opens.</p> <p>Click Yes to close the confirmation dialog box and continue.</p>

Step 5

How are you connected to the NE?

TERM1 (serial)— Go to [Step 6](#).

TERM2 (TCP/IP)— Go to [Step 8](#).

Step 6

Initialize the operation interface (OIF) through a TERM1 (serial) connection.

Note: The *INIT-OIF* command must be executed before the *ED-IP-ADDR*, *ED-LAN*, and *ENT-CIDR-ROUTE* commands become effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG;</pre> <p>Example: INIT-OIF:FUJITSU::CTAG;</p>	<p>NE ▸ <i>System Operations</i></p> <p>The Operations dialog box opens. Click Initialize tab. Select the Stack tab.</p> <p>In the Command Parameters area:</p> <p>Select OIF from the STACK INIT TYPE drop-down list. Click Initialize.</p> <p>A confirmation dialog box opens.</p> <p>Note: The confirmation message refers to an Initialize Stack operation. The Initialize Stack operation is the initialization of the OSI stack that results from the processing of the INIT-OIF command. Click Yes.</p>

Step 7

Wait 2 minutes, then go to [Step 11](#).

Step 8

Initialize the operation interface (OIF) through a TERM2 connection.

Note: The INIT-OIF command must be executed before the ED-IP-ADDR, ED-LAN, and ENT-CIDR-ROUTE commands become effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG;</pre> <p>Example: INIT-OIF:FUJITSU::CTAG;</p>	<p>NE ▸ <i>System Operations</i></p> <p>Click Initialize tab.</p> <p>In the Command Parameters area:</p> <p>Select OIF from the STACK INIT TYPE drop-down list. Click Initialize.</p> <p>A confirmation dialog box opens.</p> <p>Note: The confirmation message refers to an Initialize Stack operation. The Initialize Stack operation is the initialization of the OSI stack that results from the processing of the INIT-OIF command. Click Yes.</p> <p>A connection warning dialog box opens, indicating that the connection has been lost. You will have to log on the NETSMART 500 user interface again when it is time to continue.</p> <p>Click Logon in the pop-up window to continue.</p>

Note: The NETSMART 500 connection to the NE will be lost. After waiting 2 minutes, NETSMART 500 users should log back on the NE.

Step 9

Wait 2 minutes before continuing.



Step 10

Log on the NE.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p></p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p></p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default¹⁵</p> <p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>	<p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 graphical user interface.</p>

Step 11

Verify the IP address and mask of the LCN port.

TL1	NETSMART 500	
<p>RTRV-IP-ADDR:TID:LCN:CTAG; Example: RTRV-IP-ADDR:FUJITSU:LCN:CTAG;</p>	<p>In the tree view, click the Communications tab. Select the LCN (IP) component.</p> <div style="border: 1px solid #ccc; padding: 2px; margin: 5px 0;">Entity ▾ Properties View</div> <p>The Properties dialog box opens.</p> <p>Verify the IP address (IP), mask (MASK), and port (PORT) of the LCN port.</p> <p>Close the Properties dialog box.</p>	

Step 12

Verify that the LAN is in service.

¹⁵ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<p>RTRV-LAN:TID:LCN:CTAG;</p> <p>Example: RTRV-LAN:FUJITSU:LCN:CTAG;</p>	<p>In the tree view, click the Communications tab.</p> <p>Expand the parent LCN component by clicking the plus sign (+) to the left of <i>LCN (IP)</i>.</p> <p>Select the <i>LCN (LAN)</i> component.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that the LCN port is in service (STATE: IS).</p> <p>Close the Properties dialog box.</p>

Step 13
 Verify the default gateway.

TL1	NETSMART 500
<p>RTRV-CIDR-ROUTE:TID::CTAG::PORT: KEYWORD=DOMAIN; PORT:</p> <ul style="list-style-type: none"> LCN (local communication network port) ALL (default) <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> NEXTHOP = xxx.xxx.xxx.xxx (xxx = 0...255) ALL <p>Example: RTRV-CIDR-ROUTE:FUJITSU::CTAG;</p>	<p>In the tree view, click the Communications tab.</p> <p>Select the <TID> (SYSTEM) component.</p> <p>Entity ▶ Properties View</p> <p>Select the IP Routes tab.</p> <p>Verify current values.</p> <p>Close the Properties dialog box.</p>

Step 14
 Proceed to [Provision GOS](#).

2.6.3
Provision GOS

The grade of service (GOS) table stores system-level default values for newly created entities, including equipment, facility, and ports entities. It can be used to modify default provisioning in the following areas:

- Default PM threshold levels (PMs)
- Default threshold crossing alerts (TCAs)

- Default alarm severity for standing conditions (ALMs)
- Default values for certain entity attributes (keyword parameter values) of managed objects (MOs)



Attention: GOS provisioning does not change the provisioning of existing entities (equipment, facilities, or ports). Changes are only applicable to new entities, created after the GOS table is changed. To promote uniformity, Fujitsu recommends that GOS provisioning be performed at turn-up.

Step 1

If not already done, complete the system parameter provisioning procedures provided in [Provision System-Level Parameters](#).

Step 2

Do you wish to provision GOS?

Note: If GOS provisioning is part of your local practice, Fujitsu recommends that GOS provisioning be performed at this time.

If YES:

Perform GOS provisioning as described in [Provisioning GOS](#), then proceed to [Step 3](#).

If NO:

Proceed to [Step 3](#).

Step 3

Allow autonomous messages, which were inhibited in [Step 3](#) of [Provision System-Level Parameters](#).

Note: This step does not apply if you are using the NETSMART 500 user interface.

TL1	NETSMART 500
<pre>ALW-MSG-ALL:TID::CTAG;</pre> <p>Example: <pre>ALW-MSG-ALL:FUJITSU::CTAG;</pre></p>	<p>The NETSMART 500 graphical user interface does not support this TL1 command.</p> <p></p> <p>The Command Builder dialog opens.</p> <p>Select the ALW-MSG-ALL command in the Command Name field.</p> <p>Click Send.</p> <p>Close the TL1 Command Builder dialog box.</p>

Step 4

Does the node include subtending shelves (Auxiliary Optical shelves and/or Tributary shelves)?

IF YES:

Proceed to [Create Subtending Shelves and Install Shelf Processors](#) .

IF NO:

Proceed to [Provision Optical Shelf Equipment and Facilities](#).

2.7

Create Subtending Shelves and Install Shelf Processors

In this section:

- 2.7.1 Install Shelf Processors
- 2.7.2 Create Auxiliary Optical Shelf Equipment Entities
- 2.7.3 Create Tributary Shelf Entities

2.7.1

Install Shelf Processors

The purpose of this subprocedure is to install NE Management (NEM) Shelf Processor (MPMA-SHPx) plug-in units in the Auxiliary Optical shelves OS_n (n = 2...4, 25, 26) and Tributary shelves OS_n (n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430), as required. For plug-in unit slot locations, refer to [Slot Labels and AIDs](#), and [Slot Labels and AIDs](#).

Step 1

If not already done, complete the procedures provided in [Provision System-Level Parameters, LCN Port, and GOS](#).

Step 2

Install an MPMA-SHPx plug-in unit in each subtending shelf as follows:

- a) Inspect the unit for possible damage or debris.
- b) Install the unit into the MPMA-1 slot of the shelf.

The NOT READY and FAIL/SVCE indicators should immediately light amber.

Note: If the NOT READY and FAIL/SVCE indicators do not light amber, verify that wiring to the PWR terminal in the rear of the shelf is correct, remove the plug-in unit, and then repeat [Step 2](#).

After approximately 5 minutes, the amber NOT READY and FAIL/SVCE indicators should go out.

Note: After the indicators go out, they remain unlit until the shelf entity is created ([Create Auxiliary Optical Shelf Equipment Entities](#) or [Create Tributary Shelf Entities](#)). After the shelf entity is created, the FAIL/SVCE indicator will light green.

Step 3

Does the node include one or more Auxiliary Optical shelves?

If YES:

Proceed to [Create Auxiliary Optical Shelf Equipment Entities](#).

If NO:

Proceed to [Create Tributary Shelf Entities](#).

2.7.2

Create Auxiliary Optical Shelf Equipment Entities

Create Auxiliary Optical shelves as follows:

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X. For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default¹⁶</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 2

For each Auxiliary Optical shelf OS2...OS4, as required, create the Auxiliary Optical shelf equipment entity, and place it in service.

Note: Do not create Auxiliary Optical shelves OS25 or OS26 at this time.

Note: Shelf location identifiers, SHEFLBL and USERLBL, are optional parameters that precisely identify the location of equipment. If provisioned, the values appear in equipment retrieval and alarm messages. The SHEFLBL value indicates the physical location of the bay and shelf. The USERLBL value indicates the frame identification code (FIC). Telcordia NMA OSMINE users should keep the SHEFLBL and USERLBL parameters values as NULL (default). For more information, refer to [Shelf Location Identifiers](#).

¹⁶ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::TYPE: KEYWORD=DOMAIN:IS; AID:</p> <ul style="list-style-type: none"> OS2...OS4 <p>TYPE:</p> <ul style="list-style-type: none"> SHU3 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> SHELFLBL = Up to 13 characters with each character an uppercase letter (A...Z) or number (0...9) (null is default) USERLBL = Up to 20 characters with each character an uppercase letter (A...Z), number (0...9), or hyphen (-) (null is default) <p>Example: ENT-EQPT:FUJITSU:OS2:CTAG::SHU3::IS;</p>	<p>NE ▶ Create</p> <p>The Operations dialog box opens. Click the Shelf tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select the appropriate AIDs. Select the Type. Select the State (IS). <p>Type values into the SHELFLBL and/or USERLBL fields, if required. Click Create.</p> <p>Close the Operations dialog box.</p>

Step 3

Verify that the Auxiliary Optical shelf equipment entity is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As specified in previous step ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS2:CTAG;</p>	<p>In the tree view, select the Equipment tab. Select the appropriate shelf.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that the equipment Primary state is IS and that other properties are correct.</p> <p>Close the Properties dialog box.</p>

Note: The FAIL/SVCE indicator on (MPMA-SHPx) plug-in unit in slot MPMA-1 of this shelf should now be lit green.

Step 4

Repeat [Steps 2 through 3](#) for each Auxiliary Optical shelf OS2...OS4, as required.

Step 5

Does the node include Auxiliary Optical shelf OS25 or OS26?

If YES:
 Proceed to [Step 6](#).

If NO:
 Proceed to [Step 9](#).

Step 6

For each Auxiliary Optical shelf OS25 and OS26, as required, create the Auxiliary Optical shelf equipment entity, and place it in service.

Note: Shelf location identifiers, *SHELFLBL* and *USERLBL*, are optional parameters that precisely identify the location of equipment. If provisioned, the values appear in equipment retrieval and alarm messages. The *SHELFLBL* value indicates the physical location of the bay and shelf. The *USERLBL* value indicates the frame identification code (FIC). Telcordia NMA OSMINE users should keep the *SHELFLBL* and *USERLBL* parameters values as NULL (default). For more information, refer to [Shelf Location Identifiers](#).

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::TYPE; KEYWORD=DOMAIN:IS; AID:</p> <ul style="list-style-type: none"> OS25, OS26 <p>TYPE:</p> <ul style="list-style-type: none"> SHU3 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> <i>SHELFLBL</i> = Up to 13 characters with each character an uppercase letter (A...Z) or number (0...9) (null is default) <i>USERLBL</i> = Up to 20 characters with each character an uppercase letter (A...Z), number (0...9), or hyphen (-) (null is default) <p>Example: ENT-EQPT:FUJITSU:OS25:CTAG::SHU3: :IS;</p>	<p>NE ▶ Create</p> <p>The Operations dialog box opens. Click the Shelf tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select the appropriate AIDs. Select the Type. Select the State (IS). <p>Type values into the <i>SHELFLBL</i> and/or <i>USERLBL</i> fields, if required. Click Create.</p> <p>Close the Operations dialog box.</p>

Step 7

Verify that the Auxiliary Optical shelf equipment entity is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As specified in previous step ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS25:CTAG;</p>	<p>In the tree view, select the Equipment tab. Select the appropriate shelf.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that the equipment Primary state is IS and that other properties are correct.</p> <p>Close the Properties dialog box.</p>

Step 8

Repeat [Steps 6 through 7](#) for each Auxiliary Optical shelf OS25 and OS26, as required.

Step 9

Is the FAIL/SVCE indicator on the MPMA-SHPx plug-in unit within each of the Auxiliary Optical shelves lit green?

If YES:
Proceed to [Step 12](#).

If NO:
Proceed to [Step 10](#).

Step 10

Reinitialize the system software with LEVEL=WARM and ADOPT=SHELF.

Note: This command automatically logs the user off the NE.

TL1	NETSMART 500
<pre>INIT-SYS:TID:AID:CTAG:::LEVEL=WARM, ADOPT=SHELF; AID: • ALL (null) Example: INIT-SYS:FUJITSU:::CTAG:::LEVEL=WARM, ADOPT=SHELF;</pre>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the Initialize tab. Click the NE tab. Select Level: WARM. Select Adopt: SHELF. Click Initialize.</p> <p>Click Yes in the pop-up window to continue.</p> <p>If a second pop-up window opens, the connection is lost, and you must log on the NETSMART 500 user interface again to continue by clicking Logon.</p>

The NOT READY indicator on the NEM Shelf Processor plug-in unit lights amber and then goes out after 5 to 20 minutes. After the NOT READY indicator goes out, the FAIL/SVCE indicator lights green on the NEM Shelf Processor unit.

Step 11

Is the FAIL/SVCE indicator on the MPMA-SHPx plug-in unit within each of the Auxiliary Optical shelves lit green?

If YES:

Proceed to [Step 12](#).

If NO:

The MPMA-SHPx plug-in unit may be defective.

1. Remove the MPMA-SHPx plug-in unit from slot MPMA-1, and set it aside for repair paperwork processing.
2. Obtain another MPMA-SHPx plug-in unit, and install it in slot MPMA-1. After 5 to 20 minutes, the amber NOT READY and FAIL/SVCE indicators should go out, and the FAIL/SVCE indicator should light green.
3. If the FAIL/SVCE indicator lights green, proceed to [Step 12](#). If it does not, call Fujitsu at 1-800-USE-FTAC for technical assistance.

Step 12

Does the node include one or more Tributary shelves?

If YES:

Proceed to [Create Tributary Shelf Entities](#).

If NO:

Proceed to [Provision Optical Shelf Equipment and Facilities](#).

2.7.3

Create Tributary Shelf Entities

These steps create the Tributary shelf equipment entities and place them in service.

A shelf equipment entity cannot be created until supporting entities in the hierarchy (see the following figures) are created. For example, shelf OS100 cannot be created until shelf OS10 has been created.





Figure 33: Shelf Hierarchy at ROADM Node

Note: A single node cannot support all of the Tributary shelves shown in the following figure. A node can support no more than 20 Tributary shelves.



m1714qn_5

Figure 34: Shelf Hierarchy at HUB Node

This subprocedure includes steps to create all Tributary shelves that can be supported. Omit steps for Tributary shelves that are not included in the work order.

This procedure assumes the following:

- LAN cables and fan units (FAN6) have already been installed in each Tributary shelf ([Verify Shelf Labeling](#), [Verify LAN and RICC Cable Connections](#), [Apply Power](#), and [Install Fan Units](#)).
- NE Management (NEM) Shelf Processor units (MPMA-SHPx) have already been installed in each Tributary shelf ([Install Shelf Processors](#)).
- The Auxiliary Optical shelves OSn (n = 2...4), if used, have already been created ([Create Auxiliary Optical Shelf Equipment Entities](#)).

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default¹⁷</p>	<p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>
	<p>Click Logon. The NETSMART 500 NE View opens. The Security Message dialog box opens. Click OK. Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	

Step 2

For each Tributary shelf OS10...OS13, OS20...OS23, OS30...OS33, and OS40...OS43, as required, create the equipment entity and place it in service.

Note: Do not create Tributary shelves OS100, OS101, OS110, OS111, OS120, OS130, OS200, OS201, OS210, OS211, OS220, OS230, OS300, OS301, OS310, OS311, OS320, OS330, OS400, OS401, OS410, OS411, OS420, or OS430 at this time.

Note: Shelf location identifiers *SHELFLBL* and *USERLBL* are optional parameters that precisely identify the location of equipment. If provisioned, the values appear in equipment retrieval and alarm messages. The *SHELFLBL* value indicates the physical location of the bay and shelf. The *USERLBL* value indicates the frame identification code (FIC). Telcordia NMA OSMINE users should keep the *SHELFLBL* and *USERLBL* parameters values as NULL (default). For more information, refer to [Shelf Location Identifiers](#).

¹⁷ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::TYPE; KEYWORD=DOMAIN:IS; AID:</p> <ul style="list-style-type: none"> OS10...OS13 OS20...OS23 OS30...OS33 OS40...OS43 <p>Note: See Figure 34 for Tributary shelf hierarchy and AIDs.</p> <p>TYPE:</p> <ul style="list-style-type: none"> SHU3 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> SHELFLBL = Up to 13 characters with each character an uppercase letter (A...Z) or number (0...9) (null is default) USERLBL = Up to 20 characters with each character an uppercase letter (A...Z), number (0...9), or hyphen (-) (null is default) <p>Example: ENT-EQPT:FUJITSU:OS10:CTAG::SHU3::IS;</p>	<p>NE ▶ Create</p> <p>The Operations dialog box opens. Click the Shelf tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select the appropriate AIDs. Select the Type. Select the State (IS). <p>Type values into the SHELFLBL and/or USERLBL fields, if required. Click Create.</p> <p>Close the Operations dialog box.</p>

Step 3

Verify that the shelf equipment entity is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As identified in previous step ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS10:CTAG;</p>	<p>In the tree view, select the Equipment tab. Select the appropriate shelf.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that the equipment Primary state is IS and that other properties are correct.</p> <p>Close the Properties dialog box.</p>

Step 4

Repeat [Steps 2 through 3](#) for each Tributary shelf OS10...OS13, OS20...OS23, OS30...OS33, and OS40...OS43, as required.

Step 5

Does the node include Tributary shelves OS100, OS101, OS110, OS111, OS120, OS130, OS200, OS201, OS210, OS211, OS220, OS230, OS300, OS301, OS310, OS311, OS320, OS330, OS400, OS401, OS410, OS411, OS420, or OS430?

If YES:

Proceed to [Step 6](#).

If NO:

Proceed to [Step 9](#).

Step 6

For each Tributary shelf OS100, OS200, OS300, OS400, as required, create the equipment entity and place it in service.

Note: Shelf location identifiers *SHELFLBL* and *USERLBL* are optional parameters that precisely identify the location of equipment. If provisioned, the values appear in equipment retrieval and alarm messages. The *SHELFLBL* value indicates the physical location of the bay and shelf. The *USERLBL* value indicates the frame identification code (FIC). Telcordia NMA OSMINE users should keep the *SHELFLBL* and *USERLBL* parameters values as NULL (default). For more information, refer to [Shelf Location Identifiers](#).

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::TYPE: KEYWORD=DOMAIN:IS; AID:</p> <ul style="list-style-type: none"> OS100, OS101, OS110, OS111, OS120, OS130, OS200, OS201, OS210, OS211, OS220, OS230, OS300, OS301, OS310, OS311, OS320, OS330, OS400, OS401, OS410, OS411, OS420, OS430 <p>• Note: See Figure 34 for Tributary shelf hierarchy and AIDs.</p> <p>TYPE:</p> <ul style="list-style-type: none"> SHU3 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> SHELFLBL = Up to 13 characters with each character an uppercase letter (A...Z) or number (0...9) (null is default) USERLBL = Up to 20 characters with each character an uppercase letter (A...Z), number (0...9), or hyphen (-) (null is default) <p>Example: ENT-EQPT:FUJITSU:OS100:CTAG::SHU3::IS;</p>	<p style="text-align: center;">NE ▶ Create</p> <p>The Operations dialog box opens. Click the Shelf tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select the appropriate AIDs. Select the Type. Select the State (IS). <p>Type values into the SHELFLBL and/or USERLBL fields, if required. Click Create.</p> <p>Close the Operations dialog box.</p>

Step 7

Verify that the shelf equipment entity is in service.

TL1	NETSMART 500
<pre>RTRV-EQPT:TID:AID:CTAG;</pre> <p>AID:</p> <ul style="list-style-type: none">As identified in previous stepALL (null) <p>Example:</p> <pre>RTRV-EQPT:FUJITSU:OS100:CTAG;</pre>	<p>In the tree view, select the Equipment tab. Select the appropriate shelf.</p> <p>Entity ▸ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that the equipment Primary state is IS.</p> <p>Close the Properties dialog box.</p>

Step 8

Repeat [Steps 6 through 7](#) for each Tributary shelf OS100, OS101, OS110, OS111, OS120, OS130, OS200, OS201, OS210, OS211, OS220, OS230, OS300, OS301, OS310, OS311, OS320, OS330, OS400, OS401, OS410, OS411, OS420, and OS430, as required.

Step 9

For each Tributary shelf in the node, verify that the FAIL/SVCE indicator is lit green on each NEM Shelf Processor (MPMA-SHPx) plug-in unit.

Step 10

Are the FAIL/SVCE indicators lit green on all Tributary shelf MPMA-SHPx plug-in units?

If YES:

Proceed to [Step 15](#).

If NO:

Proceed to [Step 11](#).

Step 11

Reinitialize the system software with LEVEL=WARM and ADOPT=SHELF.

Note: This command automatically logs the user off the NE.

TL1	NETSMART 500
<pre>INIT-SYS:TID:AID:CTAG:::LEVEL=WARM, ADOPT=SHELF; AID: • ALL (null) Example: INIT-SYS:FUJITSU::CTAG:::LEVEL=WARM, ADOPT=SHELF;</pre>	<p>NE ▶ <i>System Operations</i></p> <p>The Operations dialog box opens. Click the Initialize tab. Click the NE tab. Select Level: WARM. Select Adopt: SHELF. Click Initialize.</p> <p>Click Yes in the pop-up window to continue.</p> <p>If a second pop-up window opens, the connection is lost, and you must log on the NETSMART 500 user interface again to continue by clicking Logon.</p>

The NOT READY indicator on the NEM Shelf Processor plug-in unit lights amber and then goes out after 5 to 20 minutes. After the NOT READY indicator goes out, the FAIL/SVCE indicator lights green on the NEM Shelf Processor unit.

Step 12

Are the FAIL/SVCE indicators lit green on all Tributary shelf MPMA-SHPx plug-in units?

IF YES:

Proceed to [Step 15](#).

IF NO:

Choose any Tributary shelf that does not have green FAIL/SVCE indicators on the MPMA-SHPx plug-in units, and proceed to [Step 13](#).

Step 13

Remove the MPMA-SHPx plug-in unit from slot MPMA-1, and set it aside for repair paperwork processing. Obtain another MPMA-SHPx plug-in unit, and install it in slot MPMA-1.

After 5 to 20 minutes, the amber NOT READY and FAIL/SVCE indicators should go out, and the FAIL/SVCE indicator should light green.

Step 14

If the FAIL/SVCE indicator lights green, return to [Step 9](#). If it does not, call Fujitsu at 1-800-USE-FTAC for technical assistance.

Step 15

Proceed to [Provision Optical Shelf Equipment and Facilities](#).


2.8

Provision Optical Shelf Equipment and Facilities

In this section:

- 2.8.1 Log On
- 2.8.2 Autoprovision Optical Shelf Equipment and Facilities
- 2.8.3 Manually Provision Optical Shelf Equipment
- 2.8.4 Manually Provision WDM and OSC Facilities
- 2.8.5 Place ODCC In Service

The following figure shows a flowchart of how these subprocedures are used to turn-up an Optical shelf.



m1714uk_8

Figure 35: Provision Optical Shelf Equipment and Facilities (Procedure Flowchart)

2.8.1

Log On



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default¹⁸</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

¹⁸ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

Step 2

In provisioning the Optical shelf equipment and facilities, do you want to use the autoprovisioning feature?

If YES:

Proceed to [Autoprovision Optical Shelf Equipment and Facilities](#).

If NO:

Proceed to [Manually Provision Optical Shelf Equipment](#).

2.8.2

Autoprovision Optical Shelf Equipment and Facilities

The following figure shows a flowchart of how these subtasks are used to autoprovision the Optical shelf equipment and facilities.




Figure 36: Autoprovision Optical Shelf Equipment and Facilities (Subprocedure Flowchart)

This subprocedure describes one method for installing and provisioning plug-in units in the Optical shelf OSn (n = 1...4, 25, 26). Another option is to use the procedures in [Manually Provision Optical Shelf Equipment](#), and [Manually Provision WDM and OSC Facilities](#).

Note: For plug-in unit slot locations, refer to [Slot Labels and AIDs](#).

The FLASHWAVE 7500 system provides automatic provisioning of the equipment and facilities and also provides the automatic in-service provisioning (AISP) capability for all facility types. Autoprovisioning and AISP are the default software settings.

After the plug-in unit is seated, the equipment entity is created and placed in service. Facilities are also created and placed in an Out-of-Service (OOS), Auto In-Service (AINS) state. While in the AINS state, alarms such as LOS are not generated, and the system waits for the application of a valid signal. Upon receiving a valid signal, the system begins a time-out period and then automatically transitions to the

In-Service (IS) state. The default time-out period is 8 hours and can be modified using the ED-SYS command.

Note: All equipment except shelves can be autoprovisioned. Shelves require manual provisioning to be placed in service.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

If the facility is lost during the time-out period because of LOF or LOS, the time-out period is reset. Normal alarm reporting begins when the time-out period has completed and the transition to the IS state has occurred.

Install and autoprovision Optical shelf equipment as follows:

Enable Autoprovisioning

Note: You should already be logged on the NE (refer to [Step 1](#)).

Note: Default values are shown in bold.

Step 1

Retrieve the state of the autoprovisioning feature.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the tree view, select the NE (the top-level system entity).</p> <p>Entity ▶ Properties View</p> <p>In the Current Values area of the Properties dialog box, determine the value of AUTOP (Yes or No).</p> <p>Close the Properties dialog box.</p>

Step 2

Is autoprovisioning already enabled? (Is the current value of AUTOP set to Yes?)

IF YES:

Proceed to [Step 5](#).

IF NO:

Proceed to [Step 3](#).

Step 3

Enable autoprovisioning, and provision the AISP feature and the AISP timer if necessary.

TL1	NETSMART 500
<p>ED-SYS:TID::CTAG::KEYWORD=DOMAIN; KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> CONTACT = Contact information; 40-character string delineated by escape quotes ("string") LOCATION = Location information; 40-character string delineated by escape quotes ("string") AUTOP = Y, N (autoprovisioning) AISPDEFTM = 00-00...08-00...48-00 (default valid signal timer in 1-minute increments) <p>Example: ED-SYS:FUJITSU::CTAG::AUTOP=Y, AISPDEFTM=08-00;</p>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab. Set AUTOP to Yes. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 4
 Verify that autoprovisioning is enabled.

TL1	NETSMART 500
<p>RTRV-SYS:TID::CTAG;</p> <p>Example: RTRV-SYS:FUJITSU::CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the updated information is correct.</p> <p>Close the Operations dialog box.</p>

Install All Plug-In Units

Step 5
 Refer to your work order to identify the plug-in units to be installed in the Optical shelf OSn (n = 1...4, 25, 26).

Note: [Slot Labels and AIDs](#), describes the plug-in units that are supported by each slot of the Optical shelf. However, in most applications, the Optical shelf is not fully populated with plug-in units. The work order should specify which slots should be equipped.

Note: Examples that show the plug-in units required in typical applications are given in [About System Turn-up Core Configuration](#).

Step 6
 Install the plug-in units, identified in the previous step, in their appropriate slots. Refer to [Slot Labels and AIDs](#) for slot locations. For each plug-in unit to be installed, do the following:

- a) Inspect the plug-in unit for possible damage or debris.
- b) Slide the unit into the appropriate shelf slot.

Install Filler Panels

Step 7

Install filler panels in any unused slots.

Verify Plug-In Units Are In Service

Step 8

Ensure that each of the plug-in units installed in the previous step is properly provisioned and that the equipment state is IS, Normal (STATE=IS-NR). Refer to [Slot Labels and AIDs](#), for plug-in unit listing.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> Equipment slot AID (refer to Slot Labels and AIDs) ALL <p>Example: RTRV-EQPT:FUJITSU::CTAG;</p>	<p>In the shelf OS1 graphic view or tree view, select the equipment slot.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the PRIMARY_STATE is IS.</p> <p>Verify the PRIMARY_STATE_QUALIFIER is NR.</p> <p>Close the Properties dialog box.</p>

Verify WDM Facilities Are In Service

Note: Depending on your work order, you installed one or two amplifier (APMA-xxxx) plug-in units in [Step 6](#). Amplifier plug-in units are located in slots 1 and 19 of the Optical shelf.

Step 9

Verify that the WDM facility associated with each installed amplifier plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> OSn-1-PE1 (WDM facility for slot-1 amplifier) OSn-19-PE1 (WDM facility for slot-19 amplifier) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the tree view, click the Facilities tab. Select the facility.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that In-Service state and provisioning parameters are correct.</p> <p>Close the Properties dialog box.</p>

Step 10

Are the WDM facilities in service and provisioned correctly?

If YES:

Proceed to [Step 11](#).

If NO:

Correct WDM facility provisioning using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#). Then proceed to [Step 11](#).

Verify OSC Facilities Are In Service

Step 11

Verify that the OSC facility associated with each installed OSC plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<p>RTRV-OSC:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">OSn-9-PE1 (OSC facility for slot-9 plug-in unit)OSn-11-PE1 (OSC facility for slot-11 plug-in unit)<ul style="list-style-type: none">n = 1...4, 25, 26 <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>In the tree view, click the Facilities tab. Select the facility.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens. Verify that In-Service state and provisioning parameters are correct. Close the Properties dialog box.</p>

Step 12

Are the OSC facilities in service and provisioned correctly?

If YES:

Proceed to [Step 13](#).

If NO:

Correct OSC facility provisioning using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#). Then proceed to [Place ODCC In Service](#).

Step 13

Repeat [Steps 5 through 12](#) for each Optical shelf OSn (n = 1...4, 25, 26), as required.

Step 14

Proceed to [Place ODCC In Service](#).

 This procedure is complete.

2.8.3 Manually Provision Optical Shelf Equipment

The flowchart in the following figure shows how these subtasks are used to manually provision the Optical shelf equipment.




Figure 37: Manually Provision Optical Shelf Equipment (Subprocedure Flowchart)

This subprocedure describes one method for installing and provisioning plug-in units in the Optical shelf OSn (n = 1...4, 25, 26). For an alternative method, refer to [Autoprovision Optical Shelf Equipment and Facilities](#).

Note: For plug-in unit slot locations, refer to [Slot Labels and AIDs](#).

This subprocedure includes steps to equip and manually provision each slot of the Optical shelf that can support a plug-in unit. However, in most applications, the Optical shelf is not fully populated with plug-in units. The work order should specify which slots should be equipped. Within this subprocedure, omit all steps associated with slots that are not equipped in the work order.

Note: Examples that show the plug-in units required in typical applications are given in [About System Turn-up Core Configuration](#).

Note: This procedure includes steps to install plug-in units in the appropriate slots in the Optical shelf. However, if certain plug-in units are not available, you can complete the procedure without installing them. This is called preprovisioning the slot. In this case, the unit will assume the specified provisioning when the unit is eventually installed in the slot. Note that an unequipped alarm will be raised until the unit is installed.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Install and manually provision equipment in the Optical shelf OSn (n = 1...4, 25, 26) as follows:

Disable Autoprovisioning

Note: You should already be logged on the NE (refer to [Log On](#)).

Note: Default values are shown in bold.

Step 1

Retrieve the state of the autoprovisioning feature.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the tree view, select the NE (the top-level system entity).</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>In the Current Values area of the Properties dialog box, determine the value of AUTOP (Yes or No).</p> <p>Close the Properties dialog box.</p>

Step 2

Is autoprovisioning already disabled? (Is the current value of AUTOP set to No?)

IF YES:

Proceed to [Step 5](#).

IF NO:

Proceed to [Step 3](#).

Step 3

Disable the autoprovisioning feature.

Note: If autoprovisioning is already disabled, this command will fail.

TL1	NETSMART 500
<p>ED-SYS:TID::CTAG::AUTOP=N;</p> <p>Example: ED-SYS:FUJITSU::CTAG::AUTOP=N;</p>	<p>NE ▶ <i>System Operations</i></p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab. Set AUTOP to No. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 4

Verify that the autoprovisioning feature is disabled.

TL1	NETSMART 500
<p>RTRV-SYS:TID::CTAG;</p> <p>Example: RTRV-SYS:FUJITSU::CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the value of AUTOP is No.</p> <p>Close the Operations dialog box.</p>

Install and Provision Amplifier Unit(s)

Step 5

Depending on your work order, install one or two amplifier (APMA-xxxx) plug-in units in the appropriate slots (1 and 19) of the Optical shelf. For each amplifier plug-in unit to be installed, do the following:

- a) Inspect the amplifier plug-in unit for possible damage or debris.
- b) Slide the amplifier plug-in unit into the Optical shelf slot.

Step 6

For each plug-in unit installed in the previous step, create the amplifier equipment entity, and place it in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::TYPE::IS; AID:</p> <ul style="list-style-type: none"> OSn-1 (slot 1) OSn-19 (slot 19) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>TYPE:</p> <ul style="list-style-type: none"> APMA-L2C1 APMA-M2C1 APMA-ULC1 APMA-M2U1 APMA-ULU1 APMA-MHU1 <p>Example: ENT-EQPT:FUJITSU:OS1-1:CTAG:: APMA-L2C1::IS;</p>	<p>In the tree view, select the Equipment tab.</p> <p>Expand the appropriate Optical shelf OSn (n = 1...4, 25, 26). Select slot 1 or 19.</p> <p>Entity ▸ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> At New Prov. State, select In Service (ENT-IS). Click the Type tab. Select the appropriate equipment type. Click Modify. <p>Do not close the Operations dialog box.</p>

Step 7

For each equipment entity created in the previous step, verify that it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As identified in previous step ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS1-1&OS1-19:CTAG;</p>	<p>In the Current Values of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Step 8

Is this a 2D-ROADM configuration node?

If YES:

Proceed to [Step 9](#).

If NO:

Proceed to [Step 13](#).

Install and Provision 2D-ROADM Unit(s)

Step 9

Depending on your work order, install one or two 2D-ROADM (SFMA-RDC1) plug-in units in the appropriate slots (3 and 17) of the shelf OS1. For each 2D-ROADM plug-in unit to be installed, do the following:

- a) Inspect the 2D-ROADM plug-in unit for possible damage or debris.
- b) Slide the 2D-ROADM plug-in unit into the Optical shelf slot.

Step 10

For each plug-in unit installed in the previous step, create the 2D-ROADM equipment entity, and place it in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::SFMA-RDC1::IS; AID: • OS1-3 (slot 3) • OS1-17 (slot 17)</p> <p>Example: ENT-EQPT:FUJITSU:OS1-3:CTAG:: SFMA-RDC1::IS;</p>	<p>In the tree view, select the Equipment tab. Expand the Main Optical shelf. Select slot 3 or 17.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • At New Prov. State, select In Service (ENT-IS). • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 11

For each equipment entity created in the previous step, verify that it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID: • OS1-3 (slot 3) • OS1-17 (slot 17)</p> <p>Example: RTRV-EQPT:FUJITSU:OS1-3&OS1-17:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Step 12

Proceed to [Step 33](#).

Install and Provision WSS Core Switch Unit(s)

Step 13

Depending on your work order, install one or two WSS Core Switch (SFMA-CMC1) plug-in units in the appropriate slots (3 and 17) of the Optical shelf. For each WSS Core Switch plug-in unit to be installed, do the following:

- a) Inspect the WSS Core Switch plug-in unit for possible damage or debris.
- b) Slide the WSS Core Switch plug-in unit into the Optical shelf slot.

Step 14

For each plug-in unit installed in the previous step, create the WSS Core Switch equipment entity, and place it in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::SFMA-CMC1::IS; AID: • OSn-3 (slot 3) • OSn-17 (slot 17) • n = 1...4, 25, 26</p> <p>Example: ENT-EQPT:FUJITSU:OS1-3:CTAG:: SFMA-CMC1::IS;</p>	<p>In the tree view, select the Equipment tab.</p> <p>Expand the appropriate Optical shelf. Select slot 3 or 17.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • At New Prov. State, select In Service (ENT-IS). • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 15

For each equipment entity created in the previous step, verify it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID: • As identified in previous step • ALL (null)</p> <p>Example: RTRV-EQPT:FUJITSU:OS1-3&OS1-17:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Step 16

Are you provisioning equipment in an Auxiliary Optical shelf OSn (n = 2...4, 25, 26)?

If YES:

Proceed to [Step 17](#).

If NO:

Proceed to [Step 20](#).

Note: OSC plug-in units have already been installed in shelf OS1 (Step 19 of [Install Primary NE Management Units in Shelf OS1, and Configure Shelf OS1 as the Main Optical Shelf](#)).

Install and Provision OSC Unit(s)

Step 17

Depending on your work order, install one or two OSC (SCMA-SCC4) plug-in units in the appropriate slots (9 and 11) of the Auxiliary Optical shelf. For each OSC plug-in unit to be installed, do the following:

- a) Inspect the OSC plug-in unit for possible damage or debris.
- b) Slide the OSC plug-in unit into the Optical shelf slot.

Step 18

For each plug-in unit installed in the previous step, create the OSC equipment entity, and place it in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::SCMA-SCC4::IS; AID: • OSn-9 (slot 9) • OSn-11 (slot 11) • n = 2...4, 25, 26</p> <p>Example: ENT-EQPT:FUJITSU:OS2-9:CTAG:: SCMA-SCC4::IS;</p>	<p>In the tree view, select the Equipment tab.</p> <p>Expand the appropriate Auxiliary Optical shelf OSn (n = 2...4, 25, 26). Select slot 9 or 11.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • At New Prov. State, select In Service (ENT-IS). • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 19

For each equipment entity created in the previous step, verify it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">As identified in previous stepALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS2-9&OS2-11:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Install and Provision Mux/Demux Unit(s)

Step 20

Does your work order include installation of Mux/Demux (MDMA-RMC1) plug-in units (in slots 5 and 15 of the Optical shelf)?

IF YES:

Proceed to [Step 21](#).

IF NO:

Proceed to [Step 24](#).

Step 21

Depending on your work order, install one or two Mux/Demux plug-in units in the appropriate slots (5 and 15) of the Optical shelf. For each Mux/Demux plug-in unit to be installed, do the following:

- Inspect the Mux/Demux plug-in unit for possible damage or debris.
- Slide the Mux/Demux plug-in unit into the Optical shelf slot.

Step 22

For each plug-in unit installed in the previous step, create the Mux/Demux equipment entity, and place it in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::MDMA-RMC1::IS; AID: • OSn-5 (slot 5) • OSn-15 (slot 15) • n = 1...4, 25, 26</p> <p>Example: ENT-EQPT:FUJITSU:OS1-5:CTAG:: MDMA-RMC1::IS;</p>	<p>In the tree view, select the Equipment Tab. Expand the appropriate Optical shelf. Select slot 5 or 15.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • At New Prov. State, select In Service (ENT-IS). • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 23

For each equipment entity created in the previous step, verify it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID: • As identified in previous step • ALL (null)</p> <p>Example: RTRV-EQPT:FUJITSU:OS1-5&OS1-15:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Install and Provision WSS HUB Switch Unit(s)

Step 24

Does your work order include installation of WSS HUB Switch (SFMA-CDC1) plug-in units (in slots 7 and 13 of the Optical shelf)?

If YES:
 Proceed to [Step 25](#).

If NO:
 Proceed to [Step 29](#).

Step 25

Depending on your work order, install one or two WSS HUB Switch plug-in units in the appropriate slots (7 and 13) of the Optical shelf. For each WSS HUB Switch plug-in unit to be installed, do the following:

- a) Inspect the WSS HUB Switch plug-in unit for possible damage or debris.
- b) Slide the WSS HUB Switch plug-in unit into the Optical shelf slot.

Step 26

For each plug-in unit installed in the previous step, create the WSS HUB Switch equipment entity, and place it in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::SFMA-CDC1::IS; AID: • OSn-7 (slot 7) • OSn-13 (slot 13) • n = 1...4, 25, 26</p> <p>Example: ENT-EQPT:FUJITSU:OS1-7:CTAG:: SFMA-CDC1::IS;</p>	<p>In the tree view, select the Equipment tab. Expand the appropriate Optical shelf. Select slot 7 or 13.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • At New Prov. State, select In Service (ENT-IS). • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 27

For each equipment entity created in the previous step, verify that it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID: • As identified in previous step • ALL (null)</p> <p>Example: RTRV-EQPT:FUJITSU:OS1-7&OS1-13:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Step 28

Proceed to [Step 29](#).

Install and Provision OSC HUB Interconnect Unit(s)

Step 29

Does your work order include installation of OSC HUB Interconnect (MCMA-RCS1) plug-in units (in slots 10 and 12 of the Optical shelf)?

If YES:

Proceed to [Step 30](#).

If NO:

Proceed to [Step 33](#).

Step 30

Depending on your work order, install one or two OSC HUB Interconnect plug-in units in the appropriate slots (10 and 12) of the Optical shelf. For each OSC HUB Interconnect plug-in unit to be installed, do the following:

- a) Inspect the OSC HUB Interconnect plug-in unit for possible damage or debris.
- b) Slide the OSC HUB Interconnect plug-in unit into the Optical shelf slot.

Step 31

For each plug-in unit installed in the previous step, create the OSC HUB Interconnect equipment entity, and place it in service.

TL1	NETSMART 500
<pre>ENT-EQPT:TID:AID:CTAG::MCMA-RCS1::IS; AID: • OSn-10 (slot 10) • OSn-12 (slot 12) • n = 1..4, 25, 26</pre> <p>Example: ENT-EQPT:FUJITSU:OS1-10:CTAG:: MCMA-RCS1::IS;</p>	<p>In the tree view, select the Equipment tab.</p> <p>Expand the appropriate Optical shelf. Select slot 10 or 12.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none">• At New Prov. State, select In Service (ENT-IS).• Click Modify. <p>Do not close the Operations dialog box.</p>

Step 32

For each equipment entity created in the previous step, verify that it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">As identified in previous stepALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS1-10&OS1-12:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Install Filler Panels

Step 33

Install filler panels in any unused slots of the Optical shelf.

Step 34

Repeat [Steps 5 through 33](#) for each Optical shelf OS_n (n = 1...4, 25, 26), as required.

Step 35

Proceed to [Manually Provision WDM and OSC Facilities](#).

 This procedure is complete.

2.8.4

Manually Provision WDM and OSC Facilities

The following steps are used to manually create the WDM and OSC facilities and place them in service.

Note: If you autoprovisioned the Optical shelf (refer to [Autoprovision Optical Shelf Equipment and Facilities](#)), WDM and OSC facilities have already been created. Skip this procedure and continue to [Place ODCC In Service](#).

Note: Default values are shown in bold.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Manually provision WDM and OSC facilities as follows:

Manually Provision WDM Facilities

Note: You should already be logged on the NE ([Step 1](#)).

Step 1

Depending on the work order, one or two amplifier (APMA-xxxx) plug-in units were installed in [Step 5](#). Amplifier plug-in units are located in slots 1 and 19 of the Optical shelf. For each installed amplifier plug-in unit, create the associated WDM facility, and place it in service.

TL1	NETSMART 500
<p>ENT-WDM:TID:AID:CTAG:::KEYWORD=DOMAIN:IS; AID:</p> <ul style="list-style-type: none"> OSn-1-PE1 (WDM facility associated with slot-1 amplifier) OSn-19-PE1 (WDM facility associated with slot-1 amplifier) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> VSTIMER = hh-mm <p>Example: ENT-WDM:FUJITSU:OS1-1-PE1:CTAG:::IS;</p>	<p>NE ▶ Create</p> <p>Click the Facility tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select type WDM. Select the appropriate facility AIDs. Select In Service (IS). Select the desired VSTIMER value. <p>Click Create.</p> <p>Close the Operations dialog box.</p>

Step 2

Verify that the WDM facility associated with each installed amplifier plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As identified in previous step ALL (null) <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>Click the Facilities tab in the tree area.</p> <p>Expand the appropriate shelf component.</p> <p>Select the appropriate facility AIDs.</p> <p>Note: Select more than one component using <i>CTRL+click (multiple)</i> or <i>SHIFT+click (range)</i>.</p> <p>Entity ▶ Properties View</p> <p>Verify the new facility.</p> <p>Close the Properties dialog box.</p>

Step 3

Are the WDM facilities in service and provisioned correctly?

IF YES:

Proceed to [Step 4](#).

IF NO:

Correct WDM facility provisioning using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#). Then proceed to [Step 4](#).

Manually Provision OSC Facilities

Note: Depending on the work order, one or two OSC plug-in units (SCMA-SCC4) were installed in the Optical shelf. OSC plug-in units are located in slots 9 and 11.

Step 4

For each installed OSC plug-in unit, create the OSC facility, and place it in service.

TL1	NETSMART 500
<p>ENT-OSC:TID:AID:CTAG:::KEYWORD=DOMAIN:IS; AID:</p> <ul style="list-style-type: none"> OSn-9-PE1 (OSC facility for slot-9 plug-in unit) OSn-11-PE1 (OSC facility for slot-11 plug-in unit) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> VSTIMER = hh-mm JOSECTRC = Y, N TRC = \"up to 62 ASCII characters\" EXPTRC = \"up to 62 ASCII characters\" MISCON = Y, N REMOTE = SAME, DIFF <p>Example: ENT-OSC:FUJITSU:OS1-9-PE1:CTAG::: VSTIMER=04-00:IS;</p>	<p>NE ▶ Create</p> <p>Click the Facility tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select type OSC. Select the appropriate facility AIDs. Select In Service (IS). Select the appropriate provisioning options. <p>Click Create.</p> <p>Close the Operations dialog box.</p>

Step 5

Verify that the OSC facility associated with each installed OSC plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<p>RTRV-OSC:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As identified in previous step ALL (null) <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>Click the Facilities tab in the tree area.</p> <p>Expand the appropriate shelf component.</p> <p>Select the appropriate facility AIDs.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▶ Properties View</p> <p>Verify the new facility.</p> <p>Close the Properties dialog box.</p>

Step 6

Are the OSC facilities in service and provisioned correctly?

If YES:

Proceed to [Step 7](#).

If NO:


Correct OSC facility provisioning using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#). Then proceed to [Place ODCC In Service](#).

Step 7

Repeat [Steps 1 through 6](#) for each Auxiliary Optical shelf OSn (n = 2...4, 25, 26), as required.

Step 8

Proceed to [Place ODCC In Service](#).

 This procedure is complete.

2.8.5

Place ODCC In Service

An optical data communications channel (ODCC) can be assigned to every OSC facility up to a maximum of two channels per Optical shelf. The ODCC is used for communication with network-side NEs.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Depending on your work order, you have installed one or two OSC plug-in units (SCMA-SCC4), and the OSC facility associated with each installed OSC plug-in unit has been created and is in service. OSC plug-in units are located in slots 9 and 11 of the Optical shelf. For each installed OSC plug-in unit, create the associated ODCC and place it in service.

TL1	NETSMART 500
<p>ENT-SDCC:TID:AID:CTAG::: KEYWORD=DOMAIN:IS;</p> <p>AID (matching OSC facility AID):</p> <ul style="list-style-type: none"> OSn-9-PE1 (ODCC facility for slot-9 plug-in unit) OSn-11-PE1 (ODCC facility for slot-11 plug-in unit) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> K = 1...7, 8 L2CR = PLUS-R, NTWK, USER, PLUS-C T200 = 50...200...5000 T203 = 2...10...300 N200 = 2, 3...16 N201 = 260...1024 SRV = AIMS, UITS NETID = User-defined network identifier. Character string of up to 20 alphanumeric delineated by escape quotes ("). INSTID = Identifies the NLP (ISIS) management-port instance. Refer to command ENT-SDCC for more information about keyword INSTID. <p>Example: ENT-SDCC:FUJITSU:OS1-9-PE1:CTAG::: K=8,SRV=UITS:IS;</p>	<p style="text-align: center;">NE ▶ Create</p> <p>The Operations dialog box opens. Click the DCC tab.</p> <p>Select ODCC from the TYPE drop-down list in the Command Parameters area.</p> <p>Additional parameter choices appear:</p> <ul style="list-style-type: none"> From the AID drop-down list, select the ODCC facility AIDs. From the STATE drop-down list, select IS. If required, use the additional fields to set KEYWORD=DOMAIN values. <p>Click Create.</p> <p>A confirmation dialog box opens. Click Yes.</p> <p>Close the Operations dialog box.</p>

Step 2

Initialize the operation interface (OIF).

Note: The INIT-OIF command must be executed before the ENT-SDCC command becomes effective.

TL1	NETSMART 500
<p>INIT-OIF:TID::CTAG;</p> <p>Example: INIT-OIF:FUJITSU::CTAG;</p>	<p style="text-align: center;">NE ▶ System Operations</p> <p>The Operations dialog box opens. Click Initialize tab.</p> <p>In the Command Parameters area:</p> <p>Select OIF from the STACK INIT TYPE menu. Click Initialize.</p> <p>A Confirmation dialog box opens. Click Yes. Click Logon.</p>

Step 3

Wait 2 minutes before continuing.

Note: The NETSMART 500 connection to the NE will be lost. After waiting 2 minutes, users should log back on the NE.

Step 4

Verify the ODCC.

TL1	NETSMART 500
<p>RTRV-SDCC:TID:AID:CTAG;</p> <p>AID (matching OSC facility AID):</p> <ul style="list-style-type: none">• As identified in Step 1• ALL (null) <p>Example: RTRV-SDCC:FUJITSU:ALL:CTAG;</p>	<p>Restart the NETSMART 500 user interface, and log back on the NE.</p> <p>Note: Refer to Step 1.</p> <p>In the tree view, select the Communications tab.</p> <p>Expand the appropriate Optical shelf OS1 and OSC facility to locate the ODCC entity. Select the ODCC entity.</p> <p>Entity ▸ Properties View</p> <p>The Properties dialog box opens. Verify that the State is IS.</p> <p>Close the Properties dialog box when done.</p>

Step 5

Repeat [Steps 1 through 4](#) for each Optical shelf OSn (n = 1...4, 25, 26), as required.

Step 6

Do any of the Tributary shelves in this node require OSC plug-in units?

Note: OSC units (SCMA-SCC4) are installed in Tributary shelves to support interoperability with FLASHWAVE 7500 Extension Configuration NEs.

If YES:

Proceed to [Provision Synchronization and/or Tributary Shelf OSC Units](#).

If NO:

Proceed to [Step 7](#).

Step 7

Do any of the shelves in this node require Synchronization plug-in units?

Note: Synchronization units support timing and synchronization for Flexponder™ optical line cards. They are generally required in every shelf that include a Flexponder unit. However, the Synchronization unit is optional for shelves that include only single-unit applications of the IFMA-BXC1 Flexponder. If all STS cross-connects are within

individual IFMA-BXC1 units (never between units) , the Synchronization unit can be omitted from the shelf and timing accuracy will be ± 20 ppm for the IFMA-BXC1 units.

If YES:

Proceed to [Provision Synchronization and/or Tributary Shelf OSC Units](#).

If NO:

Proceed to [Install Intrashelf Fiber-Optic Cables](#).

2.9

Provision Synchronization and/or Tributary Shelf OSC Units

In this section:

- 2.9.1 Log On
- 2.9.2 Autoprovision Synchronization and/or OSC Plug-In Units
- 2.9.3 Manually Provision Synchronization and/or OSC Plug-In Units
- 2.9.4 Provision Synchronization

The following figure shows a flowchart of how these subprocedures are used.




Figure 38: Provision Synchronization and/or Tributary Shelf OSC Units (Procedure Flowchart)

Note: Synchronization units are generally required in every shelf that include a Flexponder unit. However, the Synchronization unit is optional for shelves that include only single-unit applications of the IFMA-BXC1

Flexponder. If all STS cross-connects are within individual IFMA-BXC1 units (never between units), the Synchronization unit can be omitted from the shelf and timing accuracy will be ± 20 ppm for the IFMA-BXC1 units.

When OSC units (SCMA-SCC4) are installed in a Tributary shelf they are used to support interoperability with FLASHWAVE 7500 Extension Configuration NEs. For more information, refer to [Extension Configuration Applications](#).

These subprocedures provision OSC and/or Synchronization plug-in units and synchronization.

2.9.1 Log On



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

If not already done, log on the node where the service is being provisioned. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER : TID : UID : CTAG : : PID ; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER : FUJITSU : ROOT : CTAG : : ROOT ;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default¹⁹</p>	<p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>
	<p>Click Logon. The NETSMART 500 NE View opens. The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	

Step 2

Do you want to provision the OSC and/or Synchronization plug-in units using the autoprovisioning feature?

IF YES:

Proceed to [Autoprovision Synchronization and/or OSC Plug-In Units](#).

IF NO:

Proceed to [Manually Provision Synchronization and/or OSC Plug-In Units](#).

2.9.2

Autoprovision Synchronization and/or OSC Plug-In Units

Enable Autoprovisioning

Note: You should already be logged on the NE (refer to [Step 1](#)).



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

¹⁹ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

Step 1

Retrieve the state of the autoprovisioning feature.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the tree view, select the NE (the top-level system entity).</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>In the Current Values area of the Properties dialog box, determine the value of AUTOP (Yes or No).</p> <p>Close the Properties dialog box.</p>

Step 2

Is autoprovisioning already enabled? (Is the current value of AUTOP set to Yes?)

If YES:

Proceed to [Step 5](#).

If NO:

Proceed to [Step 3](#).

Step 3

Enable autoprovisioning, and provision the AISP feature and the AISP timer if necessary.

TL1	NETSMART 500
<pre>ED-SYS:TID::CTAG:::KEYWORD=DOMAIN; KEYWORD=DOMAIN;</pre> <ul style="list-style-type: none"> CONTACT = Contact information; 40-character string delineated by escape quotes ("string") LOCATION = Location information; 40-character string delineated by escape quotes ("string") AUTOP = Y, N (autoprovisioning) AISPDEFTM = 00-00...08-00...48-00 (default valid signal timer in 1-minute increments) <p>Example: <pre>ED-SYS:FUJITSU::CTAG:::AUTOP=Y, AISPDEFTM=08-00;</pre></p>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab. Set AUTOP to Yes. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 4

Verify that autoprovisioning is enabled.

TL1	NETSMART 500
<p>RTRV-SYS:TID::CTAG;</p> <p>Example: RTRV-SYS:FUJITSU::CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the updated information is correct.</p> <p>Close the Operations dialog box.</p>

Step 5

Do any of the Tributary shelves in this node require OSC plug-in units?

Note: OSC units (SCMA-SCC4) are installed in Tributary shelves to support interoperability with FLASHWAVE 7500 Extension Configuration NEs.

IF YES:

Proceed to [Step 6](#).

IF NO:

Proceed to [Step 10](#).

Install and Autoprovision OSC Plug-In Units

Step 6

Install the OSC plug-in units in the appropriate shelf slots (9 and/or 11), as required. Refer to [Slot Labels and AIDs](#) for slot locations. For each plug-in unit to be installed, do the following:

- a) Inspect the plug-in unit for possible damage or debris.
- b) Slide the unit into the appropriate shelf slot (slot 9 or 11).

Step 7

Ensure that the plug-in units are properly provisioned and that the equipment state is IS, Normal (STATE=IS-NR).

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • Refer to the following table. • ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS100-9:CTAG;</p>	<p>In the shelf OSn graphic view or tree view, select the equipment slot.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the PRIMARY_STATE is IS.</p> <p>Verify the PRIMARY_STATE_QUALIFIER is NR.</p> <p>Close the Properties dialog box.</p>

Table 14: Tributary Shelf OSC Unit Equipment AIDs (Core Configuration)

Equipment Type	AID
SCMA-SCC4	OSn-s <ul style="list-style-type: none">n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 (shelf)s = 9, 11 (slot)

Step 8

Repeat [Steps 6 through 7](#) for each Tributary shelf that requires OSC plug-in units.

Step 9

Do any of the shelves in this node require Synchronization plug-in units?

Note: Synchronization units support timing and synchronization for Flexponder™ optical line cards. They are generally required in every shelf that include a Flexponder unit. However, the Synchronization unit is optional for shelves that include only single-unit applications of the IFMA-BXC1 Flexponder. If all STS cross-connects are within individual IFMA-BXC1 units (never between units), the Synchronization unit can be omitted from the shelf and timing accuracy will be ±20 ppm for the IFMA-BXC1 units.

If YES:

Proceed to [Step 10](#).

If NO:

Proceed to [Install Intrashelf Fiber-Optic Cables](#).

Install and Autoprovision Synchronization Plug-In Units

Step 10

Install the Synchronization plug-in units in the appropriate shelf slots (10 and/or 12). Refer to [Slot Labels and AIDs](#) for slot locations. For each plug-in unit to be installed, do the following:

- Inspect the plug-in unit for possible damage or debris.
- Slide the unit into the appropriate shelf slot (slot 10 or 12).

Step 11

Ensure that the plug-in units are properly provisioned and that the equipment state is IS, Normal (STATE=IS-NR).

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> Refer to the following table. ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS100-10:CTAG;</p>	<p>In the shelf OSn graphic view or tree view, select the equipment slot.</p> <div style="border: 1px solid gray; padding: 2px; background-color: #cccccc; display: inline-block;">Entity ▶ Properties View</div> <p>The Properties dialog box opens.</p> <p>Verify the PRIMARY_STATE is IS.</p> <p>Verify the PRIMARY_STATE_QUALIFIER is NR.</p> <p>Close the Properties dialog box.</p>

Table 15: Synchronization Unit Equipment AIDs (Core Configuration)

Equipment Type	AID ²⁰
TCMA-ST31	<p>OSn-s (WSS Core or 2D-ROADM applications)</p> <ul style="list-style-type: none"> n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 (shelf) s = 10, 12 (slot) <p>OS1-s (2D-ROADM applications only)</p> <ul style="list-style-type: none"> s = 10, 12 (slot)

Step 12

Repeat [Steps 10 through 11](#) for each shelf that requires Synchronization plug-in units.

Step 13

Proceed to [Provision Synchronization](#).

This procedure is complete.

2.9.3

Manually Provision Synchronization and/or OSC Plug-In Units

Disable Autoprovisioning

Note: You should already be logged on the NE ([Step 1](#)).



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

²⁰ Slot 10 is for the working equipment. Slot 12 is for the protect equipment.

Step 1

Retrieve the state of the autoprovisioning feature.

TL1	NETSMART 500
<p>RTRV-SYS:TID::CTAG;</p> <p>Example: RTRV-SYS:FUJITSU::CTAG;</p>	<p>In the tree view, select the NE (the top-level system entity).</p> <p>Entity ▸ Properties View</p> <p>The Properties dialog box opens.</p> <p>In the Current Values area of the Properties dialog box, determine the value of AUTOP (Yes or No).</p> <p>Close the Properties dialog box.</p>

Step 2

Is autoprovisioning already disabled? (Is the current value of AUTOP set to No?)

If YES:

Proceed to [Step 10](#).

If NO:

Proceed to [Step 3](#).

Step 3

Disable the autoprovisioning feature.

Note: *If autoprovisioning is already disabled, this command will fail.*

TL1	NETSMART 500
<p>ED-SYS:TID::CTAG::AUTOP=N;</p> <p>Example: ED-SYS:FUJITSU::CTAG::AUTOP=N;</p>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab. Set AUTOP to No. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 4

Verify that the autoprovisioning feature is disabled.

TL1	NETSMART 500
RTRV-SYS:TID::CTAG; Example: RTRV-SYS:FUJITSU::CTAG;	In the Current Values area of the Operations dialog box, verify that the value of AUTOP is No. Close the Operations dialog box.

Step 5

Do any of the Tributary shelves in this node require OSC plug-in units?

Note: OSC units (SCMA-SCC4) are installed in Tributary shelves to support interoperability with FLASHWAVE 7500 Extension Configuration NEs.

IF YES:

Proceed to [Step 6](#).

IF NO:

Proceed to [Step 10](#).

Install and Manually Provision OSC Plug-In Units

Step 6

Install the OSC plug-in units in the appropriate shelf slots (9 and/or 11), as required. Refer to [Slot Labels and AIDs](#) for slot locations. For each Synchronization plug-in unit to be installed, do the following:

- a) Inspect the plug-in unit for possible damage or debris.
- b) Slide the unit into the appropriate shelf slot (slot 9 or 11).

Step 7

Create the OSC unit equipment entities and place in service.

TL1	NETSMART 500
ENT-EQPT:TID:AID:CTAG::SCMA-SCC4:: IS; AID: • Refer to the following table. Example: ENT-EQPT:FUJITSU:OS100-9:CTAG:: SCMA-SCC4::IS;	In the shelf OSn graphic view or tree view. Expand the appropriate shelf . Select slot 9 or 11. <div style="background-color: #cccccc; padding: 2px; display: inline-block;">Entity ▶ Operations Dialog</div> The Operations dialog box opens. Click the State tab. Select In Service (ENT-IS). Click the Type tab. Select SCMA-SCC4. Click Modify. Do not close the Operations dialog box.

Table 16: Tributary Shelf OSC Unit Equipment AIDs (Core Configuration)

Equipment Type	AID
SCMA-SCC4	OSn-s <ul style="list-style-type: none"> n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 (shelf) s = 9, 11 (slot)

Step 8

Verify that the OSC unit equipment entities are in service.

TL1	NETSMART 500
RTRV-EQPT:TID:AID:CTAG; AID: <ul style="list-style-type: none"> As identified in previous step ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS100-9:CTAG;</p>	In the Current Values area of the Operations dialog box, verify the equipment state. Close the Operations dialog box.

Step 9

Repeat [Steps 6 through 8](#) for each Tributary shelf that requires OSC plug-in units.

Step 10

Do any of the shelves in this node require Synchronization plug-in units?

Note: Synchronization units support timing and synchronization for Flexponder™ optical line cards. They are generally required in every shelf that include a Flexponder unit. However, the Synchronization unit is optional for shelves that include only single-unit applications of the IFMA-BXC1 Flexponder. If all STS cross-connects are within individual IFMA-BXC1 units (never between units), the Synchronization unit can be omitted from the shelf and timing accuracy will be ±20 ppm for the IFMA-BXC1 units.

If YES:

Proceed to [Step 11](#).

If NO:

Proceed to [Install Intrashelf Fiber-Optic Cables](#).

Install and Manually Provision Synchronization Plug-In Units

Step 11

Install the Synchronization plug-in units in the appropriate shelf slots (10 and/or 12). Refer to [Slot Labels and AIDs](#) for slot locations. For each Synchronization plug-in unit to be installed, do the following:

- a) Inspect the Synchronization plug-in unit for possible damage or debris.
- b) Slide the Synchronization plug-in unit into the Optical shelf slot.

Step 12

Create the Synchronization unit equipment entities and place in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::TCMA-ST31::IS; AID: • Refer to the following table.</p> <p>Example: ENT-EQPT:FUJITSU:OS100-10:CTAG::TCMA-ST31::IS;</p>	<p>In the shelf OSn graphic view or tree view. Expand the appropriate shelf . Select slot 10 or 12.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab. Select In Service (ENT-IS). Click the Type tab. Select TCMA-ST31. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Table 17: Synchronization Unit Equipment AIDs (Core Configuration)

Equipment Type	AID ²¹
TCMA-ST31	<p>OSn-s (WSS Core or 2D-ROADM applications)</p> <ul style="list-style-type: none"> • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 (shelf) • s = 10, 12 (slot) <p>OS1-s (2D-ROADM applications only)</p> <ul style="list-style-type: none"> • s = 10, 12 (slot)

Step 13

Verify that the Synchronization unit equipment entities are in service.

²¹ Slot 10 is for the working equipment. Slot 12 is for the protect equipment.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">As identified in previous stepALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS100-10:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify the equipment state.</p> <p>Close the Operations dialog box.</p>

Step 14

Repeat [Steps 11 through 13](#) for each shelf that requires Synchronization plug-in units.

Step 15

Proceed to [Provision Synchronization](#).

 This procedure is complete.

2.9.4

Provision Synchronization

Synchronization refers to Tributary shelf timing as well as to the primary and secondary timing outputs from a Tributary shelf. Each synchronization facility/mode (OSn-TMGSYS, OSn-TMGOUTP, OSn-TMGOUTS) automatically triggers a major alarm for any OFF NORMAL condition, either FREERUN or HOLDOVER. To minimize OFF NORMAL alarmed conditions, the user must establish a valid synchronization reference priority list (using ED-SYNCLIST) or change the default values for the timing modes (using ED-SYNC).



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default²²</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 2

Provision synchronization at each Tributary shelf that includes Synchronization plug-in units. For more information on synchronization, refer to [TCMA-ST31 \(Flexponder Synchronization Unit\)](#).

²² The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<pre>ED-SYNC:TID:AID:CTAG::: KEYWORD=DOMAIN; AID: • OSn-TMGSYS • OSn-TMGOUTP • OSn-TMGOUTS • OSn (ALL timing reference groups on the shelf) • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 KEYWORD=DOMAIN: • TMGMODE = EXT, INT²³, LINE, MIXED • RVRTV = N • RES = PRS, PRSB, STU, STUB, ST2, ST2B, ST3, ST3B, SMC, SMCB, ST4, ST4B, DUS</pre> <p>Example: ED-SYNC:FUJITSU:OS100-TMGSYS:CTAG::: TMGMODE=INT;</p>	<p>In the tree view, click the Synchronization tab.</p> <p>Expand the appropriate Tributary shelf . Select TMGSYS (SYNC)</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Select the Modify tab. Select TMGMODE.</p> <p>Select the appropriate values from the drop-down menu. Click Modify. Select the Quality Level tab. Select RES.</p> <p>Select the appropriate values from the drop-down menu. Click modify.</p> <p>Do not close the Operations dialog box.</p>

Step 3

Verify synchronization provisioning.

TL1	NETSMART 500
<pre>RTRV-SYNC:TID:AID:CTAG; AID: • OSn-TMGSYS • OSn-TMGOUTP • OSn-TMGOUTS • OSn (ALL timing reference groups on the shelf) • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 • ALL (null)</pre> <p>Example: RTRV-SYNC:FUJITSU:OS100-TMGSYS:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify the synchronization provisioning.</p> <p>Close the Operations dialog box.</p>

Step 4

Create the required T1 clock facilities for the external timing inputs (primary and secondary) and external clock outputs (primary and secondary).

²³ INT is valid TMGMODE for OSn-TMGSYS only.

TL1	NETSMART 500
<pre>ED-T1CLK:TID:AID:CTAG::: KEYWORD=DOMAIN:IS; AID: • OSn-EXTCLKINP • OSn-EXTCLKINS • OSn-EXTCLKOUTP • OSn-EXTCLKOUTS • OSn (ALL timing reference groups on the shelf) • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 KEYWORD=DOMAIN: • LINECDE = AMI, B8ZS • LBO = D1, D2, D3, D4, D5 • OOF = Y, N • FMT = SF, ESF • SYNCMSG²⁷ = Y, N • AISTHQL²⁸ = PRS, PRSB, STU, STUB, ST2, ST2B, ST3 Example: ENT-T1CLK:FUJITSU:OS100-EXTCLKINP: CTAG:::FMT=ESF:IS;</pre>	<p style="text-align: right;">NE ▶ Create</p> <p>The Operations dialog box opens. Click the T1 Clock tab. Select the appropriate values. Click Create.</p> <p>Close the Operations dialog box.</p>

Step 5

Verify provisioning of the DS1 timing facilities.

TL1	NETSMART 500
<pre>RTRV-T1CLK:TID:AID:CTAG; AID: • OSn-EXTCLKINP • OSn-EXTCLKINS • OSn-EXTCLKOUTP • OSn-EXTCLKOUTS • OSn (ALL timing reference groups on the shelf) • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 • ALL (null) Example: RTRV-T1CLK:FUJITSU:OS100-EXTCLKINP:CTAG;</pre>	<p>In the tree view, select the Synchronization tab.</p> <p>Expand the appropriate Tributary shelf. Select the appropriate entity.</p> <p style="text-align: right;">Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the timing provisioning.</p> <p>Close the Properties dialog box.</p>

²⁴ Applies only to outgoing BITS (that is, OSn-EXTCLKOUTP or OSn-EXTCLKOUTS)

²⁵ Applies only to incoming BITS (that is, OSn-EXTCLKINP or OSn-EXTCLKINS)

²⁶ When FMT=SF, the only valid value for SYNCMSG is N.

²⁷ Default value of SYNCMSG is Y when FMT=ESF (N when FMT=SF).

²⁸ Applies only to OSn-EXTCLKOUTP or OSn-EXTCLKOUTS and when SYNCMSG=N.

Step 6

If the timing mode set in [Step 2](#) is EXT, create the required synchronization reference priority lists. A separate list can be created for system timing references (OSn-TMGSYS), the primary external clock output port (OSn-TMGOUTP), and the secondary external clock output port (OSn-TMGOUTS).

A sync list is a prioritized list from 1 to 2 valid timing sources, with the highest priority reference specified first. The list of prioritized entries identified in a single execution of this command defines the complete sync list, replacing the previous list for the specified AID.

The following restrictions apply:

- When the timing mode set with ED-SYNC is EXT, only the external clock AIDs, OSn-EXTCLKINP or OSn-EXTCLKINS, are accepted as reference sources.
- When the timing mode set with ED-SYNC is INT, the ED-SYNCLIST command is not allowed.

TL1	NETSMART 500
<pre>ED-SYNCLIST:TID:AID:CTAG::: KEYWORD=DOMAIN; AID: • OSn-TMGSYS • OSn-TMGOUTP • OSn-TMGOUTS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 KEYWORD=DOMAIN: • LIST = OSn-EXTCLKINP, OSn-EXTCLKINS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 Example: ED-SYNCLIST:FUJITSU:OS100-TMGSYS: CTAG:::LIST=OS100-EXTCLKINP& OS100-EXTCLKINS;</pre>	<p>In the tree view, click the Synchronization tab.</p> <p>Expand the appropriate Tributary shelf.</p> <p>Select the appropriate entity.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>Select the Sync List tab.</p> <p>Select the Set tab.</p> <p>Move the command parameters from the Available list to the Selected list in the order you wish them to appear in the list.</p> <p>Click Set.</p> <p>Do not close the Operations dialog box.</p>

Note: Once the sync lists are created for TMGOUTP and TMGOUTS, the associated TMGOUTP and TMGOUTS alarm conditions (SYNC and FREERUN) should clear.

Step 7

Verify sync list provisioning.

TL1	NETSMART 500
<pre>RTRV-SYNCLIST:TID:AID:CTAG; AID: • OSn-TMGSYS • OSn-TMGOUTP • OSn-TMGOUTS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 • ALL (null) Example: RTRV-SYNCLIST:FUJITSU: OS100-TMGSYS:CTAG;</pre>	<p>In the Current Values area of the Operations dialog box, verify the sync list provisioning.</p> <p>Close the Operations dialog box.</p>

Step 8

Proceed to [Install Intrashelf Fiber-Optic Cables](#).

2.10

Install Intrashelf Fiber-Optic Cables

In this section:

- 2.10.1 Overview Installing Intrashelf Cables Core Configuration
- 2.10.2 Examples of Intrashelf Cabling
- 2.10.3 Installing Intrashelf Cables



Warning: Verify the transmit and receive fibers are connected to the correct ports of the plug-in unit. An incorrect connection can result in dropped traffic or an equipment fault and may damage the laser optics.

2.10.1

Overview Installing Intrashelf Cables Core Configuration

The following figure shows the full complement of intrashelf fiber-optic cables that can be installed in the Main Optical shelf OS1 or Auxiliary Optical shelf OSn (n = 2...4, 25, 26) in WSS Core configurations.




Figure 39: Full Complement of Fiber-Optic Cable Connections for WSS Core Configuration

The following figure shows the full complement of internal fiber-optic cables that can be installed between plug-in units in the 2D-ROADM configuration. Typically, only some of these cables are installed, as shown by examples in [Examples of Intrashelf Cabling](#).




Figure 40: Full Complement of Fiber-Optic Cable Connections for 2D-ROADM Configuration

The procedure in [Installing Intrashelf Cables](#) will guide you in installing only those cables that are appropriate for the plug-in units installed in the shelf. The procedure is performed once for the Main Optical shelf OS1 and then repeated for each Auxiliary Optical shelf OSn (n = 2...4, 25, 26), as required.

2.10.2 Examples of Intrashelf Cabling

Terminal Node WSS Core Configuration

Note: Refer also to [About System Turn-up Core Configuration](#) .

The following figure shows the fiber-optic cable connections for a terminal node supporting adds and drops to WDM facility OS1-1-PE1.




Figure 41: Cables for Terminal Node Supporting OS1-1-PE1 (WDM) Adds and Drops—Main Optical Shelf OS1, WSS Core Configuration

The following figure shows the fiber-optic cable connections for a terminal node supporting adds and drops to WDM facility OS1-19-PE1.




Figure 42: Cables for Terminal Node Supporting OS1-19-PE1 (WDM) Adds and Drops—Main Optical Shelf OS1, WSS Core Configuration

Terminal Node 2D-ROADM Configuration

Note: Refer also to [About System Turn-up Core Configuration](#).

The following figure shows the fiber-optic cable connections for a terminal node supporting adds and drops to WDM facility OS1-1-PE1.




Figure 43: Cables for Terminal Node Supporting OS1-1-PE1 (WDM) Adds and Drops—Optical Shelf OS1, 2D-ROADM Configuration

The following figure shows the fiber-optic cable connections for a terminal node supporting adds and drops to WDM facility OS1-19-PE1.




Figure 44: Cables for Terminal Node Supporting OS1-19-PE1 (WDM) Adds and Drops—Optical Shelf OS1, 2D-ROADM Configuration

2-Degree Add/Drop Node WSS Core Configuration

The following figure shows the fiber-optic cable connections for a node supporting adds and drops to WDM facilities OS1-1-PE1 and OS1-19-PE1.

Note: Refer also to [About System Turn-up Core Configuration](#).




Figure 45: Cables for 2-Degree Add/Drop Node–Main Optical Shelf OS1, WSS Core Configuration

2-Degree Add/Drop Node 2D-ROADM Configuration

The following figure shows the fiber-optic cable connections for a node supporting adds and drops to WDM facilities OS1-1-PE1 and OS1-19-PE1.

Note: Refer also to [About System Turn-up Core Configuration](#).




Figure 46: Cables for 2-Degree Add/Drop Node-Optical Shelf OS1, 2D-ROADM Configuration

Express Node

The following figure shows the fiber-optic cable connections for an Express node supporting pass-through traffic between WDM facilities OS1-1-PE1 and OS1-19-PE1.




Figure 47: Cables for 2-Degree Express Node–Main Optical Shelf OS1

Note: Refer also to [About System Turn-up Core Configuration](#) .

HUB Node

In a HUB node, each Optical shelf can be provisioned to support one or two network degrees and each network degree can be provisioned to support add/drop and/or hubbing. The following figure shows the intrashelf fiber-optic cable connections for an Optical shelf that supports two network degrees with add/drop and hubbing for both degrees.




Figure 48: Cables for Add/Drop HUB Nodes–Optical Shelves

The following figures shows the intrashelf fiber-optic cable connections for Optical shelves that supports one network degrees with add/drop and hubbing.




Figure 49: Cables for Add/Drop HUB Nodes–Optical Shelf with Slot-1 WDM Facility




Figure 50: Cables for Add/Drop HUB Nodes–Optical Shelf Slot-19 WDM Facility

HUB nodes can include network degrees that does not support add/drop and/or hubbing. Network degrees that does not support add/drop does not include the MDMA-RMC1 (Mux/Demux unit) and associated cabling. Network degrees that does not support hubbing, do not include the SFMA-CDC1 (WSS HUB Switch unit) and associated cabling.

In addition to the cabling shown in the preceding three figures, HUB nodes require connections between WSS HUB Switch units on different Optical shelves. These cabling connections are not included in this procedure (refer to [Provision HUB Interconnections](#)).


ILA Node

Procedures for ILA shelf turn-up are presented in [ILA Node Turn-Up](#). For ILA Shelf fiber-optic cable connections, refer to [Install Intrashelf Fiber-Optic Cables](#).

2.10.3

Installing Intrashelf Cables

The following flowcharts (WSS Core Configuration and 2D-ROADM Configuration) show how these subtasks are used to install intrashelf cables.



m1714us_4

Figure 51: Installing Intrashelf Cables (WSS Core Configuration) (Subprocedure Flowchart)




Figure 52: Installing Intrashelf Cables (2D-ROADM Configuration) (Subprocedure Flowchart)

Figure 39 shows the full complement of intrashelf fiber-optic cables that can be installed in an Optical shelf. Typically, depending on the node application, only some of these cables are installed. The cables required for some example applications are illustrated in [Examples of Intrashelf Cabling](#). This procedure provides guidance for installing only those cables that are appropriate for the Optical shelves and plug-in units installed at the node. The procedure is performed once for the Main Optical shelf OS1 and then repeated for each Auxiliary Optical shelf OSn (n = 2...4, 25, 26), as required.



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).



Warning: Verify the transmit and receive fibers are connected to the correct ports of the plug-in unit. An incorrect connection can result in dropped traffic or an equipment fault and may damage the laser optics.



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to [Fiber Cable Handling](#).

Install intrashelf fiber-optic cables as follows:

Step 1

Start with the Main Optical shelf OS1.

Note: The following steps are performed once for the Main Optical shelf OS1 and then repeated for the Auxiliary Optical shelves OS n ($n = 2...4, 25, 26,$) as required.

Step 2

Is an amplifier (APMA-xxxx) plug-in unit installed in slot 1 of the shelf?

IF YES:

Proceed to [Step 3](#).

IF NO:

Proceed to [Step 4](#).

Step 3

Is this a WSS Core Configuration NE?

IF YES:

Proceed to [Step 5](#) (WSS Core Configuration).

IF NO:

Proceed to [Step 8](#) (2D-ROADM Configuration).

Step 4

Is this a WSS Core Configuration NE?

If YES:

Proceed to [Step 16](#) (WSS Core Configuration).

If NO:

Proceed to [Step 10](#) (2D-ROADM Configuration).

Install Basic Slot-1 Amplifier Connections WSS Core Configuration

If an amplifier (APMA-xxxx) plug-in unit is installed in slot 1, three LC-LC fiber-optic cables must be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 53: Basic Slot-1 Amplifier Connections (WSS Core Configuration)

Table 18: Basic Slot-1 Amplifier Connections (WSS Core Configuration)

From Amplifier (APMA-xxxx)		To WSS Core Switch (SFMA-CMC1)		To OSC Unit (SCMA-SCC4)	
Shelf Slot	Connector	Shelf Slot	Connector	Shelf Slot	Connector
1	TAMP IN (APMA-xxC1) TAMP IN-1 (APMA-xxU1)	3	OPT OUT	n/a	
1	OSC IN	n/a		9	NTWK OUT-1
1	OSC OUT			9	NTWK IN-1

Step 5

Obtain and clean three LC-LC fiber-optic cables.

Step 6

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 53](#) and listed in the preceding table.

Step 7

Is a Mux/Demux (MDMA-RMC1) plug-in unit installed in slot 5 of the shelf?

If YES:

Proceed to [Step 11](#).

If NO:

Proceed to [Step 13](#).

**Install Basic Slot-1 Amplifier Connections
 2D-ROADM Configuration**

If an amplifier (APMA-xxxx) plug-in unit is installed in slot 1, four LC-LC fiber-optic cables must also be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 54: Basic Slot-1 Amplifier Connections (2D-ROADM Configuration)

Table 19: Basic Slot-1 Amplifier Connections (2D-ROADM Configuration)

From Amplifier (APMA-xxxx)		To 2D-ROADM Unit (SFMA-RDC1)		To OSC Unit (SCMA-SCC4)	
Shelf Slot	Connector	Shelf Slot	Connector	Shelf Slot	Connector
1	TAMP IN (APMA-xxC1) TAMP IN-1 (APMA-xxU1)	3	OPT OUT	n/a	
1	RAMP OUT-2	3	DMUX IN	n/a	
1	OSC IN	n/a		9	NTWK OUT-1
1	OSC OUT	n/a		9	NTWK IN-1

Step 8

Obtain and clean four LC-LC fiber-optic cables.

Step 9

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 54](#) and listed in the preceding table.

Step 10

Is an amplifier (APMA-xxxx) plug-in unit installed in slot 19 of the shelf?

IF YES:

Proceed to [Step 20](#).

IF NO:

Proceed to [Install LAMs and MPO Connections](#).

Install Connections to Slot-5 Mux/Demux Unit

If a Mux/Demux (MDMA-RMC1) plug-in unit is installed in slot 5, two LC-LC fiber-optic cables must also be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 55: Slot-5 Mux/Demux Connections

Table 20: Slot-5 Mux/Demux Connections

From Amplifier (APMA-xxxx)		From WSS Core Switch (SFMA-CMC1)		To Mux/Demux (MDMA-RMC1)	
Shelf Slot	Connector	Shelf Slot	Connector	Shelf Slot	Connector
n/a		3	PORT IN-1	5	OPT OUT
1	RAMP OUT-2	n/a		5	OPT IN

Step 11

Obtain and clean two LC-LC fiber-optic cables.

Step 12

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 55](#) and listed in the preceding table.

Step 13

Is a WSS HUB Switch (SFMA-CDC1) plug-in unit installed in slot 7 of the shelf?

IF YES:

Proceed to [Step 14](#).

IF NO:

Proceed to [Step 16](#).

Install Connections to Slot-7 WSS HUB Switch

If a WSS HUB Switch (SFMA-CDC1) plug-in unit is installed in slot 7, one LC-LC fiber-optic cable must also be installed as shown in the following figure. The following table lists the connections for the cable.




Figure 56: Slot-7 WSS HUB Switch Connections

Table 21: Slot-7 WSS HUB Switch Connections

From Amplifier (APMA-xxxx)		To WSS HUB Switch (SFMA-CDC1)	
Shelf Slot	Connector	Shelf Slot	Connector
1	RAMP OUT-3	7	OPT IN

Step 14

Obtain and clean one LC-LC fiber-optic cable.

Step 15

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 56](#) and listed in the preceding table.

Step 16

Is an amplifier (APMA-xxxx) plug-in unit installed in slot 19 of the shelf?

IF YES:

Proceed to [Step 17](#).

IF NO:

Proceed to [Step 31](#).

Install Basic Slot-19 Amplifier Connections

WSS Core Configuration

If an amplifier (APMA-xxxx) plug-in unit is installed in slot 19, three LC-LC fiber-optic cables must also be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 57: Basic Slot-19 Amplifier Connections (WSS Core Configuration)

Table 22: Basic Slot-19 Amplifier Connections (WSS Core Configuration)

From Amplifier (APMA-xxxx)		To WSS Core Switch (SFMA-CMC1)		To OSC Unit (SCMA-SCC4)	
Shelf Slot	Connector	Shelf Slot	Connector	Shelf Slot	Connector
19	TAMP IN (APMA-xxC1) TAMP IN-1 (APMA-xxU1)	17	OPT OUT	n/a	
19	OSC IN	n/a		11	NTWK OUT-1
19	OSC OUT	n/a		11	NTWK IN-1

Step 17

Obtain and clean three LC-LC fiber-optic cables.

Step 18

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 57](#) and listed in the preceding table.

Step 19

Is a Mux/Demux (MDMA-RMC1) plug-in unit installed in slot 15 of the shelf?

IF YES:

Proceed to [Step 23](#).

IF NO:

Proceed to [Step 25](#).

Install Basic Slot-19 Amplifier Connections 2D-ROADM Configuration

If an amplifier (APMA-xxxx) plug-in unit is installed in slot 19, four LC-LC fiber-optic cables must also be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 58: Basic Slot-19 Amplifier Connections (2D-ROADM Configuration)

Table 23: Basic Slot-19 Amplifier Connections (2D-ROADM Configuration)

From Amplifier (APMA-xxxx)		To 2D-ROADM Unit (SFMA-RDC1)		To OSC Unit (SCMA-SCC4)	
Shelf Slot	Connector	Shelf Slot	Connector	Shelf Slot	Connector
19	TAMP IN (APMA-xxC1) TAMP IN-1 (APMA-xxU1)	17	OPT OUT	n/a	
19	RAMP OUT-2	17	DMUX IN	n/a	
19	OSC IN	n/a		11	NTWK OUT-1
19	OSC OUT	n/a		11	NTWK IN-1

Step 20

Obtain and clean four LC-LC fiber-optic cables.

Step 21

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 58](#) and listed in the preceding table.

Step 22

Are two amplifier (APMA-xxxx) plug-in units installed in the shelf (one in slot 1 and another in slot 19)?

IF YES:

Proceed to [Step 32](#).

IF NO:

Proceed to [Install LAMs and MPO Connections](#).

Install Connections to Slot-15 Mux/Demux Unit

If a Mux/Demux (MDMA-RMC1) plug-in unit is installed in slot 15, two LC-LC fiber-optic cables must also be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 59: Slot-15 Mux/Demux Connections

Table 24: Slot-15 Mux/Demux Connections

From Amplifier (APMA-xxxx)		From WSS Core Switch (SFMA-CMC1)		To Mux/Demux (MDMA-RMC1)	
Shelf Slot	Connector	Shelf Slot	Connector	Shelf Slot	Connector
n/a		17	PORT IN-1	15	OPT OUT
19	RAMP OUT-2	n/a		15	OPT IN

Step 23

Obtain and clean two LC-LC fiber-optic cables.

Step 24

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 59](#) and listed in the preceding table.

Step 25

Is a WSS HUB Switch (SFMA-CDC1) plug-in unit installed in slot 13 of the shelf?

IF YES:

Proceed to [Step 26](#).

IF NO:

Proceed to [Step 28](#).

Install Connections to Slot-13 WSS HUB Switch

If a WSS HUB Switch (SFMA-CDC1) plug-in unit is installed in slot 13, one LC-LC fiber-optic cable must also be installed as shown in the following figure. The following table lists the connections for the cable.




Figure 60: Slot-13 WSS HUB Switch Connections

Table 25: Slot-13 WSS HUB Switch Connections

From Amplifier (APMA-xxxx)		To WSS HUB Switch (SFMA-CDC1)	
Shelf Slot	Connector	Shelf Slot	Connector
19	RAMP OUT-3	13	OPT IN

Step 26

Obtain and clean one LC-LC fiber-optic cable.

Step 27

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 60](#) and listed in the preceding table.

Step 28

Are two amplifier (APMA-xxxx) plug-in units installed in the shelf (one in slot 1 and another in slot 19)?

IF YES:

Proceed to [Step 29](#).

IF NO:

Proceed to [Step 31](#).

Install Pass-Through Cables, If Required

WSS Core Configuration

If two amplifier (APMA-xxxx) plug-in units are installed in the shelf (slots 1 and/or 19), two LC-LC fiber-optic cables must also be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 61: Pass-Through Cable Connections (WSS Core Configuration)

Table 26: Pass-Through Cable Connections (WSS Core Configuration)

Amplifier (APMA-xxxx)		WSS Core Switch (SFMA-CMC1)	
Shelf Slot	Connector	Shelf Slot	Connector
1	RAMP OUT-1	17	PORT IN-9
19	RAMP OUT-1	3	PORT IN-9

Step 29

Obtain and clean two LC-LC fiber-optic cables.

Step 30

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 61](#) and listed in the preceding table.

Step 31

Is the node a HUB node (including one or more Auxiliary Optical shelves)?

IF YES:

Repeat this procedure starting from [Step 2](#) for each Auxiliary Optical shelf OSn (n = 2...4, 25, 26). Then proceed to [Install LAMs and MPO Connections](#).

IF NO:

Proceed to [Install LAMs and MPO Connections](#).

Install Pass-Through Cables, If Required

2D-ROADM Configuration

If two amplifier (APMA-xxxx) plug-in units are installed in the shelf (slots 1 and/or 19), two LC-LC fiber-optic cables must also be installed as shown in the following figure. The following table lists the connections for each cable.




Figure 62: Pass-Through Cable Connections (2D-ROADM Configuration)

Table 27: Pass-Through Cable Connections (2D-ROADM Configuration)

Amplifier (APMA-xxxx)		2D-ROADM Unit (SFMA-RDC1)	
Shelf Slot	Connector	Shelf Slot	Connector
1	RAMP OUT-3	17	THRU IN
19	RAMP OUT-3	3	THRU IN

Step 32

Obtain and clean two LC-LC fiber-optic cables.

Step 33

Connect the cable ends to the appropriate plug-in units and connectors as shown in [Figure 62](#) and listed in the preceding table.

Step 34

Proceed to [Install LAMs and MPO Connections](#).

 This procedure is complete.

2.11 Install LAMs and MPO Connections

In this section:

- 2.11.1 Install LAMs and MPO Connections to Mux/Demux Units (WSS Core Configuration)
- 2.11.2 Install LAMs and MPO Connections to 2D-ROADM Units (2D-ROADM Configuration)

The lambda access module (IPMA-LAM5) is a passive plug-in unit that is used to optically interconnect the MDMA-RMC1 or SFMA-RDC1 unit (in the Optical shelf) to optical line cards (in the Tributary shelf).

For WSS Core Configuration nodes, proceed to [Install LAMs and MPO Connections to Mux/Demux Units \(WSS Core Configuration\)](#). For 2D-ROADM Configuration nodes, proceed to [Install LAMs and MPO Connections to 2D-ROADM Units \(2D-ROADM Configuration\)](#).

2.11.1 Install LAMs and MPO Connections to Mux/Demux Units (WSS Core Configuration)

Each LAM plug-in unit is located in a LAS shelf. LAS shelf LAS-OS1 is associated with the main Optical shelf OS1. If required, another LAS shelf (LAS-OSn) is associated with each Auxiliary Optical shelf OSn (n = 2...4, 25, 26) (HUB nodes only).

Each LAM provides one MPO connector (OPT MAIN) and eight LC-type fiber-optic cable connectors (PORT1...PORT8) that are used to either add or drop eight channels to/from a WDM facility.

The following figure shows the MPO-to-MPO cable interconnections between Mux/Demux plug-in units in an Optical shelf and LAM plug-in units in the associated LAS shelf.

From the following figure, observe the following:

- WDM facilities are associated with LAMs as follows:
 - LAMs on the left side of LAS-OSn support WDM facility OSn-1-PE1 (n = 1...4, 25, 26)
 - LAMs on the right side of LAS-OSn support WDM facility OSn-19-PE1 (n = 1...4, 25, 26)
- Each LAM supports eight channels: 1...8, 9...16, 17...24, 25...32, or 33...40
- Each LAM either adds or drops the eight channels




Figure 63: MPO Cable Connections to Shelf LAS-OSn (WSS Core Configuration)

The following table identifies the LAMs needed to add or drop each WDM channel.

Table 28: LAMs Required to Add/Drop WDM Channel (WSS Core Configuration)

WDM -Facility ²⁹	Add/Drop	Required LAMs (Identified by LAS Shelf Slot Name)					
		LAS Shelf	Channels1...8	Channels9...16	Channels17...24	Channels25...32	Channels33...40
OSn-1-PE1	Add	LAS-OSn	IPMA-9	IPMA-7	IPMA-5	IPMA-3	IPMA-1
	Drop		IPMA-10	IPMA-8	IPMA-6	IPMA-4	IPMA-2
OSn-19-PE1	Add		IPMA-12	IPMA-14	IPMA-16	IPMA-18	IPMA-20
	Drop		IPMA-11	IPMA-13	IPMA-15	IPMA-17	IPMA-19



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).

Step 1

Consult network design specifications to determine the shelf and slot location for each LAM (IPMA-LAM5) to be installed.

Step 2

For each uninstalled LAM, do the following:

Step 3

- a) Inspect the LAM for possible damage or debris.
- b) Insert the LAM in the appropriate slot of the appropriate LAS shelf.
- c) Referring to the following table, identify the MDMA-RMC1 plug-in unit and connector that supports the LAM.
- d) Using an MPO-to-MPO fiber-optic ribbon cable, physically connect OPT MAIN of the LAM to the appropriate MDMA-RMC1 plug-in unit connector.

²⁹ OSn refers to the Optical shelf, n = 1...4, 25, 26.

Table 29: MPO-to-MPO Cable Connections to LAS Shelves (WSS Core Configuration)

From LAM			To MDMA-RMC1		
Shelf ³⁰	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
LAS-OSn	IPMA-1	OPT MAIN	OSn	5	MUX IN 33-40
	IPMA-2	OPT MAIN			DMUX OUT 33-40
	IPMA-3	OPT MAIN			MUX IN 25-32
	IPMA-4	OPT MAIN			DMUX OUT 25-32
	IPMA-5	OPT MAIN			MUX IN 17-24
	IPMA-6	OPT MAIN			DMUX OUT 17-24
	IPMA-7	OPT MAIN			MUX IN 9-16
	IPMA-8	OPT MAIN			DMUX OUT 9-16
	IPMA-9	OPT MAIN			MUX IN 1-8
	IPMA-10	OPT MAIN			DMUX OUT 1-8
LAS-OSn	IPMA-11	OPT MAIN	OSn	15	DMUX OUT 1-8
	IPMA-12	OPT MAIN			MUX IN 1-8
	IPMA-13	OPT MAIN			DMUX OUT 9-16
	IPMA-14	OPT MAIN			MUX IN 9-16
	IPMA-15	OPT MAIN			DMUX OUT 17-24
	IPMA-16	OPT MAIN			MUX IN 17-24
	IPMA-17	OPT MAIN			DMUX OUT 25-32
	IPMA-18	OPT MAIN			MUX IN 25-32
	IPMA-19	OPT MAIN			DMUX OUT 33-40
	IPMA-20	OPT MAIN			MUX IN 33-40

Step 4

Proceed to [Connect DCMs or Install Loopback Cables](#).

2.11.2

Install LAMs and MPO Connections to 2D-ROADM Units (2D-ROADM Configuration)

Each LAM plug-in unit is located in LAS shelf LAS-OS1 which is associated with the optical shelf OS1.

³⁰ OSn refers to the Optical shelf, n = 1...4, 25, 26.

Each LAM provides one MPO connector (OPT MAIN) and eight LC-type fiber-optic cable connectors (PORT1...PORT8) that are used to either add or drop eight channels to/from a WDM facility.

The following figure shows the MPO-to-MPO cable interconnections between 2D-ROADM plug-in units in the optical shelf and LAM plug-in units in the LAS shelf.

From the following figure, observe the following:

- WDM facilities are associated with LAMs as follows:
 - LAMs on the left side of LAS-OS1 support WDM facility OS1-1-PE1
 - LAMs on the right side of LAS-OS1 support WDM facility OS1-19-PE1
- Each LAM supports eight channels: 1...8, 9...16, 17...24, 25...32, or 33...40
- Each LAM either adds or drops the eight channels




Figure 64: MPO Cable Connections to Shelf LAS-OS1 (2D-ROADM Configuration)

The following table identifies the LAMs needed to add or drop each WDM channel.

Table 30: LAMs Required to Add/Drop WDM Channel (2D-ROADM Configuration)

WDM -Facility	Add/Drop	Required LAMs (Identified by LAS Shelf Slot Name)					
		LAS Shelf	Channels1 ...8	Channels9 ...16	Channels1 7...24	Channels2 5...32	Channels3 3...40
OS1-1-PE1	Add	LAS-OS1	IPMA-9	IPMA-7	IPMA-5	IPMA-3	IPMA-1
	Drop		IPMA-10	IPMA-8	IPMA-6	IPMA-4	IPMA-2
OS1-19-PE1	Add		IPMA-12	IPMA-14	IPMA-16	IPMA-18	IPMA-20
	Drop		IPMA-11	IPMA-13	IPMA-15	IPMA-17	IPMA-19



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).

Step 1

Consult network design specifications to determine the shelf and slot location for each LAM (IPMA-LAM5) to be installed.

Step 2

For each uninstalled LAM, do the following:

Step 3

- a) Inspect the LAM for possible damage or debris.
- b) Insert the LAM in the appropriate slot of the LAS shelf.
- c) Using the following table, identify the SFMA-RDC1 plug-in unit and connector that supports the LAM.
- d) Using an MPO-to-MPO fiber-optic ribbon cable, physically connect OPT MAIN of the LAM to the appropriate SFMA-RDC1 plug-in unit connector.

Table 31: MPO-to-MPO Cable Connections to LAS Shelf (2D-ROADM Configuration)

From LAM			To MDMA-RMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
LAS-OS1	IPMA-1	OPT MAIN	OS1	3	MUX IN 33-40
	IPMA-2	OPT MAIN			DMUX OUT 33-40
	IPMA-3	OPT MAIN			MUX IN 25-32
	IPMA-4	OPT MAIN			DMUX OUT 25-32
	IPMA-5	OPT MAIN			MUX IN 17-24
	IPMA-6	OPT MAIN			DMUX OUT 17-24
	IPMA-7	OPT MAIN			MUX IN 9-16
	IPMA-8	OPT MAIN			DMUX OUT 9-16
	IPMA-9	OPT MAIN			MUX IN 1-8
	IPMA-10	OPT MAIN			DMUX OUT 1-8
LAS-OS1	IPMA-11	OPT MAIN	OS1	17	DMUX OUT 1-8
	IPMA-12	OPT MAIN			MUX IN 1-8
	IPMA-13	OPT MAIN			DMUX OUT 9-16
	IPMA-14	OPT MAIN			MUX IN 9-16
	IPMA-15	OPT MAIN			DMUX OUT 17-24
	IPMA-16	OPT MAIN			MUX IN 17-24
	IPMA-17	OPT MAIN			DMUX OUT 25-32
	IPMA-18	OPT MAIN			MUX IN 25-32
	IPMA-19	OPT MAIN			DMUX OUT 33-40
	IPMA-20	OPT MAIN			MUX IN 33-40

Step 4

Proceed to [Connect DCMs or Install Loopback Cables](#).

2.12 Connect DCMs or Install Loopback Cables

In this section:

- 2.12.1 Overview of DCM or Loopback Cabling Core Configuration
- 2.12.2 Connect Amplifiers to DCMs or Install Loopback Cables

As explained in [Overview of DCM or Loopback Cabling Core Configuration](#), each amplifier (APMA-xxxx) plug-in unit must be connected to a Dispersion Compensation Module (DCM), or a loopback fiber must be installed in place of the DCM. The procedure in [Connect Amplifiers to DCMs or Install Loopback Cables](#), guides you in connecting DCMs and installing loopback cables as required.

Before performing the procedure in [Connect Amplifiers to DCMs or Install Loopback Cables](#), you should know whether or not a DCM is required for each amplifier (APMA-xxxx) plug-in unit in the node. For each amplifier that requires a DCM, you should also know where it has been installed. If uncertain, contact your Network Design/ Planning organization.

2.12.1 Overview of DCM or Loopback Cabling Core Configuration

Generally, as shown in the following figure, a Dispersion Compensation Module (DCM) is used with each amplifier (APMA-xxxx) plug-in unit to overcome the effects of chromatic dispersion. However, depending on network design, the DCM is not always required.




Figure 65: Fiber-Optic Cable Connections to DCMs

If a DCM is not used, a loopback fiber-optic cable should be installed in place of the DCM. the following figure shows an example where loopback cables are used with both amplifiers.

Note: If the amplifier is unit type APMA-L2C1 or APMA-ULC1, an 11 dB optical attenuator, part number 37-424-612, is required in the loopback.




Figure 66: Fiber-Optic Loopback Cable Connections


Depending on network design, one amplifier may require a DCM, and the other may not. In a HUB node, up to eight amplifiers may be equipped (two in each Optical shelf). Each amplifier may or may not use a DCM.

The steps in [Connect Amplifiers to DCMs or Install Loopback Cables](#), should be performed for the Main Optical shelf OS1 and then repeated if the Auxiliary Optical shelves OSn (n = 2...4, 25, 26) are used.

2.12.2

Connect Amplifiers to DCMs or Install Loopback Cables

The following figure shows a flowchart of subtasks that connects DCMs or installs loopback cables.



mt1714ut_4

Figure 67: Connect Amplifiers to DCMs or Install Loopback Cables (Subprocedure Flowchart)



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to [Fiber Cable Handling](#).

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT/(Route66K)</td> <td>Password: ROOT/(Route66K)</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default³¹</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT/(Route66K)	Password: ROOT/(Route66K)	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT/(Route66K)	Password: ROOT/(Route66K)														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

³¹ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

Step 2

Start with the Main Optical shelf OS1.

Note: The following steps are performed once for the Main Optical shelf OS1 and then repeated for the each Auxiliary Optical shelf OSn (n = 2...4, 25, 26), as required.

Step 3

Is an amplifier (APMA-xxxx) plug-in unit installed in slot 1 of the shelf?

If YES:

Proceed to [Step 4](#).

If NO:

Proceed to [Step 12](#).

Step 4

Does this amplifier require connection to a DCM?

If YES:

Proceed to [Step 5](#).

If NO:

Proceed to [Step 10](#).

Connect DCM to Slot-1 Amplifier

Step 5

Obtain and clean two LC-SC fiber-optic cables.

Step 6

Connect the cable ends to the plug-in units and connectors listed in the following table.

Table 32: Slot-1 Amplifier-to-DCM Fiber-Optic Cable Connections

From APMA-xxxx		To DCM ³²	
Shelf Slot	Connector	Shelf Slot	Connector
1	to DCF	DCM-1	OPT In
1	from DCF	DCM-1	OPT Out

³² DCMs are housed in the SFD3 dispersion compensation shelf (FC9512SFD3).

Record DCM Inventory Information for Slot-1 Amplifier

Step 7

Enter inventory information for the DCM module connected to the slot-1 amplifier.

TL1	NETSMART 500
<p>ED-DCM:TID:AID:CTAG::: KEYWORD=DOMAIN; AID:</p> <ul style="list-style-type: none"> OS1-1, OS2-1, OS3-1, OS4-1, OS25-1, OS26-1 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> Refer to the following table. <p>Example: ED-DCM:FUJITSU:OS1-1:CTAG::: DCM1VENDID=FC9682F220-01, DCM1SERIALNO=1234567, DCM3DOM=07.07, DCM3CLEI=ABCD123456, DCM3USI=ABCDEFGH12345678MNOPQRST;</p>	<p>In the tree view, select the Equipment tab.</p> <p>Expand the appropriate Optical shelf.</p> <p>Select amplifier unit in slot 1.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>Click the DCM tab.</p> <p>In the Command Parameters area, enter the DCM inventory information, per your local practice.</p> <p>Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Table 33: ED-DCM Keyword and Domain Input Parameters

Keyword	Domain (Default in Bold)	Description
DCMxVENDID (x=1...3)	FCnnnnnnnn-mm	DCM vendor ID, where FCnnnnnnnn is the 10-character FC code and mm is the 2-character hardware revision number (13-character string) Example: FC9682F220-01
DCMxSERIALNO (x=1...3)	nnnnnnnn	DCM equipment unit serial number (up to a 7-character string)
DCMxDOM (x=1...3)	yy.mm	DCM date of manufacture, where yy = last two digits of the year and mm = 01...12 (5-character string)
DCMxCLEI (x=1...3)	nnnnnnnnnn	COMMON LANGUAGE® Equipment Identifier (CLEI™) (10-character string) Note: CLEI attribute is associated with the shelf and provides inventory information about the plug-in unit.
DCMxUSI (x=1...3)	nnnnnnnnnnnnnnnnnnnnnnnnnnnnnn nnnnnn	DCM unique serial identifier (USI) (25-character string)

Step 8

Verify the DCM inventory information.

TL1	NETSMART 500
RTRV-DCM:TID:AID:CTAG; AID: • As identified in previous step • ALL (null) <i>Example:</i> RTRV-DCM:FUJITSU:OS1-1:CTAG;	Verify that the values shown in the Current Values area of the Operations dialog are correct. Close the Operations dialog box.

Step 9
 Proceed to [Step 13](#).

Install Slot-1 Loopback Cable

Step 10
 Obtain and clean one LC-LC fiber-optic cable.

Step 11
 Is the amplifier in slot 1 type APMA-L2C1 or APMA-ULC1?

If YES: from DCF

Connect a 12 dB optical attenuator, part number 956-130-5x12, to the **from DCF** connector of the amplifier plug-in unit. Then proceed to [Step 12](#).

If NO:

An optical attenuator is not required. Proceed to [Step 12](#).

Step 12
 Connect the cable ends to the plug-in unit connectors listed in the following table.

Table 34: Slot-1 Amplifier Loopback Cable Connections

From APMA-xxxx		To APMA-xxxx	
Shelf Slot	Connector	Shelf Slot	Connector
1	to DCF	1	from DCF

Step 13

Is an amplifier (APMA-xxxx) plug-in unit installed in slot 19 of the shelf?

If YES:

Proceed to [Step 14](#).

If NO:

Proceed to [Step 23](#).

Step 14

Does this amplifier require connection to a DCM?

If YES:

Proceed to [Step 15](#).

If NO:

Proceed to [Step 20](#).

Connect DCM to Slot-19 Amplifier

Step 15

Obtain and clean two LC-SC fiber-optic cables.

Step 16

Connect the cable ends to the plug-in units and connectors listed in the following table.

Table 35: Slot-19 Amplifier-to-DCM Fiber-Optic Cable Connections

From APMA-xxxx		To DCM ³³	
Shelf Slot	Connector	Shelf Slot	Connector
19	to DCF	DCM-2	OPT In
19	from DCF	DCM-2	OPT Out

Record DCM Inventory Information for Slot-19 Amplifier

Step 17

Enter inventory information for the DCM module connected to the slot-19 amplifier.

³³ DCMs are housed in the SFD3 dispersion compensation shelf (FC9512SFD3).

TL1	NETSMART 500
<pre>ED-DCM:TID:AID:CTAG::: KEYWORD=DOMAIN; AID: • OS1-19, OS2-19, OS3-19, OS4-19, OS25-19, OS26-19 KEYWORD=DOMAIN: • Refer to Table 33.</pre> <p>Example: ED-DCM:FUJITSU:OS1-19:CTAG::: DCM1VENDID=FC9682F220-01, DCM1SERIALNO=1234567, DCM3DOM=07.07, DCM3CLEI=ABCD123456, DCM3USI=ABCDEFGH12345678MNOPQRST;</p>	<p>In the tree view, select the Equipment tab. Expand the appropriate Optical shelf. Select amplifier unit in slot 19.</p> <div style="border: 1px solid #ccc; background-color: #f0f0f0; padding: 2px; display: inline-block;"> Entity ▸ Operations Dialog </div> <p>The Operations dialog box opens. Click the DCM tab.</p> <p>In the Command Parameters area, enter the DCM inventory information, per your local practice. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 18
Verify the DCM inventory information.

TL1	NETSMART 500
<pre>RTRV-DCM:TID:AID:CTAG; AID: • As identified in previous step • ALL (null)</pre> <p>Example: RTRV-DCM:FUJITSU:OS1-19:CTAG;</p>	<p>Verify that the values shown in the Current Values area of the Operations dialog are correct.</p> <p>Close the Operations dialog box.</p>

Step 19
Proceed to [Step 23](#).

Install Slot-19 Loopback Cable

Step 20
Obtain and clean one LC-LC fiber-optic cable.

Step 21
Is the amplifier in slot 1 type APMA-L2C1 or APMA-ULC1?

If YES: from DCF

Connect a 12 dB optical attenuator, part number 956-130-5x12, to the **from DCF** connector of the amplifier plug-in unit. Then proceed to [Step 22](#).

If NO:

An optical attenuator is not required. Proceed to [Step 22](#).

Step 22

Connect the cable ends to the plug-in unit connectors listed in the following table.

Table 36: Slot-19 Amplifier Loopback Cable Connections

From APMA-xxxx		To APMA-xxxx	
Shelf Slot	Connector	Shelf Slot	Connector
19	to DCF	19	from DCF

Step 23

Is the node a HUB node (including one or more Auxiliary Optical shelves)?

IF YES:

Repeat this subprocedure, starting from [Step 3](#), for each Auxiliary Optical shelf OSn (n = 2...4, 25, 26). Then proceed to [Provision HUB Interconnections](#).

IF NO:

Proceed to [Step 24](#).

Step 24

Are all NEs in the network turned up?


IF YES:

Proceed to [Make Network Connections](#).

Note: You have completed the turn-up for the node, but have not connected it to the network. Network connections are made after all the nodes have been turned up (see [Figure 2](#)).

IF NO:

Repeat the turn-up procedures, starting from [Verify Shelf Labeling](#), [Verify LAN and RICC Cable Connections](#), [Apply Power](#), and [Install Fan Units](#), for the next NE.

 This procedure is complete.

2.13

Provision HUB Interconnections

In this section:

- 2.13.1 Provision HUB Interconnections—Symmetric HUB Node
- 2.13.2 Provision HUB Interconnections—Asymmetric HUB Node

HUB connections are required to pass signals between network degrees residing on different optical shelves. Each HUB connection involves a physical part (an LC-LC fiber-optic cable connection) and a software part (equipment connection), informing the system of the physical connection. The FLASHWAVE 7500 Core Configuration system supports the following schemes for HUB interconnection:

- **Symmetric HUB Interconnection**—HUB connections follow a fixed, predetermined pattern and equipment connections are automatically created by the system software.
- **Asymmetric HUB Interconnection**—HUB connections do not follow a predetermined pattern and equipment connections must be manually entered (not automatic).

For more information on symmetric and asymmetric HUBs, refer to [Core Configuration of Core Configuration](#).



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to [Fiber Cable Handling](#).

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default³⁴</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 2

Retrieve the value of keyword HUBMODE.

Note: If the node is a symmetric HUB node, HUBMODE should be set to AUTO (default). If the node is an asymmetric HUB node, the value of HUBMODE should be MANUAL.

³⁴ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
RTRV-SYS:TID::CTAG; Example: RTRV-SYS:FUJITSU::CTAG;	In the tree view, click the Equipment tab. Select the top-level (system) entity. <div style="border: 1px solid black; padding: 2px; display: inline-block; margin: 5px 0;">Entity ▸ Properties View</div> The Properties dialog box opens. Verify the value of HUBMODE. Close the Properties dialog box.

Step 3

Is HUBMODE set to AUTO?

If YES:

Proceed to [Provision HUB Interconnections—Symmetric HUB Node](#).

If NO:

Proceed to [Provision HUB Interconnections—Asymmetric HUB Node](#).

2.13.1

Provision HUB Interconnections Symmetric HUB Node

This subprocedure guides you to install only those cables that are appropriate for the plug-in units installed at the node.

Note: For rules and precautions regarding handling, storing, cleaning, connecting, and disconnecting fiber-optic cables, refer to [Fiber Cable Handling](#).

The following table lists all possible HUB interconnections for a symmetric HUB node.

Note: The following tables and figures refer to WSS HUB Switch unit SFMA-CDC1 and WSS Core Switch unit SFMA-CMC1.

Table 37: Optical Shelf Interconnections for a Symmetric HUB Node

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS1	7	PORT OUT-1	OS2	17	PORT IN-7
	7	PORT OUT-2		3	PORT IN-7

Table 37: Optical Shelf Interconnections for a Symmetric HUB Node (Cont.)

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
	13	PORT OUT-1		17	PORT IN-8
	13	PORT OUT-2		3	PORT IN-8
OS2	7	PORT OUT-1	OS1	17	PORT IN-7
	7	PORT OUT-2		3	PORT IN-7
	13	PORT OUT-1		17	PORT IN-8
	13	PORT OUT-2		3	PORT IN-8
OS1	7	PORT OUT-3	OS3	17	PORT IN-7
	7	PORT OUT-4		3	PORT IN-7
	13	PORT OUT-3		17	PORT IN-8
	13	PORT OUT-4		3	PORT IN-8
OS3	7	PORT OUT-1	OS1	17	PORT IN-5
	7	PORT OUT-2		3	PORT IN-5
	13	PORT OUT-1		17	PORT IN-6
	13	PORT OUT-2		3	PORT IN-6
OS2	7	PORT OUT-3	OS3	17	PORT IN-5
	7	PORT OUT-4		3	PORT IN-5
	13	PORT OUT-3		17	PORT IN-6
	13	PORT OUT-4		3	PORT IN-6
OS3	7	PORT OUT-3	OS2	17	PORT IN-5
	7	PORT OUT-4		3	PORT IN-5
	13	PORT OUT-3		17	PORT IN-6
	13	PORT OUT-4		3	PORT IN-6
OS1	7	PORT OUT-5	OS4	17	PORT IN-7
	7	PORT OUT-6		3	PORT IN-7
	13	PORT OUT-5		17	PORT IN-8

Table 37: Optical Shelf Interconnections for a Symmetric HUB Node (Cont.)

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
	13	PORT OUT-6		3	PORT IN-8
OS4	7	PORT OUT-1	OS1	17	PORT IN-3
	7	PORT OUT-2		3	PORT IN-3
	13	PORT OUT-1		17	PORT IN-4
	13	PORT OUT-2		3	PORT IN-4
OS2	7	PORT OUT-5	OS4	17	PORT IN-5
	7	PORT OUT-6		3	PORT IN-5
	13	PORT OUT-5		17	PORT IN-6
	13	PORT OUT-6		3	PORT IN-6
OS4	7	PORT OUT-3	OS2	17	PORT IN-3
	7	PORT OUT-4		3	PORT IN-3
	13	PORT OUT-3		17	PORT IN-4
	13	PORT OUT-4		3	PORT IN-4
OS3	7	PORT OUT-5	OS4	17	PORT IN-3
	7	PORT OUT-6		3	PORT IN-3
	13	PORT OUT-5		17	PORT IN-4
	13	PORT OUT-6		3	PORT IN-4
OS4	7	PORT OUT-5	OS3	17	PORT IN-3
	7	PORT OUT-6		3	PORT IN-3
	13	PORT OUT-5		17	PORT IN-4

Table 37: Optical Shelf Interconnections for a Symmetric HUB Node (Cont.)

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
	13	PORT OUT-6		3	PORT IN-4

- [Figures 69 through 70](#) show the fiber-optic cable interconnections needed to support a 4-degree HUB node. A 3-degree HUB requires interconnections to only one side of the Auxiliary Optical shelf OS2.
- [Figures 71 through 74](#) show the fiber-optic cable interconnections needed to support a 6-degree HUB node. A 5-degree HUB requires interconnections to only one side of the Auxiliary Optical shelf OS3.
- [Figures 75 through 80](#) show the fiber-optic cable interconnections needed to support an 8-degree HUB node. A 7-degree HUB requires interconnections to only one side of the Auxiliary Optical shelf OS4.

The following flowchart shows how fiber-optic cable interconnection tasks are used to interconnect the Optical shelves.




Figure 68: Interconnect Optical Shelves (Subprocedure Flowchart)



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to [Fiber Cable Handling](#).

Step 1

Are slots 3 and 7 of Auxiliary Optical shelf OS2 equipped with plug-in units?

If YES:

Proceed to [Step 2](#).

If NO:

Proceed to [Step 4](#).

Install Cables from OS1 to OS2, Slots 3 and 7

Step 2


Obtain and clean four LC-LC fiber-optic cables.

Step 3

Connect the cable ends to the appropriate connectors of the plug-in units in the Main Optical shelf OS1 and the Auxiliary Optical shelf OS2 listed in the following table and shown in the following figure.

Table 38: Interconnections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS2 Slots 3 and 7

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS1	7	PORT OUT-2	OS2	3	PORT IN-7
	13	PORT OUT-2	OS2	3	PORT IN-8
OS2	7	PORT OUT-1	OS1	17	PORT IN-7
	7	PORT OUT-2	OS1	3	PORT IN-7



mi714qb_2

Figure 69: Interconnections for SFMA-CDC1 between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS2 Slots 3 and 7

Step 4

Are slots 13 and 17 of Auxiliary Optical shelf OS2 equipped with plug-in units?

If YES:

Proceed to [Step 5](#).

If NO:

Proceed to [Step 33](#).

Install Cables from OS1 to OS2, Slots 13 and 17

Step 5


Obtain and clean four LC-LC fiber-optic cables.

Step 6

Connect the cable ends to the appropriate connectors of the plug-in units in the Main Optical shelf OS1 and the Auxiliary Optical shelf OS2 listed in the following table and shown in the following figure.

Table 39: Interconnections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS2 Slots 13 and 17

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS1	7	PORT OUT-1	OS2	17	PORT IN-7
OS1	13	PORT OUT-1	OS2	17	PORT IN-8
OS2	13	PORT OUT-1	OS1	17	PORT IN-8
OS2	13	PORT OUT-2	OS1	3	PORT IN-8



m1714qc_1

Figure 70: Interconnections for SFMA-CDC1 between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS2 Slots 13 and 17

Step 7

Does the node include Auxiliary Optical shelf OS3?

If YES:

Proceed to [Step 8](#).

If NO:

Proceed to [Step 33](#).

Step 8

Are slots 3 and 7 of Auxiliary Optical shelf OS3 equipped with plug-in units?

If YES:

Proceed to [Step 9](#).

If NO:

Proceed to [Step 14](#).

Install Cables from OS1 to OS3, Slots 3 and 7

Step 9


Obtain and clean four LC-LC fiber-optic cables.

Step 10

Connect the cable ends to the appropriate connectors of the plug-in units in the Main Optical shelf OS1 and the Auxiliary Optical shelf OS2 listed in the following table and shown in the following figure.

Table 40: Interconnections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS3 Slots 3 and 7

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS1	7	PORT OUT-4	OS3	3	PORT IN-7
	13	PORT OUT-4	OS3	3	PORT IN-8
OS3	7	PORT OUT-1	OS1	17	PORT IN-5
	7	PORT OUT-2	OS1	3	PORT IN-5



mi714qe_4

Figure 71: Interconnections for SFMA-CDC1 between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS3 Slots 3 and 7

Install Cables from OS2 to OS3, Slots 3 and 7

Step 11

Obtain and clean four LC-LC fiber-optic cables.

Step 12


Connect the cable ends to the appropriate connectors of the plug-in units in the Auxiliary Optical shelf OS2 and the Auxiliary Optical shelf OS3 listed in the following table and shown in the following figure.

Table 41: Interconnections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS3 Slots 3 and 7

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS2	7	PORT OUT-4	OS3	3	PORT IN-5
	13	PORT OUT-4	OS3	3	PORT IN-6
OS3	7	PORT OUT-3	OS2	17	PORT IN-5
	7	PORT OUT-4	OS2	3	PORT IN-5

Step 13

Are slots 13 and 17 of Auxiliary Optical shelf OS3 equipped with plug-in units?



mi1714qh_3

Figure 72: Interconnections for SFMA-CDC1 between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS3 Slots 3 and 7

If YES:

Proceed to [Step 14](#).
 FLASHWAVE 7500

Release 8.1, Issue 2, October 2013
 FNC-7500-0091-270A

Proceed to [Step 20](#).

Install Cables from OS1 to OS3, Slots 13 and 17

Step 14


Obtain and clean four LC-LC fiber-optic cables.

Step 15

Connect the cable ends to the appropriate connectors of the plug-in units in the Main Optical shelf OS1 and the Auxiliary Optical shelf OS3 listed in the following table and shown in the following figure.

Table 42: Interconnections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS3 Slots 13 and 17

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS1	7	PORT OUT-3	OS3	17	PORT IN-7
OS1	13	PORT OUT-3	OS3	17	PORT IN-8
OS3	13	PORT OUT-1	OS1	17	PORT IN-6
OS3	13	PORT OUT-2	OS1	3	PORT IN-6



m1714qf_1

Figure 73: Interconnections for SFMA-CDC1 between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS3 Slots 13 and 17

Install Cables from OS2 to OS3, Slots 13 and 17

Step 16


Obtain and clean four LC-LC fiber-optic cables.

Step 17

Connect the cable ends to the appropriate connectors of the plug-in units in the Auxiliary Optical shelf OS2 and the Auxiliary Optical shelf OS3 listed in the following table and shown in the following figure.

Table 43: Interconnections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS3 Slots 13 and 17

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS2	7	PORT OUT-3	OS3	17	PORT IN-5
OS2	13	PORT OUT-3	OS3	17	PORT IN-6
OS3	13	PORT OUT-3	OS2	17	PORT IN-6
OS3	13	PORT OUT-4	OS2	3	PORT IN-6



m1714qi_1

Figure 74: Interconnections for SFMA-CDC1 between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS3 Slots 13 and 17

Step 18

Does the node include Auxiliary Optical shelf OS4?

If YES:

Proceed to [Step 19](#).

If NO:

Proceed to [Step 33](#).

Step 19

Are slots 3 and 7 of Auxiliary Optical shelf OS4 equipped with plug-in units?

If YES:

Proceed to [Step 20](#).

If NO:

Proceed to [Step 27](#).

Install Cables from OS1 to OS4, Slots 3 and 7

Step 20


Obtain and clean four LC-LC fiber-optic cables.

Step 21

Connect the cable ends to the appropriate connectors of the plug-in units in the Main Optical shelf OS1 and the Auxiliary Optical shelf OS4 listed in the following table and shown in the following figure.

Table 44: Interconnections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS4 Slots 3 and 7

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS1	7	PORT OUT-6	OS4	3	PORT IN-7
	13	PORT OUT-6	OS4	3	PORT IN-8
OS4	7	PORT OUT-1	OS1	17	PORT IN-3
	7	PORT OUT-2	OS1	3	PORT IN-3



mi714qk_3

Figure 75: Interconnections for SFMA-CDC1 between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS4 Slots 3 and 7

Install Cables from OS2 to OS4, Slots 3 and 7

Step 22


Obtain and clean four LC-LC fiber-optic cables.

Step 23

Connect the cable ends to the appropriate connectors of the plug-in units in the Auxiliary Optical shelf OS2 and the Auxiliary Optical shelf OS4 listed in the following table and shown in the following figure.

Table 45: Interconnections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS4 Slots 3 and 7

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS2	7	PORT OUT-6	OS4	3	PORT IN-5
	13	PORT OUT-6	OS4	3	PORT IN-6
OS4	7	PORT OUT-3	OS2	17	PORT IN-3
	7	PORT OUT4	OS2	3	PORT IN-3



mi1714qn_3

Figure 76: Interconnections for SFMA-CDC1 between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS4 Slots 3 and 7

Install Cables from OS3 to OS4, Slots 3 and 7

Step 24


Obtain and clean four LC-LC fiber-optic cables.

Step 25

Connect the cable ends to the appropriate connectors of the plug-in units in the Auxiliary Optical shelf OS3 and the Auxiliary Optical shelf OS4 listed in the following table and shown in the following figure.

Table 46: Interconnections between Auxiliary Optical Shelf OS3 and Auxiliary Optical Shelf OS4 Slots 3 and 7

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS3	7	PORT OUT-6	OS4	3	PORT IN-3
	13	PORT OUT-6	OS4	3	PORT IN-4
OS4	7	PORT OUT-5	OS3	17	PORT IN-3
	7	PORT OUT-6	OS3	3	PORT IN-3



mi1714qq_3

Figure 77: Interconnections for SFMA-CDC1 between Auxiliary Optical Shelf OS3 and Auxiliary Optical Shelf OS4 Slots 3 and 7

Step 26

Are slots 13 and 17 of Auxiliary Optical shelf OS4 equipped with plug-in units?

IF YES:

Proceed to [Step 27](#).

IF NO:

Proceed to [Step 33](#).

Install Cables from OS1 to OS4, Slots 13 and 17

Step 27


Obtain and clean four LC-LC fiber-optic cables.

Step 28

Connect the cable ends to the appropriate connectors of the plug-in units in the Main Optical shelf OS1 and the Auxiliary Optical shelf OS4 listed in the following table and shown in the following figure.

Table 47: Interconnections between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS4 Slots 13 and 17

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS1	7	PORT OUT-5	OS4	17	PORT IN-7
	13	PORT OUT-5	OS4	17	PORT IN-8
OS4	13	PORT OUT-1	OS1	17	PORT IN-4
	13	PORT OUT-2	OS1	3	PORT IN-4



m1714ql_1

Figure 78: Interconnections for SFMA-CDC1 between Main Optical Shelf OS1 and Auxiliary Optical Shelf OS4 Slots 13 and 17

Install Cables from OS2 to OS4, Slots 13 and 17

Step 29


Obtain and clean four LC-LC fiber-optic cables.

Step 30

Connect the cable ends to the appropriate connectors of the plug-in units in the Auxiliary Optical shelf OS2 and the Auxiliary Optical shelf OS4 listed in the following table and shown in the following figure.

Table 48: Interconnections between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS4 Slots 13 and 17

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS2	7	PORT OUT-5	OS4	17	PORT IN-5
	13	PORT OUT-5	OS4	17	PORT IN-6
OS4	13	PORT OUT-3	OS2	17	PORT IN-4
	13	PORT OUT-4	OS2	3	PORT IN-4



m1714qo_1

Figure 79: Interconnections for SFMA-CDC1 between Auxiliary Optical Shelf OS2 and Auxiliary Optical Shelf OS4 Slots 13 and 17

Install Cables from OS3 to OS4, Slots 13 and 17

Step 31

Obtain and clean four LC-LC fiber-optic cables.

Step 32

Connect the cable ends to the appropriate connectors of the plug-in units in the Auxiliary Optical shelf OS3 and the Auxiliary Optical shelf OS4 listed in the following table and listed in the following figure.

Table 49: Interconnections between Auxiliary Optical Shelf OS3 and Auxiliary Optical Shelf OS4 Slots 13 and 17

From SFMA-CDC1			To SFMA-CMC1		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OS3	7	PORT OUT-5	OS4	17	PORT IN-3
	13	PORT OUT-5	OS4	17	PORT IN-4
OS4	13	PORT OUT-5	OS3	17	PORT IN-4
	13	PORT OUT-6	OS3	3	PORT IN-4

Step 33

Are all NEs in the network turned up?


If YES:

Proceed to [Connect Network Fiber-Optic Cables](#).

Note: You have completed the turn-up for the node, but have not connected it to the network. Network connections are made after all nodes are turned up (see [Figure 2](#)).


If NO:

Repeat the turn-up procedures, starting from [Verify Shelf Labeling](#), [Verify LAN and RICC Cable Connections](#), [Apply Power](#), and [Install Fan Units](#), for the next NE.



m1714qr_1

Figure 80: Interconnections for SFMA-CDC1 between Auxiliary Optical Shelf OS3 and Auxiliary Optical Shelf OS4 Slots 13 and 17

 This procedure is complete.

2.13.2 Provision HUB Interconnections Asymmetric HUB Node

This subprocedure guides you to provision a HUB interconnection between two network degrees. The subprocedure must be performed once for each pair of network degrees that are to support pass-through service.

The following three tasks are performed for each HUB interconnection:

- Install two LC-LC fiber-optic cables between WSS HUB Switch units and WSS Core Switch units.
- Install one LAN cable between RICC connectors on backplane of the applicable Optical shelves.
- Create two equipment connections (using the ENT-CONN-EQPT command or equivalent) to inform the system of the LC-LC fiber-optic cable connections.

The following table lists the 12 network degrees that can be potentially connected. For convenience, the twelve degrees are designated by the WDM facility AID. The following table identifies the shelf, plug-in units, and backplane connector group associated with each degree.

Table 50: Network Degrees

Network Degree / WDM Facility AID	Shelf	Plug-In Unit Slot			Backplane Connector Group
		SFMA-CMC1	SFMA-CDC1	MCMA-RCS1	
OS1-1-PE1	OS1	3	7	10	RICC (MCMA-1)
OS1-19-PE1	OS1	17	13	12	RICC (MCMA-2)
OS2-1-PE1	OS2	3	7	10	RICC (MCMA-1)
OS2-19-PE1	OS2	17	13	12	RICC (MCMA-2)
OS3-1-PE1	OS3	3	7	10	RICC (MCMA-1)
OS3-19-PE1	OS3	17	13	12	RICC (MCMA-2)
OS4-1-PE1	OS4	3	7	10	RICC (MCMA-1)
OS4-19-PE1	OS4	17	13	12	RICC (MCMA-2)
OS25-1-PE1	OS25	3	7	10	RICC (MCMA-1)

Table 50: Network Degrees (Cont.)

Network Degree / WDM Facility AID	Shelf	Plug-In Unit Slot			Backplane Connector Group
		SFMA-CMC1	SFMA-CDC1	MCMA-RCS1	
OS25-19-PE1	OS25	17	13	12	RICC (MCMA-2)
OS26-1-PE1	OS26	3	7	10	RICC (MCMA-1)
OS26-19-PE1	OS26	17	13	12	RICC (MCMA-2)

As presented in the following table, each network degree supports six groups of connectors, numbered 1...6. Each group consist of three connectors; one SFMA-CDC1 unit connector, one SFMA-CMC1 unit connector, and one RICC connector (on the backplane). Any group of three connectors can be used to interconnect with another network degree.

Table 51: HUB Connector Groups

Connection Group (Available on Each Network Degree)	Applicable to Network Degree OSn-1-PE1 (WDM Facility AID)			Applicable to Network Degree OSn-19-PE1 (WDM Facility AID)		
	Plug-In Unit		Backplane RICC (MCMA-1) Port	Plug-In Unit		Backplane RICC (MCMA-2) Port
	SFMA-CDC1	SFMA-CMC1		SFMA-CDC1	SFMA-CMC1	
	Slot 7	Slot 3	Slot 10	Slot 13	Slot 17	Slot 12
1	PORT OUT-1	PORT IN-8	PORT 1 (CN35)	PORT OUT-1	PORT IN-8	PORT 1 (CN32)
2	PORT OUT-2	PORT IN-7	PORT 2 (CN36)	PORT OUT-2	PORT IN-7	PORT 2 (CN33)
3	PORT OUT-3	PORT IN-6	PORT 3 (CN37)	PORT OUT-3	PORT IN-6	PORT 3 (CN34)
4	PORT OUT-4	PORT IN-5	PORT 4 (CN28)	PORT OUT-4	PORT IN-5	PORT 4 (CN24)
5	PORT OUT-5	PORT IN-4	PORT 5 (CN29)	PORT OUT-5	PORT IN-4	PORT 5 (CN25)
6	PORT OUT-6	PORT IN-3	PORT 6 (CN30)	PORT OUT-6	PORT IN-3	PORT 6 (CN26)

Table 51: HUB Connector Groups (Cont.)

Connection Group (Available on Each Network Degree)	Applicable to Network Degree OSn-1-PE1 (WDM Facility AID)			Applicable to Network Degree OSn-19-PE1 (WDM Facility AID)		
	Plug-In Unit		Backplane RICC (MCMA-1) Port	Plug-In Unit		Backplane RICC (MCMA-2) Port
	SFMA-CDC1	SFMA-CMC1		SFMA-CDC1	SFMA-CMC1	
	Slot 7	Slot 3	Slot 10	Slot 13	Slot 17	Slot 12
g = 1...6	PORT OUT-g	PORT IN-(9-g)	PORT g	PORT OUT-g	PORT IN-(9-g)	PORT g

The following figure shows the cable connections between two network degrees. Observe the following:

- The two network degrees must reside on different Optical shelves.
- The three connectors used at each network degree can belong to any one of the six groups listed in the preceding table, but all three must belong to the same group.
- The LAN cable interconnects the two RICC connectors.
- The two LC-LC fiber-optic cables interconnect the WSS HUB Switch unit (SFMA-CDC1) on one network degree to the WSS Core Switch unit (SFMA-CMC1) on the other network degree.




Figure 81: Cable Connections Interconnecting Two Network Degrees

The following table lists the equipment connection AIDs applicable to each group within each network degree.



Hint: Remember that equipment connections are created using the ENT-CONN-EQPT command, or equivalent, and are used to inform the system of the LC-LC fiber-optic cable connections.

Table 52: HUB Connector Group Equipment Connection AIDs

Note: OSn refers to the Optical shelf (OS1, OS2, OS3, OS4, OS25, or OS26) that supports the network degree (refer to).

Connection Group (Available on Each Network Degree)	Applicable to Network Degree OSn-1-PE1 (WDM Facility AID)		Applicable to Network Degree OSn-19-PE1 (WDM Facility AID)	
	fromAID	toAID	fromAID	toAID
1	OSn-7-PC1	OSn-3-PC8	OSn-13-PC1	OSn-17-PC8
2	OSn-7-PC2	OSn-3-PC7	OSn-13-PC2	OSn-17-PC7
3	OSn-7-PC3	OSn-3-PC6	OSn-13-PC3	OSn-17-PC6
4	OSn-7-PC4	OSn-3-PC5	OSn-13-PC4	OSn-17-PC5
5	OSn-7-PC5	OSn-3-PC4	OSn-13-PC5	OSn-17-PC4

Table 52: HUB Connector Group Equipment Connection AIDs (Cont.)

Note: OSn refers to the Optical shelf (OS1, OS2, OS3, OS4, OS25, or OS26) that supports the network degree (refer to).

Connection Group (Available on Each Network Degree)	Applicable to Network Degree OSn-1-PE1 (WDM Facility AID)		Applicable to Network Degree OSn-19-PE1 (WDM Facility AID)	
	fromAID	toAID	fromAID	toAID
6	OSn-7-PC6	OSn-3-PC3	OSn-13-PC6	OSn-17-PC3
g = 1...6	OSn-7-PCg	OSn-3-PC(9-g)	OSn-13-PCg	OSn-17-PC(9-g)

There are two equipment connections as shown the following figure. Both equipment connections associate the fromAID of one network degree to the toAID of the other network degree.

The following figure shows the two equipment connections (ENT-CONN-EQPT commands, or equivalent) required to inform the system of the LC-LC fiber-optic cable connections between two network degrees. Observe the following:

- The equipment connections link AIDs belonging to different network degrees. They do not link AIDs belonging to the same network degree.
- The fromAID and toAID associated with each network degree must belong to the same group (1...6). Furthermore, that group must match the group used for making LC-LC fiber-optic cable connections.

Note: Compare The following figure to The preceding figure and observe that the equipment connections mirror the LC-LC fiber-optic cable connections.




Figure 82: Equipment Connections Interconnecting Two Network Degrees

Provision HUB interconnections as follows:

Note: Steps of this procedure are illustrated by an arbitrary example interconnecting network degree OS2-1-PE1 (WDM) with network degree OS25-19-PE1 (WDM). The interconnection is made using connection group 4 at degree OS2-1-PE1 (WDM) and connection group 6 at degree OS25-19-PE1 (WDM).

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT/(Route66K)</td> <td>Password: ROOT/(Route66K)</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default³⁵</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT/(Route66K)	Password: ROOT/(Route66K)	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT/(Route66K)	Password: ROOT/(Route66K)														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

Identify Network Degrees

Step 2

Identify the two network degrees to be connected. The following table lists the 12 network degrees that can be potentially connected. The two network degrees must reside on different Optical shelves.

³⁵ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

Table 53: Network Degrees

WDM Facility AID	Optical Shelf	Plug-In Unit Slot			Backplane Connector Group
		SFMA-CDC1	SFMA-CMC1	MCMA-RCS1	
OS1-1-PE1	OS1	7	3	10	RICC (MCMA-1)
OS1-19-PE1	OS1	13	17	12	RICC (MCMA-2)
OS2-1-PE1	OS2	7	3	10	RICC (MCMA-1)
OS2-19-PE1	OS2	13	17	12	RICC (MCMA-2)
OS3-1-PE1	OS3	7	3	10	RICC (MCMA-1)
OS3-19-PE1	OS3	13	17	12	RICC (MCMA-2)
OS4-1-PE1	OS4	7	3	10	RICC (MCMA-1)
OS4-19-PE1	OS4	13	17	12	RICC (MCMA-2)
OS25-1-PE1	OS25	7	3	10	RICC (MCMA-1)
OS25-19-PE1	OS25	13	17	12	RICC (MCMA-2)
OS26-1-PE1	OS26	7	3	10	RICC (MCMA-1)
OS26-19-PE1	OS26	13	17	12	RICC (MCMA-2)

Example:

Connect network degree OS2-1-PE1 (WDM) to network degree OS25-19-PE1 (WDM).

Step 3

For both network degrees identified in [Step 2](#), use the preceding table to identify the applicable shelf, plug-in units, and backplane connector group. Make a note of this information for reference.

<i>Example:</i>	Network Degree OS2-1-PE1 (WDM) Equipment	Network Degree OS25-19-PE1 (WDM) Equipment
Shelf	OS2	OS25
SFMA-CDC1	slot 7	slot 13
SFMA-CMC1	slot 3	slot 17
Backplane Connector Group	RICC (MCMA-1)	RICC (MCMA-2)

Choose Connection Groups

Step 4

For both network degrees, choose a connection group 1...6 that is currently unused.

Note: To determine whether a connection group is currently used, refer to local documentation or inspect the associated connectors as described in the [Steps 5 through 6](#). The same group number can be used for both network degrees.

Example:

For network degree OS2-1-PE1 (WDM): choose group 4
 For network degree OS25-19-PE1 (WDM): choose group 6

Verify Connection Group Availability

Step 5

For both network degrees, use the following table to identify the connectors associated with the chosen connector groups. Make a note of this information for reference.

Table 54: HUB Connector Groups

Connection Group (Available on Each Network Degree)	Applicable to Network Degrees OSn-1-PE1 (WDM Facility AID)			Applicable to Network Degrees OSn-19-PE1 (WDM Facility AID)		
	Plug-In Unit		Backplane RICC (MCMA-1) Port	Plug-In Unit		Backplane RICC (MCMA-2) Port
	SFMA-CDC1	SFMA-CMC1		SFMA-CDC1	SFMA-CMC1	
	Slot 7	Slot 3	Slot 10	Slot 13	Slot 17	Slot 12
1	PORT OUT-1	PORT IN-8	PORT 1 (CN35)	PORT OUT-1	PORT IN-8	PORT 1 (CN32)
2	PORT OUT-2	PORT IN-7	PORT 2 (CN36)	PORT OUT-2	PORT IN-7	PORT 2 (CN33)
3	PORT OUT-3	PORT IN-6	PORT 3 (CN37)	PORT OUT-3	PORT IN-6	PORT 3 (CN34)
4	PORT OUT-4	PORT IN-5	PORT 4 (CN28)	PORT OUT-4	PORT IN-5	PORT 4 (CN24)
5	PORT OUT-5	PORT IN-4	PORT 5 (CN29)	PORT OUT-5	PORT IN-4	PORT 5 (CN25)
6	PORT OUT-6	PORT IN-3	PORT 6 (CN30)	PORT OUT-6	PORT IN-3	PORT 6 (CN26)
g = 1...6	PORT OUT-g	PORT IN-(9-g)	PORT g	PORT OUT-g	PORT IN-(9-g)	PORT g

<i>Example:</i>	Network Degree OS2-1-PE1 (WDM) Equipment	Group 4 Connectors	Network Degree OS25-19-PE1 (WDM) Equipment	Group 6 Connectors
Shelf	OS2		OS25	
SFMA-CDC1	slot 7	PORT OUT-4	slot 13	PORT OUT-6
SFMA-CMC1	slot 3	PORT IN-5	slot 17	PORT IN-3
Backplane Connector Group	RICC (MCMA-1) slot 10	PORT 4 (CN28)	RICC (MCMA-2) slot 12	PORT 6 (CN26)

Step 6

Inspect the equipment to verify that the six connectors identified in [Step 5](#) are currently unused.

Step 7

Are all connectors identified in [Step 5](#) currently unused?

IF YES:

Proceed to [Step 8](#).

IF NO:

One or both of the connector groups chosen in [Step 4](#) may already be in use. Return to [Step 4](#) and choose a different connection group for one or both network degrees.

Install LC-LC Cables

Step 8

Obtain and clean two LC-LC fiber-optic cables.

Step 9

Install the two LC-LC fiber-optic cables between connectors identified in [Step 5](#) (see The following figure):

- a) Connect one end of the cable to the appropriate PORT OUT connector on the WSS HUB Switch unit (SFMA-CDC1) associated with one of the network degrees.
- b) Connect the other end of the cable to the appropriate PORT IN connector on the WSS Core Switch unit (SFMA-CMC1) on the other network degree.
- c) Repeat [Step 1](#) and [Step 2](#) for the other cable.




Figure 83: LC Cable Connections Interconnecting Two Network Degrees

Example:	Connect Cable From:			Connect Cable To:		
	SFMA-CDC1 PORT OUT			SFMA-CMC1 PORT IN		
	Shelf	Slot	Connector	Shelf	Slot	Connector
Cable 1	OS2	slot 7	PORT OUT-4	OS25	slot 17	PORT IN-3
Cable 2	OS25	slot 13	PORT OUT-6	OS2	slot 3	PORT IN-5

Install RICC Cable

Step 10

Obtain one LAN cable (21-332-xxx).

Step 11

Install the cable between the backplane connectors identified in [Step 5](#).

- a) Connect one end of the cable to the appropriate backplane connector on the shelf associated with one of the network degrees.
- b) Connect the other end of the cable to the appropriate backplane connector on the shelf associated with the other network degree.

Example:	Connect RICC Cable From:			Connect RICC Cable to:		
	Shelf	Backplane Connector Group	Connector	Shelf	Backplane Connector Group	Connector
	OS2	RICC (MCMA-1)	PORT 4	OS25	RICC (MCMA-2)	PORT 6

Enter Equipment Connections

Step 12

For both network degrees, use the following table to identify the equipment connection AIDs associated with the connector groups chosen in [Step 4](#). Make a note of this information for reference.

Table 55: HUB Connector Group Equipment Connection AIDs

Note: OSn refers to the Optical shelf (OS1, OS2, OS3, OS4, OS25, or OS26) that supports the network degree.

Connection Group (Available on Each Network Degree)	Applicable to Network Degrees OSn-1-PE1 (WDM Facility AID)		Applicable to Network Degrees OSn-19-PE1 (WDM Facility AID)	
	fromAID	toAID	fromAID	toAID
1	OSn-7-PC1	OSn-3-PC8	OSn-13-PC1	OSn-17-PC8
2	OSn-7-PC2	OSn-3-PC7	OSn-13-PC2	OSn-17-PC7
3	OSn-7-PC3	OSn-3-PC6	OSn-13-PC3	OSn-17-PC6
4	OSn-7-PC4	OSn-3-PC5	OSn-13-PC4	OSn-17-PC5
5	OSn-7-PC5	OSn-3-PC4	OSn-13-PC5	OSn-17-PC4
6	OSn-7-PC6	OSn-3-PC3	OSn-13-PC6	OSn-17-PC3
g = 1...6	OSn-7-PCg	OSn-3-PC(9-g)	OSn-13-PCg	OSn-17-PC(9-g)

Example:	Network Degree OS2-1-PE1 (WDM) (Group 4)	Network Degree OS25-19-PE1 (WDM) (Group 6)
Shelf	OS2	OS25
fromAID	OS2-7-PC4	OS25-13-PC6
toAID	OS2-3-PC5	OS25-17-PC3

Step 13

Enter two equipment connections using the AIDs identified in [Step 12](#).

Note: In both equipment connections the fromAID relates to one network degree and the toAID relates to the other network degree.

TL1	NETSMART 500
<p>ENT-CONN-EQPT:TID:fromAID,toAID: CTAG; fromAID,toAID:</p> <ul style="list-style-type: none"> As identified in Step 12. <p>Example: ENT-CONN-EQPT:FUJITSU:OS2-7-PC4, OS25-17-PC3;</p> <p>Example: ENT-CONN-EQPT:FUJITSU:OS25-13-PC6, OS2-3-PC5;</p>	<p>NE ▶ Graphical Cross-Connects</p> <p>The Cross-Connects window opens.</p> <p>From the View Rate drop-down list, select XC_EQPT_ASYM.</p> <p>From any one of three drop-down lists (top-left, top-right, or bottom), select the equipment associated with the fromAID.</p> <p>From a different drop-down list, select the equipment associated with the toAID.</p> <p>Click on the fromAID to begin drawing a line that represents the connection.</p> <p>Click on the toAID to terminate the line.</p> <p>The pending connection is now represented by a dashed line with an arrow pointing to the toAID.</p> <p>Entity ▶ Operations Dialog</p> <p>Click Create. The dashed line becomes solid.</p> <p>Close the Operations dialog box. Close the Cross-Connects window.</p>

Step 14
 Verify that the equipment connections are entered.

TL1	NETSMART 500
<p>RTRV-CONN-EQPT:TID::CTAG;</p> <p>Example: RTRV-CONN-EQPT:FUJITSU::CTAG;</p>	<p>In the tree view area, select the Connect Equip. tab.</p>

The HUB connection is now provisioned.

Step 15
 Repeat [Steps 2 through 14](#) until all required HUB connections have been provisioned.


Step 16
 Are all NEs in the network turned up?

If YES:
 Proceed to [Make Network Connections](#).

Note: *You have completed the turn-up for the node, but have not connected it to the network. Network connections are made after all nodes are turned up (see [Figure 2](#)).*

If NO:

Repeat the turn-up procedures, starting from [Verify Shelf Labeling](#), [Verify LAN and RICC Cable Connections](#), [Apply Power](#), and [Install Fan Units](#), for the next NE.

 This procedure is complete.

2.14

Make Network Connections

In this section:

- 2.14.1 Connect Network Fiber-Optic Cables
- 2.14.2 Verify Fiber Connections
- 2.14.3 Reset the Span Loss Variation Alarm References



Warning: Verify the transmit and receive fibers are connected to the correct ports of the plug-in unit. An incorrect connection can result in dropped traffic or an equipment fault and may damage the laser optics.

These subprocedures are performed in the order given, beginning with [Connect Network Fiber-Optic Cables](#).

2.14.1

Connect Network Fiber-Optic Cables

Use the procedure in this section to connect network fiber-optic cables between adjacent nodes. Start at any span, and repeat the subprocedures until network connections are complete for all spans in the network.

At the network level (between NEs), fiber-optic cable connections are made at the OPT IN and OPT OUT connectors of amplifier (APMA-xxxx) plug-in units (located in slot 1 or 19 of Optical shelf OS_n (n = 1...4, 25, 26)). [Figures 84 through 92](#) shows connections for nine example networks. The transmit end of each cable connects to the OPT OUT connector (on an amplifier plug-in unit) in one node, the receive end connects to the OPT IN connector (on an amplifier plug-in unit) in another node.

[Figure 84](#) shows network cable connections for an example 4-node ring network.

[Figure 85](#) shows network cable connections for two 4-node ring networks interconnected through a 4-degree HUB node. The HUB node includes Auxiliary Optical shelf OS2.

[Figure 86](#) shows network cable connections for a 4-node ring network interconnected to a 3-node linear network through a 3-degree HUB node. The HUB node includes Auxiliary Optical shelf OS2.

[Figure 87](#) shows network cable connections for three 4-node ring networks interconnected through a 6-degree HUB node. The HUB node includes Auxiliary Optical shelves OS2 and OS3.

[Figure 88](#) shows network cable connections for two 4-node ring networks interconnected to a 3-node linear network through a 5-degree HUB node. The HUB node includes Auxiliary Optical shelves OS2 and OS3.

[Figure 89](#) shows network cable connections for four 4-node rings interconnected through an 8-degree HUB node. The HUB node includes Auxiliary Optical shelves OS2, OS3, and OS4.

Figure 90 shows network cable connections for three 4-node ring networks and a 3-node linear network interconnected through a 7-degree HUB node. The HUB node includes Auxiliary Optical shelves OS2, OS3, and OS4.

The following figure shows network cable connections for three 4-node ring networks and two 3-node linear networks interconnected through an 8-degree HUB node. The HUB node includes Auxiliary Optical shelves OS2, OS3, and OS4.




Figure 84: Network Connections for 4-Node Ring Network

The following figures shows network cable connections for a 6-node mesh network with two 3-degree HUB nodes interconnected. Each HUB node includes Auxiliary Optical shelf OS2.




Figure 85: Network Connections for Two Ring Networks Interconnected through 4-Degree HUB Node




Figure 86: Network Connections for Ring Network and Linear Network Interconnected through 3-Degree HUB Node





Figure 87: Network Connections for Three Ring Networks Interconnected through 6-Degree HUB Node



m1714pu_2

Figure 88: Network Connections for Two Ring Networks and Linear Network Interconnected through 5-Degree HUB Node






Figure 89: Network Connections for Four Ring Networks Interconnected through 8-Degree HUB Node



mt1714pw_5

Figure 90: Network Connections for Three Ring Networks and Linear Network Interconnected through 7-Degree HUB Node



m1714px_3

Figure 91: Network Connections for Three Ring Networks and Two Linear Networks Interconnected through 8-Degree HUB Node





Figure 92: Network Connections for 6-Node Mesh Network Interconnected through Two 3-Degree HUB Nodes

The following figure shows the network fiber-optic cable connections for a representative span. The nodes are labeled Node A and Node B. In Node B, the span cables connect to the amplifier plug-in unit in slot 19 of an Optical shelf. In Node A, the span cables connect to the amplifier plug-in unit in slot 1 of an Optical shelf.



Note: n = 1...4

Figure 93: Representative Span between Two Adjacent Nodes

For HUB nodes (containing Main Optical shelf OS1 and one or more Auxiliary Optical shelves), it is important to know whether the span connects to Main Optical shelf OS1 or Auxiliary Optical shelf OSn (n = 2...4, 25, 26). These connections depend on network design, as shown in [Figure 85](#) or [Figure 86](#).



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).



Warning: Do not make any fiber connections until optical levels have been measured. Failure to check optical power levels before connecting fibers to optical receivers can damage receivers if power levels are not within specification.



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to [Fiber Cable Handling](#).

Step 1

Identify and clean both ends of the two network fiber-optic cables associated with the span (see [Figure 93](#)). Refer to [Fiber Cable Handling](#).

Step 2

For each cable, if an in-line optical attenuator is required by the network engineering design specification, clean the attenuator, and connect it to the receiving end of the cable.

Step 3

Connect the cable ends (with the optical attenuator, if used) to the appropriate plug-in units and connectors as listed in the following table.

Table 56: Network Connections for Representative Span

Note: For HUB nodes, knowing whether the span connects to the Main Optical shelf OS1 or Auxiliary Optical shelf OSn (n = 2...4, 25, 26) is important. These connections depend on network design, as shown in or .

Node A APMA-xxxx			Node B APMA-xxxx		
Shelf	Shelf Slot	Connector	Shelf	Shelf Slot	Connector
OSn • n = 1...4, 25, 26	19	OPT OUT	OSn • n = 1...4, 25, 26	1	OPT IN
	19	OPT IN ³⁶		1	OPT OUT

Step 4

Repeat [Steps 1 through 3](#) for each span in the network.

Step 5

Proceed to [Verify Fiber Connections](#).

2.14.2

Verify Fiber Connections

This subprocedure includes steps to verify that every optical transmitter is connected to the correct optical receiver at the downstream node. It will also verify that span losses are in accordance with network design. For an overview of the correct network fiber connections, refer to [Connect Network Fiber-Optic Cables](#). Connection errors may not show up immediately as alarm indicators and can lead to protection switching failures.

This procedure assumes the following:

- Fiber-optic cables are installed as described in [Install Intrashelf Fiber-Optic Cables](#), and [Connect Network Fiber-Optic Cables](#).
- A technician is present at each connected node.

Note: *This procedure can also be performed from one location by remotely logging on to each NE. However, if a misconnection on a downstream NE is suspected during the verification procedure, a technician will need to go to the downstream NE to verify the physical connections.*

- Network design information is available to judge whether span loss values (retrieved in [Step 23](#)) are acceptable.



Danger: *Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.*

³⁶ If an in-line optical attenuator is required, it is placed at the OPT IN connector to the amplifier plug-in unit.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: Verify the transmit and receive fibers are connected to the correct ports of the plug-in unit. An incorrect connection can result in dropped traffic or an equipment fault and may damage the laser optics.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

At each site, log on the NE.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default³⁷</p> <p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>	<p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>

Check Alarms and Conditions

Step 2

At each node in the system, retrieve alarms and conditions. Do not continue this procedure until all alarms and conditions are either cleared or accounted for. Refer to [Responding to Alarms and Conditions](#), for trouble clearing information.

TL1	NETSMART 500	
<p>RTRV-COND-ALL:TID::CTAG;</p> <p>Example: RTRV-COND-ALL:FUJITSU::CTAG;</p>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px; display: inline-block;">NE ▾ Alarms</div> <div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px; display: inline-block;">View ▾ Filter</div> <p>The Alarm Filter dialog box opens.</p> <p>Ensure that all fault types are selected in the Fault Type area.</p> <p>Ensure all severity levels are selected in the Severity area. Click Close. Close Active Alarms window.</p>	

³⁷ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

Verify WDM Facilities are In Service

Step 3

At each node in the system, verify that the WDM facilities are in service.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">OSn-1-PE1, OSn-19-PE1<ul style="list-style-type: none">n = 1...4, 25, 26 <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the tree view, click the Facilities tab.</p> <p>Expand the appropriate Optical shelf OSn (n = 1...4, 25, 26). Select a WDM facility.</p> <p>Entity ▸ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that the facility is in service (PRIMARY_STATE: IS).</p> <p>Close the Properties dialog box.</p> <p>Repeat for the other WDM facility.</p>

Step 4

Are the WDM facilities in service?

If YES:

Proceed to [Step 7](#).

If NO:

Continue with [Step 5](#).

Step 5

Place the WDM facility or facilities in service.

TL1	NETSMART 500
<p>ED-WDM:TID:AID:CTAG:::IS; AID:</p> <ul style="list-style-type: none"> OSn-1-PE1, OSn-19-PE1 <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: ED-WDM:FUJITSU:OS1-1-PE1: CTAG:::IS;</p>	<p>In the tree view, click the Facilities tab. Select the appropriate WDM facility or facilities.</p> <p>Note: Select multiple components using CTRL+click or SHIFT+click.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area, select In Service (ED:IS) from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components are selected.</p> <p>Do not close the Operations dialog box.</p>

Step 6

Verify that the service state of the WDM facility or facilities was changed to IS.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As identified in previous step <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the Current Values to confirm that the primary state is In Service (PRIMARY_STATE: IS).</p> <p>Close the Operations dialog box.</p>

Verify OSC Facilities are In Service

Step 7

At each node in the system, verify that the OSC facilities are in service.

TL1	NETSMART 500
<p>RTRV-OSC:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> OSn-9-PE1, OSn-11-PE1 <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>In the tree view, click the Facilities tab. Select an OSC facility.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens. Verify that the facility is in service (PRIMARY_STATE: IS). Close the Properties dialog box. Repeat for the other OSC facility.</p>

Step 8

Are the OSC facilities in service?

IF YES:

Proceed to [Step 11](#).

IF NO:

Continue with [Step 9](#).

Step 9

Place the OSC facility or facilities in service.

TL1	NETSMART 500
<p>ED-OSC:TID:AID:CTAG:::IS; AID:</p> <ul style="list-style-type: none"> OSn-9-PE1, OSn-11-PE1 <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: ED-OSC:FUJITSU:OS1-9-PE1: CTAG:::IS;</p>	<p>In the tree view, click the Facilities tab. Select the appropriate OSC facility or facilities.</p> <p>Note: Select multiple components using CTRL+click or SHIFT+click.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area: Select In Service (ED:IS) from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components are selected.</p> <p>Do not close the Operations dialog box.</p>

Step 10

Verify that the service state of the OSC facility or facilities was changed to IS.

TL1	NETSMART 500
<p>RTRV-OSC:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As identified in previous step ALL (null) <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>In the Current Values of the Operations dialog box, verify that the primary state is In Service (PRIMARY_STATE: IS).</p> <p>Close the Operations dialog box.</p>

Verify Fiber Connections

Step 11

Choose one of the nodes to begin the verification process.

Note: The following verification steps are applied at each node in turn. The node under verification is called the **current node**.

Step 12

At the current node, identify the amplifier plug-in unit for which you want to verify the fiber connection.

Step 13

At the current node, determine the downstream node to which the amplifier is supposed to transmit. Also, identify the shelf and slot in the downstream node where the amplifier is supposed to transmit, and provide this information to the technician at the downstream node. The following table lists the four possible shelf and slot locations.

Note: The following table also lists the associated OSC facility AID for use in [Step 16](#).

Table 57: Downstream Receive Connections and OSC Facilities

Network Receive Connection on Downstream Node			OSC Facility AID
Shelf ³⁸	Slot	Connector	
OSn	1	OPT IN	OSn-9-PE1
OSn	19	OPT IN	OSn-11-PE1

Step 14

At the downstream node, monitor the node for alarms.

Step 15

At the current node, temporarily disconnect the fiber-optic cable from the amplifier plug-in unit connector OPT OUT.

Step 16

At the downstream node, verify that an OSC LOS alarm is raised for the appropriate OSC facility at the downstream node. Refer to the preceding table.

³⁸ OSn refers to the Optical shelf, n = 1...4, 25, 26.

TL1	NETSMART 500
RTRV-ALM-ALL:TID::CTAG; Example: RTRV-ALM-ALL:FUJITSU::CTAG;	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">NE ▶ Alarms</div> <div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">View ▶ Filter</div> <p>The Alarm Filter dialog box opens.</p> <p>Ensure that all fault types are selected in the Fault Type area.</p> <p>Ensure that all severity levels are selected in the Severity area.</p> <p>Click Close.</p> <p>Close Active Alarms window.</p>

Note: If a different node or facility produces an alarm instead, correct the fiber connection error, and then repeat the verification process. Refer to [Connect Network Fiber-Optic Cables](#).

If the fiber-optic cable was disconnected from the amplifier plug-in unit in slot 19 of the Main Optical shelf OS1 at the current node, the OSC facility (OS1-9-PE1) at the downstream node should be alarmed.

Step 17

At the current node, clean and reconnect the fiber-optic cable that was disconnected in [Step 15](#).

Step 18

At the downstream node, verify that the downstream receiver OSC LOS alarm clears within a few seconds.

TL1	NETSMART 500
RTRV-ALM-ALL:TID::CTAG; Example: RTRV-ALM-ALL:FUJITSU::CTAG;	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">NE ▶ Alarms</div> <div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">View ▶ Filter</div> <p>The Alarm Filter dialog box opens.</p> <p>Ensure that all fault types are selected in the Fault Type area.</p> <p>Ensure that all severity levels are selected in the Severity area.</p> <p>Click Close.</p> <p>Close Active Alarms window.</p>

Step 19

Repeat [Steps 12 through 18](#) for each amplifier plug-in unit in the current node, and then proceed to [Step 20](#).

Step 20

Repeat [Steps 11 through 19](#) for every node in the network. Then proceed to [Step 21](#).

Verify Span Loss

Step 21

Choose one of the nodes to begin the verification process.

Note: The following verification steps are applied at each node in turn. The node under verification is called the **current node**.

Step 22

At the current node, identify the network degree for which you want to verify the span loss.

Step 23

For the current network degree, retrieve the span loss.

TL1	NETSMART 500
<pre>RTRV-PM-PORT:TID:AID:CTAG::SPANLOSS; AID: • OSn-1-PE1, OSn-19-PE1 • n = 1...4, 25, 26 Example: RTRV-PM-PORT:FUJITSU:OS1-1-PE1: CTAG::SPANLOSS;</pre>	<p>Select the Equipment tab in the tree area.</p> <p>Locate the appropriate amplifier equipment entity and expand it to view subentities.</p> <p>Select the OSn-s-PE1 (PORT) subentity.</p> <p>Reports</p> <p>▶ Selected Entities ▶ PM Data</p> <p>The PM Data Query dialog box opens.</p> <p>From the MONTYPE drop-down list, select SPANLOSS.</p> <p>Click Generate Report.</p> <p>The PM Data report window opens.</p> <p>Confirm that value in the Validity field is TRUE.</p> <p>Span loss is reported in the Monitor Value field.</p> <p>Close the PM Data report window.</p>

The TL1 response format is as follows:

```
SID DATE TIME
M CTAG COMPLD
  "AID:MONTYPE,MONVAL,VLDTY,LOCN,DIRN"
```

Step 24

Is the value of the validity (VLDTY) parameter TRUE?

Note: If the validity parameter is FALSE, the returned value is invalid.

IF YES:

Proceed to [Step 25](#).

IF NO:

Call Fujitsu at 1-800-USE-FTAC for technical assistance.

Step 25

Is the span loss in accordance with network design?

Note: The span loss in dB is contained in the monitored value (MONVAL) field.

IF YES:

Proceed to [Step 26](#)

IF NO:


Call Fujitsu at 1-800-USE-FTAC for technical assistance.

Step 26

Repeat [Steps 23 through 25](#) for each network degree in the current node, and then proceed to [Step 27](#).

Step 27

Repeat [Steps 21 through 26](#) for every node in the network. Then proceed to [Reset the Span Loss Variation Alarm References](#).

 This procedure is complete.

2.14.3

Reset the Span Loss Variation Alarm References

This procedure is used to reset the system reference value (SYSREF) for the span loss variation (SLV) alarm associated with each amplifier that is new to the network. The procedure sets the value of SYSREF to the current span loss value.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Identify the new network connections, then, starting with any node that includes a new network connection, proceed to [Step 2](#).

Note: Steps 2 through 16 are performed once for each new network connection. To perform these steps you must be able to identify the OSC facility, WDM facility, and the amplifier equipment associated with the network connection.



Step 2

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p>  <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p>  <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default³⁹</p> <p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>	<p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 graphical user interface.</p>

Step 3

Edit the OSC facility out of service.

TL1	NETSMART 500	
<p>ED-OSC:TID:AID:CTAG::::OOS; AID:</p> <ul style="list-style-type: none"> OSn-9-PE1 (OSC facility for slot-9 plug-in unit) OSn-11-PE1 (OSC facility for slot-11 plug-in unit) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: ED-OSC:FUJITSU:OS1-9-PE1: CTAG::::OOS;</p>	<p>In the tree view, click the Facilities tab.</p> <p>Expand the appropriate shelf component.</p> <p>Select one or more facility components.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity > Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>Select the appropriate facility state from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components were selected.</p> <p>Do not close the Operations dialog box.</p>	

³⁹ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

Step 4

Verify that the OSC facility state is out of service.

TL1	NETSMART 500
<p>RTRV-OSC:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As specified in the previous step ALL (null) <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify the facility state.</p> <p>Close the Operations dialog box.</p>

Step 5

Edit the WDM facility out of service.

TL1	NETSMART 500
<p>ED-WDM:TID:AID:CTAG:::OOS; AID:</p> <ul style="list-style-type: none"> OSn-1-PE1 (WDM facility associated with slot-1 amplifier) OSn-19-PE1 (WDM facility associated with slot-1 amplifier) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: ED-WDM:FUJITSU:OS1-1-PE1: CTAG:::OOS;</p>	<p>In the tree view, click the Facilities tab.</p> <p>Expand the appropriate shelf component.</p> <p>Select one or more facility components.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>Click the State tab.</p> <p>Select the appropriate facility state from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components were selected.</p> <p>Do not close the Operations dialog box.</p>

Step 6

Verify that the WDM facility state is out of service.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As specified in the previous step ALL (null) <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify the facility state.</p> <p>Close the Operations dialog box.</p>

Step 7

Edit the amplifier equipment state out of service.

TL1	NETSMART 500
<p>ED-EQPT:TID:AID:CTAG::::OOS; AID:</p> <ul style="list-style-type: none"> OSn-1 (slot 1) OSn-19 (slot 19) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: ED-EQPT:FUJITSU:OS1-1:CTAG::::OOS;</p>	<p>In the tree view, click the Equipment tab. Expand the appropriate shelf component. Select one or more equipment components.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>Select the appropriate facility state from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components were selected.</p> <p>Do not close the Operations dialog box.</p>

Step 8

Retrieve the amplifier equipment provisioning:

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As identified in previous step ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS1-1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify equipment provisioning.</p> <p>Close the Operations dialog box.</p>

a) Verify that the amplifier equipment state is out of service.

b) Following local practice, make a record of the current value of SYSREF.

Note: The current value of SYSREF is noted so that it can be compared to the value of SYSREF after SYSREF is reset to the current span loss value (Step 10).

Step 9

Edit keyword TCAREF to REFRESET.

Note: This step resets the system reference value (SYSREF) to the current span loss value.

TL1	NETSMART 500
<pre>ED-EQPT:TID:AID:CTAG::: TCAREF=REFRESET; AID: • As identified in previous step</pre> <p>Example: <pre>ED-EQPT:FUJITSU:OS1-1:CTAG::: TCAREF=REFRESET;</pre></p>	<p>The NETSMART 500 user interface does not support this TL1 command. However, the NETSMART 500 user interface does provide a TL1 command interface (the NE Command Manager located at the bottom of the NETSMART 500 window) to enter any TL1 command.</p>

Step 10

Retrieve the amplifier equipment provisioning and, following local practice, make a note of the new value of SYSREF.

Note: The new value of SYSREF can be compared to the value noted in [Step 8](#). The value may or may not have changed.

TL1	NETSMART 500
<pre>RTRV-EQPT:TID:AID:CTAG; AID: • As identified in previous step • ALL (null)</pre> <p>Example: <pre>RTRV-EQPT:FUJITSU:OS1-1:CTAG;</pre></p>	<p>In the tree view, click the Equipment tab. Expand the appropriate shelf component. Select one or more equipment components.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▶ Properties View</p> <p>Close the Properties dialog box.</p>

Step 11

Place the amplifier equipment back in service.

TL1	NETSMART 500
<p>ED-EQPT:TID:AID:CTAG::::IS; AID:</p> <ul style="list-style-type: none"> • OSn-1 (slot 1) • OSn-19 (slot 19) <ul style="list-style-type: none"> • n = 1...4, 25, 26 <p>Example: ED-EQPT:FUJITSU:OS1-1:CTAG::::IS;</p>	<p>In the tree view, click the Equipment tab. Expand the appropriate shelf component. Select one or more equipment components.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▸ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>Select the appropriate facility state from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components were selected.</p> <p>Do not close the Operations dialog box.</p>

Step 12

Verify that the amplifier equipment state is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • As identified in previous step • ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS1-1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify equipment provisioning.</p> <p>Close the Operations dialog box.</p>

Step 13

Place the WDM facility back in service.

TL1	NETSMART 500
<p>ED-WDM:TID:AID:CTAG:::IS; AID:</p> <ul style="list-style-type: none"> OSn-1-PE1 (WDM facility associated with slot-1 amplifier) OSn-19-PE1 (WDM facility associated with slot-1 amplifier) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: ED-WDM:FUJITSU:OS1-1-PE1:CTAG:::IS;</p>	<p>In the tree view, click the Facilities tab.</p> <p>Expand the appropriate shelf component.</p> <p>Select one or more facility components.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▾ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>Click the State tab.</p> <p>Select the appropriate facility state from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components were selected.</p> <p>Do not close the Operations dialog box.</p>

Step 14

Verify that the WDM facility state is in service.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As specified in the previous step ALL (null) <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify the facility state.</p> <p>Close the Operations dialog box.</p>

Step 15

Place the OSC facility back in service.

TL1	NETSMART 500
<p>ED-OSC:TID:AID:CTAG:::IS; AID:</p> <ul style="list-style-type: none"> OSn-9-PE1 (OSC facility for slot-9 plug-in unit) OSn-11-PE1 (OSC facility for slot-11 plug-in unit) <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>Example: ED-OSC:FUJITSU:OS1-9-PE1: CTAG:::IS;</p>	<p>In the tree view, click the Facilities tab.</p> <p>Expand the appropriate shelf component.</p> <p>Select one or more facility components.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>Click the State tab.</p> <p>Select the appropriate facility state from the New Prov. State drop-down list.</p> <p>Click Modify or Modify All if multiple components were selected.</p> <p>Do not close the Operations dialog box.</p>

Step 16

Verify that the OSC facility state is in service.

TL1	NETSMART 500
<p>RTRV-OSC:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> As specified in the previous step ALL (null) <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify the facility state.</p> <p>Close the Operations dialog box.</p>

Step 17

Repeat [Steps 2 through 16](#) for each new network connection, in every node, that is included in the turn-up. Then proceed to [Step 18](#).

Step 18

Do you want to provision node attributes to support control plane features?

Note: Control plane provisioning is needed to permit the NETSMART 500 graphical user interface to generate a network topology view (see [Figure 96](#)) and to support optical reach validation in A-to-Z path planning (refer to [Use the NETSMART 500 Create A to Z Path Wizard](#)).

IF YES:

Proceed to [Provision Control Plane](#).

IF NO:

Proceed to [Acceptance Testing](#).


2.15

Provision Control Plane

In this section:

- 2.15.1 Enable Auto Address Server for IP Address Provisioning
- 2.15.2 Manually Provision IP Addresses
- 2.15.3 Enable IP Routing by OSPF
- 2.15.4 Enable IP Routing by Integrated IS-IS
- 2.15.5 Launch Network Topology View
- 2.15.6 Provision Optical Reach Data

The following figure shows a flowchart of how these subprocedures are used.



m1718xh_3

Figure 94: Flowchart to Provision Control Plane to Enable Network Topology View

IP addresses must be provisioned and IP routing must be enabled prior to launching the NETSMART 500 network topology view (refer to [Launch Network Topology View](#)). IP addresses can be provisioned indirectly using the auto address server (refer to [Enable Auto Address Server for IP Address Provisioning](#)) or they can be provisioned manually (refer to [Manually Provision IP Addresses](#)). IP routing can be enabled using the OSPF mechanism (refer to [Enable IP Routing by OSPF](#)) or using the Integrated IS-IS mechanism (refer to [Enable IP Routing by Integrated IS-IS](#)). The same mechanism should be used for all nodes in the network. Do not enable both mechanisms.

To start, choose one of the following methods for provisioning IP addresses and proceed accordingly:

- [Enable Auto Address Server for IP Address Provisioning](#)
- [Manually Provision IP Addresses](#)

2.15.1

Enable Auto Address Server for IP Address Provisioning

This subprocedure applies to the node that is to serve as the auto address server. Any NE within the network can be the auto address server, but there can be only one auto address server in the network. If more than one NE within a network is set to be an auto address server, the duplicate server alarm (DUPSVR) will be raised on the server NEs.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Log on the node that is to serve as the auto address server.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default⁴⁰</p>	<p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>
	<p>Click Logon. The NETSMART 500 NE View opens. The Security Message dialog box opens. Click OK. Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	

Enable Auto Address Server

Step 2

Enable the Auto Address Server.

TL1	NETSMART 500	
<p>ED-NLP:TID::CTAG:::ADDRSVR=Y; Example: ED-NLP:FUJITSU::CTAG:::ADDRSVR=Y;</p>	<p>Click Communications tab in tree view. Select the NLP component.</p> <div style="background-color: #cccccc; padding: 2px; display: inline-block;">Entity ▸ Operations Dialog</div> <p>The Operations dialog box opens. In the Command Parameters area, select Y from the ADDRSVR State drop-down list. Click Modify. A confirmation dialog box opens. Click Yes to close the confirmation dialog box and continue. Close the Operations dialog box.</p>	

⁴⁰ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

Step 3

Initialize the OIF.

Note: The `INIT-OIF` command must be executed before the `ED-NLP` command becomes effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG::TTIMES=DOWN;</pre> <p>Example: <pre>INIT-OIF:FUJITSU::CTAG::TTIMES=DOWN;</pre></p>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the Initialize tab. Click the Stack tab.</p> <p>Select OIF from the STACK INIT TYPE menu.</p> <p>Select DOWN from the TTIMES menu. Click Initialize. Click Yes. Click OK.</p> <p>Close the NETSMART 500 user interface. Click Yes.</p>

Note: The NETSMART 500 software connection to the NE will be lost. After waiting 2 minutes, users should log back on the NE.

Step 4

Wait 2 minutes before continuing.

Step 5

If necessary, log back on the NE (refer to [Step 1](#) for logon details).

Step 6

Verify that the Auto Address Server is enabled.

TL1	NETSMART 500
<pre>RTRV-NLP:TID::CTAG;</pre> <p>Example: <pre>RTRV-NLP:FUJITSU::CTAG;</pre></p>	<p>In the tree view, click the Communications tab. Select the NLP component.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens. Verify that ADDR5VR is Y.</p> <p>Close the Properties dialog box.</p>

Enter Address Pool

Step 7

Enter the address pool.

TL1	NETSMART 500
<pre>ENT-ADDR-POOL:TID::CTAG::ENTRY: KEYWORD=DOMAIN; ENTRY: • 1...20 KEYWORD=DOMAIN: • GROUP=0...255 • SUBGRP=1...8IPADDR= x.x.x.x (x=0...255) • MASK=x.x.x.x (x=0...255), 255.255.255.0 • RANGE=1...150 Example: ENT-ADDR-POOL:FUJITSU::CTAG::1: GROUP=1, SUBGRP=2;</pre>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Address Pools tab. Click the Enter tab.</p> <p>In the Command Parameters area, select the appropriate parameters. Click Enter.</p> <p>A confirmation dialog box opens.</p> <p>Click Yes to close the confirmation dialog box and continue.</p> <p>Close the Operations dialog box.</p>

Step 8

Initialize the OIF.

Note: The *INIT-OIF* command must be executed before the *ENT-ADDR-POOL* command becomes effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG::TTIMES=DOWN; Example: INIT-OIF:FUJITSU::CTAG::: TTIMES=DOWN;</pre>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Initialize tab. Click the Stack tab.</p> <p>Select OIF from the STACK INIT TYPE menu.</p> <p>Select DOWN from the TTIMES menu. Click Initialize. Click Yes. Click OK.</p> <p>Close the NETSMART 500 user interface. Click Yes.</p>

Note: The *NETSMART 500* connection to the *NE* will be lost. After waiting 2 minutes, *NETSMART 500* users should log back on the *NE*.

Step 9

Wait 2 minutes before continuing.

Step 10

If necessary, log back on the NE (refer to [Step 1](#) for log on details).

Step 11

Verify that the address pool is entered.


TL1	NETSMART 500
<pre>RTRV-ADDR-POOL:TID::CTAG;</pre> <p>Example: <pre>RTRV-ADDR-POOL:FUJITSU::CTAG;</pre></p>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Address Pools tab. Click the Enter tab.</p> <p>Verify provisioning in the current values area.</p> <p>Close the Operations dialog box.</p>

Step 12

Proceed to one of the following procedures to enable IP routing.

Note: The FLASHWAVE 7500 system supports two methods for IP routing: Integrated IS-IS and OSPF. The same mechanism should be used for all nodes in the network. Do not enable both mechanisms.

- [Enable IP Routing by OSPF](#)
- [Enable IP Routing by Integrated IS-IS](#)

 This procedure is complete.

2.15.2

Manually Provision IP Addresses



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Starting with any node, proceed to [Step 2](#).

Note: [Steps 2 through 11](#) are performed once for each node in the network.

Step 2

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X. For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2) Configure: use default⁴¹</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Change NEM IP Address Source to Manual

Step 3

Change the NEM IP address source to manual.

⁴¹ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

TL1	NETSMART 500
<pre>ED-IP-ADDR:TID:NEM:CTAG::: ADDRSRC=MAN;</pre> <p>Example: <pre>ED-IP-ADDR:FUJITSU:NEM:CTAG::: ADDRSRC=MAN;</pre></p>	<p>Click the Communications tab in the tree area. Select the NEM (IP) entity.</p> <div style="background-color: #cccccc; padding: 2px; margin: 5px 0;">Entity ▶ Operations Dialog</div> <p>From the ADDR SRC drop-down list, select MAN. Click Modify.</p> <p>Do not close the Operations dialog.</p>

Step 4
 Initialize the OIF.

Note: The `INIT-OIF` command must be executed before the `ED-IP-ADDR` command becomes effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID:::CTAG:::TTIMES=DOWN;</pre> <p>Example: <pre>INIT-OIF:FUJITSU:::CTAG::: TTIMES=DOWN;</pre></p>	<p>Click the Initialize tab. Click the Stack tab.</p> <p>Select OIF from the STACK INIT TYPE menu.</p> <p>Select DOWN from the TTIMES menu. Click Initialize. Click Yes. Click OK.</p> <p>Close the NETSMART 500 user interface. Click Yes.</p>

Note: The NETSMART 500 software connection to the NE will be lost. After waiting 2 minutes, users should log back on the NE.

Step 5
 Wait 2 minutes before continuing.

Step 6
 If necessary, log back on the NE (refer to [Step 1](#) for log on details).

Enter the NEM IP Address

Step 7
 Set the NEM IP address.

TL1	NETSMART 500
<pre>ED-IP-ADDR:TID:NEM:CTAG::: KEYWORD=DOMAIN; KEYWORD=DOMAIN;</pre> <ul style="list-style-type: none"> MASK = xxx.xxx.xxx.xxx, 255.255.255.0 (IP subnetwork mask, where xxx = 0...255) IP = xxx.xxx.xxx.xxx, 0.0.0.0 (node IP address, where xxx = 0...255) <p>Example: <pre>ED-IP-ADDR:FUJITSU:NEM:CTAG::: IP=10.10.10.1,MASK=255.255.255.0;</pre></p>	<p>Click the Communications tab in the tree area. Select the NEM (IP) entity.</p> <div style="border: 1px solid gray; background-color: #cccccc; padding: 2px; margin: 5px 0;"> Entity ▶ Operations Dialog </div> <p>Enter the IP subnet mask address and node IP address. Do not close the Operations dialog.</p>

Step 8
 Initialize the OIF.

Note: The *INIT-OIF* command must be executed before the *ED-IP-ADDR* command becomes effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG:::TTIMES=DOWN;</pre> <p>Example: <pre>INIT-OIF:FUJITSU::CTAG::: TTIMES=DOWN;</pre></p>	<p>Click the Initialize tab. Click the Stack tab.</p> <p>Select OIF from the STACK INIT TYPE menu.</p> <p>Select DOWN from the TTIMES menu. Click Initialize. Click Yes. Click OK.</p> <p>Close the NETSMART 500 user interface. Click Yes.</p>

Note: The *NETSMART 500* software connection to the NE will be lost. After waiting 2 minutes, users should log back on the NE.

Step 9
 Wait 2 minutes before continuing.

Step 10
 If necessary, log back on the NE (refer to [Step 1](#) for log on details).

Step 11
 Verify IP address provisioning.

TL1	NETSMART 500
<p>RTRV-IP-ADDR:TID:NEM:CTAG;</p> <p>Example: RTRV-IP-ADDR:FUJITSU:NEM:CTAG;</p>	<p>Click the Communications tab in the tree area. Select the NEM (IP) entity.</p> <p>Entity ▶ Properties View</p> <p>Verify the parameters in the Current Values area of the Properties dialog box. Close the Properties dialog box.</p>

Step 12

Is the NEM IP address provisioned for all nodes in the network?

If YES:

Proceed to one of the following procedures to enable IP routing.

Note: The FLASHWAVE 7500 system supports two methods for IP routing: Integrated IS-IS and OSPF. The same mechanism should be used for all nodes in the network. Do not enable both mechanisms.

- [Enable IP Routing by OSPF](#)
- [Enable IP Routing by Integrated IS-IS](#)

If NO:

Return to [Step 2](#) and repeat this procedure for the next node.

 This procedure is complete.

2.15.3

Enable IP Routing by OSPF

This subprocedure provides an example for provisioning OSPF for a simple FLASHWAVE 7500 network. For more detailed information about provisioning OSPF for a particular network, refer to the local engineering instructions and [Provisioning Dynamic IP Routing \(OSPF\)](#).

The following figure shows a simple example of OSPF provisioning for a 3-node ring. Example IP addresses are shown for each node. The OSPF interfaces OSn-9-PE1 and OSn-11-PE1 support IP connections to neighboring NEs through the OSC.




Figure 95: Simple Example of OSPF Provisioning



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Starting with any node, proceed to [Step 2](#).

Note: [Steps 2 through 8](#) are performed once for each node in the network.

Step 2

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT/(Route66K)</td> <td>Password: ROOT/(Route66K)</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default⁴²</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT/(Route66K)	Password: ROOT/(Route66K)	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT/(Route66K)	Password: ROOT/(Route66K)														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

Enable OSPF Process

Step 3 Enable OSPF.

⁴² The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<p>ED-OSPF-BASE:TID::CTAG:::IS;</p> <p>Example: ED-OSPF-BASE:FUJITSU::CTAG:::IS;</p>	<p>In the tree view:</p> <p>Click on the Communications tab.</p> <p>Expand, if necessary, to reveal OSPF_BASE (OSPF_BASE). Select OSPF_BASE (OSPF_BASE).</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>In the Command Parameters area:</p> <p>From the State drop-down list, select IS. Click Modify.</p> <p>Do not close the Operations window.</p>

Step 4

Verify that OSPF is in service.

Note: The OSPF router ID (RTRID) is automatically set to the NEM public IP address.

TL1	NETSMART 500
<p>RTRV-OSPF-BASE:TID::CTAG;</p> <p>Example: RTRV-OSPF-BASE:FUJITSU::CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the State is IS.</p> <p>Close the Operations dialog box.</p>

Enter NEM OSPF Interface(s)

Step 5

Enter the NEM OSPF interface.

TL1	NETSMART 500
<p>ENT-OSPF-IF:TID:NEM:CTAG;</p> <p>Example: ENT-OSPF-IF:FUJITSU:NEM:CTAG;</p>	<p>In the tree view:</p> <p>Click on the Communications tab.</p> <p>Expand, if necessary, to reveal OSPF_BASE (OSPF_BASE). Select OSPF_BASE (OSPF_BASE).</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the Create tab. Click the OSPF_IF tab.</p> <p>From the AID drop-down list, select NEM. Click Create. Close the Operations window.</p>

Step 6
 Verify the NEM OSPF interface.

TL1	NETSMART 500
<p>RTRV-OSPF-IF:TID:NEM:CTAG;</p> <p>Example: RTRV-OSPF-IF:FUJITSU:NEM:CTAG;</p>	<p>In the tree view:</p> <p>Click on the Communications tab. Expand OSPF_BASE (OSPF_BASE). Select NEM (OSPF_IF).</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog opens. Verify that the provisioning parameters are correct. Close the Properties dialog box.</p>

Enter OSC OSPF Interface(s)

Step 7
 Enter the OSC OSPF interface(s).

Note: Before creating an OSPF interface on an OSC facility (OSn-9-PE1 or OSn-11-PE1, the OSC facility must be provisioned. Refer to [Provisioning SDCC \(SONET/SDH DCC, OSC ODCC, GCCO\)](#), for SDCC provisioning instructions.

TL1	NETSMART 500
<p>ENT-OSPF-IF:TID:AID:CTAG:::</p> <p>KEYWORD=DOMAIN:IS;</p> <p>AID:</p> <ul style="list-style-type: none"> OSn-9-PE1 OSn-11-PE1 <ul style="list-style-type: none"> n = 1...4, 25, 26 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> AREAID⁴³ = xxx.xxx.xxx.xxx (xxx = 0...255), 0.0.0.0 TYPE = P2P Refer to the following table for additional KEYWORD=DOMAIN options. <p>Example: ENT-OSPF-IF:FUJITSU:OS1-11-PE1: CTAG:::AREAID=0.0.0.2:IS;</p>	<p>In the tree view: Click the Communications tab.</p> <p>Expand, if necessary, to reveal OSPF_BASE (OSPF_BASE). Select OSPF_BASE (OSPF_BASE).</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the Create tab. Click the OSPF_IF tab.</p> <p>In the Command Parameters area: From the State drop-down list, select IS.</p> <p>From the AID drop-down list, select OSn-9-PE1 or OSn-11-PE1.</p> <p>Based on the local work order, modify other parameters as required. The following table provides descriptions of ENT-OSPF-IF keyword parameters. Click Create. Close the Operations window.</p>

Table 58: ENT-OSPF-IF Keyword and Domain Input Parameters

Keyword	Domain (Default in Bold)	Description
AREAID	xxx.xxx.xxx.xxx (xxx = 0...255) 0.0.0.0	AREAID uniquely identifies the area to which the interface connects. An AREAID value of 0.0.0.0 is used for the OSPF backbone.
TYPE	OSPF interface type	
	BCAST	OSPF interface type for LCN and LMP
	P2P	OSPF interface type for OSC
	LPBK	OSPF interface type for NEM port
TXDELAY	1 ...3600	The estimated number of seconds required to transmit a link state update packet over the interface
RTRSINTV	0... 5 ...3600	The number of seconds between LSA retransmissions for adjacencies belonging to this interface. This value is also used when retransmitting database description and link state request packets.
HLOINTV	1... 10 ...65535	Length of time, in seconds, between the Hello packets that the router sends on the interface. This value must be the same for all routers attached to a common network.
POLLINTV	0... 120 ...2147483647	The larger time interval, in seconds, between the Hello packets sent to an inactive nonbroadcast multiaccess neighbor

⁴³ OSn-9-PE1 and OSn-11-PE1 OSPF interfaces must be provisioned in the same OSPF area as NEM OSPF interface.

Table 58: ENT-OSPF-IF Keyword and Domain Input Parameters (Cont.)

Keyword	Domain (Default in Bold)	Description
CASTMODE	BLOCKED	Status of the multicast capability of the interface. BLOCKED indicates that multicast forwarding is blocked.
DEADINTV	0... 40 ...2147483647	Number of seconds that the Hello packets from a router have not been seen before its neighbors declare the router down. This value should be some multiple of the Hello interval. This value must be the same for all routers attached to a common network.
METRIC	1...65535 ⁴⁴	METRIC (cost) of the interface (link)
RTRPRIO	0 ...255	Router priority of this interface used in broadcast network. This value can be modified to values other than 0 only when more than two Fujitsu NE LCN ports need to be connected together in a broadcast network running OSPF and when there is no other vendor's router participating in this routing domain. This field is used in the designated router election algorithm.
AUTYPE	Authentication type	
	0	Authentication type is "no authentication."
	1	Authentication type is "simple password."
	2	Authentication type is "MD5."
AUKEY	Authentication code used when AUTYPE=1	
	0- to 8-byte ASCII string	8-byte ASCII character string delineated by escape quotes
	null	Empty character string delineated by escape quotes (\")
MD5KEY1	Authentication key 1 used for MD5 algorithm when AUTYPE=2	
	0- to 8-byte ASCII string	8-byte ASCII character string delineated by escape quotes
	null	Empty character string delineated by escape quotes (\")
MD5KEY2	Authentication key 2 (up to 8 ASCII characters) used for MD5 algorithm when AUTYPE=2	
	0- to 8-byte ASCII string	8-byte ASCII character string delineated by escape quotes
	null	Empty character string delineated by escape quotes (\")
ACTKEY	Active MD5 key used for MD5 algorithm when AUTYPE=2	
	1	Key 1 is active.
	2	Key 2 is active.

Step 8
 Verify the OSC OSPF interface(s).

⁴⁴ Default is 1 for OSC or 10 for LCN and LMP.

TL1	NETSMART 500
<pre>RTRV-OSPF-IF:TID::CTAG;</pre> <p>Example: <pre>RTRV-OSPF-IF:FUJITSU::CTAG;</pre></p>	<p>In the tree view: Click the Communications tab. Expand OSPF_BASE (OSPF_BASE). Select the appropriate OSPF-IF: OSn-9-PE1 or OSn-11-PE1.</p> <p>Entity ▾ Properties View</p> <p>Verify the state is IS and that provisioning parameters are correct. Close the Properties View window.</p>

Step 9


Is OSPF provisioned for all nodes in the network?

IF YES:

Proceed to [Launch Network Topology View](#).

IF NO:

Return to [Step 2](#) and repeat this procedure for the next node.

 This procedure is complete.

2.15.4

Enable IP Routing by Integrated IS-IS



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Starting with any node, proceed to [Step 2](#).

Note: [Steps 2 through 8](#) are performed once for each node in the network.

Step 2

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default⁴⁵</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 3 Enable Integrated IS-IS.

⁴⁵ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<pre>ED-NLP:TID::CTAG:::INITS=Y;</pre> <p>Example: <pre>ED-NLP:FUJITSU::CTAG:::INITS=Y;</pre></p>	<p>Click the Communications tab in the tree area. Select the NLP component.</p> <div style="background-color: #cccccc; padding: 2px; margin: 5px 0;">Entity ▸ Operations Dialog</div> <p>For the INTIS parameter, select Yes. Click Modify.</p> <p>A confirmation dialog box opens. Click Yes.</p> <p>Do not close the Operations dialog box.</p>

Step 4

Initialize the OIF.

Note: The INIT-OIF command must be executed before the ED-NLP command becomes effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG:::TTIMES=DOWN;</pre> <p>Example: <pre>INIT-OIF:FUJITSU::CTAG::: TTIMES=DOWN;</pre></p>	<p>Click the Initialize tab. Click the Stack tab.</p> <p>Select OIF from the STACK INIT TYPE menu.</p> <p>Select DOWN from the TTIMES menu. Click Initialize. Click Yes. Click OK.</p> <p>Close the NETSMART 500 user interface. Click Yes.</p>

Note: The NETSMART 500 software connection to the NE will be lost. After waiting 2 minutes, users should log back on the NE.

Step 5

Wait 2 minutes before continuing.

Step 6

If necessary, log back on the NE (refer to [Step 2](#) for log on details).

Step 7

Verify that the INITS parameter is set to Y/Yes.

TL1	NETSMART 500
<pre>RTRV-NLP:TID::CTAG;</pre> <p>Example: <pre>RTRV-NLP:FUJITSU::CTAG;</pre></p>	<p>Click the Communications tab in the tree area. Select the NLP component.</p> <p>Entity ▶ Properties View</p> <p>Verify the parameters in the Current Values area of the Properties dialog box. Close the Properties dialog box.</p>

Step 8

Is Integrated IS-IS provisioned for all nodes in the network?

If YES:

Proceed to [Launch Network Topology View](#).

If NO:

Return to [Step 2](#) and repeat this procedure for the next node.

2.15.5

Launch Network Topology View

The NETSMART 500 network topology view is a graphical depiction of the network elements connected to the logged-on NE. The topology view is opened from the dashboard, where it displays within the view panel. The following figure shows an example of a NETSMART 500 network topology view of a FLASHWAVE 7500 network configuration. Refer to [Operating Control Plane and Network Discovery](#), for more information about the network topology view, the control plane, and network discovery.




Figure 96: Example of NETSMART 500 Network Topology View



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default⁴⁶</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 2

Retrieve the Network Topology features to see the graphical network topology view.

Note: The RTRV-TPNET command is in binary transport version 2 (BTv2) format; therefore, the response is encoded and may not be useful to the user. The NETSMART 500 user interface should be used for this operation because it decodes and formats the data for the user.

⁴⁶ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<pre>RTRV-TPNET:TID::CTAG:::</pre> <pre>KEYWORD=DOMAIN;</pre> <pre>KEYWORD=DOMAIN:</pre> <ul style="list-style-type: none"> Refer to the following table for keyword and domain input parameters. <p>Example: <pre>RTRV-TPNET:FUJITSU::CTAG;</pre></p>	<p>From the Dashboard:</p> <p>In the tree view, select the NE. From the menu bar, select:</p> <div style="border: 1px solid gray; padding: 2px; display: inline-block; background-color: #cccccc;"> NE ▸ Topology </div> <p>The graphical view of the network topology appears.</p>

Table 59: RTRV-TPNET Keyword and Domain Input Parameters

Keyword	Domain (Default in Bold)	Description
TYPE	Type of retrieval	
	TOPO	Returns only neighbor and TID responses
	AID	Returns only AID mapping
	ALL	Returns neighbor, TID, and AID responses
ITERATOR	252 ASCII characters	When a response does not contain all the data requested (due to size constraints) an Iterator is returned to allow for retrieval of the next set of data. This pattern will continue until all data has been retrieved.
FORMAT	DEBUG	Prints the command response in ASCII

Step 3


Proceed to [Provision Optical Reach Data](#).

2.15.6

Provision Optical Reach Data

Use this procedure to provision control plane optical reach information. Start at any node, and repeat the procedure for each node in the network.

The following figure shows a flowchart for the provisioning process.



m1718xi_2

Figure 97: Flowchart for Control Plane Optical Reach Provisioning



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Starting with any node, proceed to [Step 2](#).

Note: [Steps 2 through 11](#) are performed once for each node in the network.

Log on Node

Step 2

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default⁴⁷</p> <p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>	<p>Click Logon. The NETSMART 500 NE View opens. The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 graphical user interface.</p>

Determine Current Software Release

Step 3

Retrieve the software version information and determine the active GISSUE.

TL1	NETSMART 500	
<p>RTRV-VERSION:TID::CTAG; Example: RTRV-VERSION:FUJITSU::CTAG;</p>	<p>NE ▶ System Operations</p> <p>The Operation dialog opens. Click the Attributes tab. Click the Modify tab.</p> <p>In the Current Values area of the Operations dialog box, determine the value of the Active GISSUE. Close the Operations dialog box.</p>	

⁴⁷ The default serial port settings are recommended: baud rate– 9600, parity– none, data bits– 8, stop bits– 1.

Step 4

Is the active GISSUE 09-01-1?

If YES:

Proceed to [Step 5](#).

If NO:

Proceed to [Step 8](#).

Provision Bulk Loss and Repair Margin (Release 6.1)

Step 5

Provision bulk loss and repair margin for the node.

- Bulk loss (BULKLOSS) refers the receive-side connector loss in decibels. The provisioned value applies to each link in the node.
- Repair margin is used to account for end-of-life fiber degradation. It can be specified as a percentage of total span loss (RPRMRGN) or in decibels (RPRMRGNDB). The provisioned value applies to each link in the node.

Note: *RPRMRGN and RPRMRGNDB cannot be specified at the same time. If one is specified, then the other parameter value must be set to 0.*

TL1	NETSMART 500
<p>ED-CPLANE:TID::CTAG:::KEYWORD=DOMAIN; KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> • BULKLOSS = 0...3 (Bulk loss in decibels) • RPRMRGN = 0...20 dB (Repair margin, a percentage of computed total span loss) • RPRMRGNDB = 0...3 dB (Repair margin in decibels) <p>Example: ED-CPLANE:FUJITSU::CTAG::: BULKLOSS=2,RPRMRGN=10;</p>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the Control Plane tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • Enter parameter values. • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 6

Verify that bulk loss and repair margin parameter values are correct.

TL1	NETSMART 500
<p>RTRV-CPLANE:TID::CTAG;</p> <p>Example: RTRV-CPLANE:FUJITSU::CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct.</p> <p>Close the Operations dialog box.</p>

Step 7

Proceed to [Step 12](#).

Provision Bulk Loss and Repair Margin (Release 6.1.2 and later)

Step 8

Starting with any network degree of the current node, proceed to [Step 9](#).

Note: [Steps 9 through 10](#) are performed once for each network degree of the node.

Step 9

Provision bulk loss and repair margin for the network degree.

- Bulk loss (BULKLOSS) refers the receive-side connector loss in decibels.
- Repair margin is used to account for end-of-life fiber degradation. It can be specified as a percentage of total span loss (RPRMRGN) or in decibels (RPRMRGNDB).

Note: RPRMRGN and RPRMRGNDB cannot be specified at the same time. If one is specified, then the other parameter value must be set to 0.

TL1	NETSMART 500
<pre>ED-TELINK:TID:AID:CTAG:::KEYWORD=DOMAIN; AID: • OSn-1-PE1 (WDM facility associated with slot-1 amplifier) • OSn-19-PE1 (WDM facility associated with slot-19 amplifier) • n = 1...4, 25, 26 KEYWORD=DOMAIN: • BULKLOSS = 0...3 (Bulk loss in decibels) • RPRMRGN = 0...20 dB (Repair margin, a percentage of computed total span loss) • RPRMRGNDB = 0...3 dB (Repair margin in decibels) Example: ED-TELINK:FUJITSU:OS1-1-PE1:CTAG::: BULKLOSS=2,RPRMRGN=10;</pre>	<p>In the tree view: Click the Facilities tab. Expand the appropriate shelf. Expand the appropriate WDM facility. Select the TELINK entity for the WDM facility.</p> <p>Entity ▶ Operations Dialog</p> <p>Select the Modify tab</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • Enter parameter values. • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 10

Verify that the provisioned bulk loss and repair margin attribute values are correct.

TL1	NETSMART 500
<p>RTRV-TELINK:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • Same value used in previous step. <p>Example: RTRV-TELINK:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct.</p> <p>Close the Operations dialog box.</p>

Step 11

Repeat [Steps 9 through 10](#) for each network degree of the current node. Then proceed to [Step 12](#).

Provision Fiber Type and Length

Step 12

Starting with any network degree of the current node, proceed to [Step 13](#).

Note: [Steps 13 through 24](#) are performed once for each network degree of the node.

Step 13

Provision fiber type and length.

TL1	NETSMART 500
<p>ED-TELINK:TID:AID:CTAG:::KEYWORD=DOMAIN; AID:</p> <ul style="list-style-type: none"> • OSn-1-PE1 (WDM facility associated with slot-1 amplifier) • OSn-19-PE1 (WDM facility associated with slot-19 amplifier) <ul style="list-style-type: none"> • n = 1...4, 25, 26 <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> • FBRTYPE = SMF (single-mode fiber), <ul style="list-style-type: none"> • ELEAF (enhanced large affective area fiber), • TW-C (TrueWave® classic fiber), • TW-RS (TrueWave reduced slope fiber), • TW-P (TrueWave plus fiber) • FBRLen = 0...210.00 (km) <p>Example: ED-TELINK:FUJITSU:OS1-1-PE1:CTAG::: FBRTYPE=SMF,FBRLen=40.0;</p>	<p>In the tree view: Click the Facilities tab. Expand the appropriate shelf. Expand the appropriate WDM facility. Select the TELINK entity for the WDM facility.</p> <p>Entity ▶ Operations Dialog</p> <p>Select the Modify tab</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • Select a value from the FBRTYPE pull-down menu. • Enter a value for the FBRLen parameter. • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 14

Verify that the provisioned values are correct.

TL1	NETSMART 500
RTRV-TELINK:TID:AID:CTAG; AID: <ul style="list-style-type: none"> • Same value used in previous step. Example: RTRV-TELINK:FUJITSU:OS1-1-PE1:CTAG;	In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct. Do not close the Operations dialog box.

Provision Fiber Loss

Step 15

Set one of the following parameters to provision fiber loss:

- FBRLOSS (measured fiber loss, dB)
- LCOEFF (fiber loss coefficient, dB/km)

Note: Do not set both parameters. The next step describes how the system uses this information to compute fiber loss.

TL1	NETSMART 500
ED-TELINK:TID:AID:CTAG:::KEYWORD=DOMAIN; AID: <ul style="list-style-type: none"> • Same value used in previous step. KEYWORD=DOMAIN: <ul style="list-style-type: none"> • FBRLOSS = 0...39.00 (dB) • LCOEFF = 0.17...0.25...3900.00 (dB/km) Example: ED-TELINK:FUJITSU:OS1-1-PE1:CTAG::: LCOEFF=0.5;	In the Command Parameters area of the Operations dialog: <ul style="list-style-type: none"> • Enter a value for FBRLOSS or LCOEFF. • Click Modify. Do not close the Operations dialog box.

Step 16

Verify that fiber loss provisioning is correct.

The system calculates COMPFBRLOSS (computed fiber loss) in one of two ways:

- COMPFBRLOS = FBRLOSS (if FBRLOSS is nonzero)
- COMPFBRLOS = LCOEFF*FBRLLEN (if FBRLOSS is zero)

TL1	NETSMART 500
RTRV-TELINK:TID:AID:CTAG; AID: <ul style="list-style-type: none"> • Same value used in previous step. Example: RTRV-TELINK:FUJITSU:OS1-1-PE1:CTAG;	In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct. Do not close the Operations dialog box.

Provision Attenuator Padding

Step 17

If a receive-side attenuator was installed for the network degree, set the value of PADR (receive-side attenuator padding in dB). Otherwise, proceed to the next step.

TL1	NETSMART 500
ED-TELINK:TID:AID:CTAG:::KEYWORD=DOMAIN; AID: <ul style="list-style-type: none"> • Same value used in previous step. KEYWORD=DOMAIN: <ul style="list-style-type: none"> • PADR = 0...32 (dB) Example: ED-TELINK:FUJITSU:OS1-1-PE1:CTAG::: PADR=8;	In the Command Parameters area of the Operations dialog: <ul style="list-style-type: none"> • Enter a value for PADR. • Click Modify. Do not close the Operations dialog box.

Verify Span Loss Provisioning

Step 18

Verify that span loss provisioning is correct.

The system calculates COMPSPANLOSS (computed span loss) in one of two ways, depending on whether repair margin was provisioned using RPRMRGN or RPRMRGNDB:

- $COMPSPANLOSS = COMPFBRLOSS * (1 + RPRMRGN/100) + 2 * BULKLOSS + PADR + INDCM$
- OR
- $COMPSPANLOSS = COMPFBRLOSS + RPRMRGNDB + 2 * BULKLOSS + PADR + INDCM$

Note: INDCM is a retrieve-only parameter. Its value depends on the provisioned DCM.

TL1	NETSMART 500
RTRV-TELINK:TID:AID:CTAG; AID: <ul style="list-style-type: none"> • Same value used in previous step. Example: RTRV-TELINK:FUJITSU:OS1-1-PE1:CTAG;	In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct. Do not close the Operations dialog box.

Provision PMD

Step 19

Set one of the following parameters to provision polarization mode dispersion (PMD):

- FBRPDM (measured PMD, ps)
- PMDCOEFF (PMD coefficient, ps/sqrt[km])

Note: Do not set both parameters. The next step describes how the system uses this information to compute fiber PMD.

TL1	NETSMART 500
ED-TELINK:TID:AID:CTAG:::KEYWORD=DOMAIN; AID: <ul style="list-style-type: none"> • Same value used in previous step. KEYWORD=DOMAIN: <ul style="list-style-type: none"> • FBRPDM = 0.00...52.40 (ps) • PMDCOEFF = 0.00...0.15...524.00 (ps/sqrt[km]) Example: ED-TELINK:FUJITSU:OS1-1-PE1:CTAG::: LCOEFF=0.5;	In the Command Parameters area of the Operations dialog: <ul style="list-style-type: none"> • Enter a value for FBRPDM or PMDCOEFF. • Click Modify. Do not close the Operations dialog box.

Step 20

Verify that PMD provisioning is correct.

The system calculates COMPFBRPMD (computed fiber PMD) in one of two ways:

- COMPFBRPMD = FBRPDM (if FBRPDM is nonzero)
- COMPFBRPMD = PMDCOEFF*sqrt(FBRLLEN) (if FBRPDM is zero)

TL1	NETSMART 500
<p>RTRV-TELINK:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">• Same value used in previous step. <p>Example: RTRV-TELINK:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct.</p> <p>Do not close the Operations dialog box.</p>

Step 21

Do you wish to provision chromatic dispersion values?

If you choose to provision chromatic dispersion, three values are required. If you choose not to provision these values, the control plane will calculate chromatic dispersion based on fiber type and fiber length.

If YES:

Proceed to [Step 22](#).

If NO:

Proceed to [Step 24](#).

Provision Chromatic Dispersion

Step 22

Set all three of the following parameters:

- MEASLAMBDA (measured wavelength, nm)
- MEASSPANDISP (measured span dispersion, ps/nm)
- MEASSPANDISPSLOPE (measured span dispersion slope, ps/nm²)

TL1	NETSMART 500
<p>ED-TELINK:TID:AID:CTAG:::KEYWORD=DOMAIN; AID:</p> <ul style="list-style-type: none"> • Same value used in previous step. <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> • MEASLAMBDA = 1530.00...1565.00 (nm) • MEASSPANDISP = 0.00...3600.00 (ps/nm) • MEASSPANDISPSLOPE = 0.00...20.00 (ps/nm²) <p>Example: ED-TELINK:FUJITSU:OS1-1-PE1:CTAG::: MEASLAMBDA=1550.00, MEASSPANDISP=400.00, MEASSPANDISPSLOPE=10.00;</p>	<p>In the Command Parameters area of the Operations dialog:</p> <ul style="list-style-type: none"> • Enter values. • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 23
 Verify that chromatic dispersion provisioning is correct.

TL1	NETSMART 500
<p>RTRV-TELINK:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • Same value used in previous step. <p>Example: RTRV-TELINK:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct.</p> <p>Do not close the Operations dialog box.</p>

Place the TELink in Service

Step 24
 Place the TELink in service.

TL1	NETSMART 500
<p>ED-TELINK:TID:AID:CTAG:::IS; AID:</p> <ul style="list-style-type: none"> • Same value used in previous step. <p>Example: ED-TELINK:FUJITSU:OS1-1-PE1:CTAG:::IS;</p>	<p>Select the State tab</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • Select In Service from the New Prov. State drop-down list. • Click Modify. <p>Do not close the Operations dialog box.</p>

Step 25
 Verify that the TELink is in service.


TL1	NETSMART 500
<p>RTRV-TELINK:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">• Same value used in previous step. <p>Example: RTRV-TELINK:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that values for the provisioned parameters are correct.</p> <p>Close the Operations dialog box.</p>

Step 26

Repeat [Steps 13 through 25](#) for each network degree of the current node. Then proceed to [Step 27](#).

Step 27

Repeat [Steps 2 through 26](#) for each node in the network. Then proceed to [Acceptance Testing](#).

 This procedure is complete.

3

Acceptance Testing

In this chapter:

- 3.1 Test Synchronization Reference Switching
- 3.2 Verify Network Operation

This chapter provides procedures to acceptance test a new FLASHWAVE® 7500 Core Configuration application. These procedures should be performed after all nodes have been turned up (refer to [System Turn-Up](#)).

3.1 Test Synchronization Reference Switching

In this section:

- 3.1.1 Testing Manual Switching of Externally Timed Tributary Shelf
- 3.1.2 Testing Automatic Equipment Protection Switching of Synchronization Units

This section contains procedures for testing the behavior of synchronization timing (OSn-TMGYSYS [n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430]). The procedures apply to each Tributary shelf that includes Synchronization plug-in units.

3.1.1 Testing Manual Switching of Externally Timed Tributary Shelf

This procedure applies only to Tributary shelves timed off the primary external clock.

Expected Results—The Tributary shelf should switch to the secondary external clock input as a result of the command to switch to the secondary source. After releasing the manual switch and manually switching back to the primary source, the reference should switch back to the primary external clock input.



Attention: When entering TL1 commands or NETSMART® 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Perform a manual timing switch to the secondary external clock timing reference.

TL1	NETSMART 500
<pre>OPR-SYNCNSW:TID:AID:CTAG:: SOURCE,MAN; AID: • OSn-TMGSYS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 SOURCE: • OSn-EXTCLKINS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 Example: OPR-SYNCNSW:FUJITSU:OS100-TMGSYS: CTAG::OS100-EXTCLKINS,MAN;</pre>	<p>In the tree view, select the Synchronization tab. Expand tree elements, if required. Select the appropriate TMGSYS entity.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the Sync Switch tab. Click the Operate tab. Select MAN from the SC menu.</p> <p>Select OSn-EXTCLKINS (T1CLK) from the SOURCE menu. Click Operate.</p> <p>Do not close the Operations dialog box.</p>

Step 2

Verify that the timing reference switched to the secondary external clock input.

The STATE of EXTCLKINP should be STBYH. The STATE of EXTCLKINS should be ACT.

TL1	NETSMART 500
<pre>RTRV-SYNCLIST:TID:AID:CTAG; AID: • OSn-TMGSYS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 • ALL (null) Example: RTRV-SYNCLIST:FUJITSU: OS100-TMGSYS:CTAG;</pre>	<p>In the Current Values area of the Operations dialog box, verify the timing reference properties.</p> <p>Close the Operations dialog box.</p>

Step 3

Release the manual switch.

TL1	NETSMART 500
<pre> RLS-SYNCNSW:TID:AID:CTAG; AID: • OSn-TMGSYS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 • ALL (null) Example: RLS-SYNCNSW:FUJITSU: OS100-TMGSYS:CTAG; </pre>	<p>In the tree view, select the Synchronization tab.</p> <p>Expand tree elements, if required.</p> <p>Select the appropriate TMGSYS entity.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>Click the Sync Switch tab.</p> <p>Click the Release tab.</p> <p>Click Release.</p> <p>Close the Operations dialog box.</p>

Step 4

Switch back to the primary external clock input.

TL1	NETSMART 500
<pre> OPR-SYNCNSW:TID:AID:CTAG:: SOURCE,MAN; AID: • OSn-TMGSYS • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 SOURCE: • OSn-EXTCLKINP • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 Example: OPR-SYNCNSW:FUJITSU:OS100-TMGSYS: CTAG::OS100-EXTCLKINP,MAN; </pre>	<p>In the tree view, select the Synchronization tab.</p> <p>Expand tree elements, if required.</p> <p>Select the appropriate TMGSYS entity.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>Click the Sync Switch tab.</p> <p>Click the Operate tab.</p> <p>Select MAN from the SC menu.</p> <p>Select OSn-EXTCLKINP (T1CLK) from the SOURCE menu.</p> <p>Click Operate.</p> <p>Do not close the Operations dialog box.</p>

Step 5

Verify that the timing reference switched to the primary external clock input.

The STATE of EXTCLKINP should be ACT. The STATE of EXTCLKINS should be STBYH.

TL1	NETSMART 500
<p>RTRV-SYNCLIST:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • OSn-TMGSYS <ul style="list-style-type: none"> • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 • ALL (null) <p>Example: RTRV-SYNCLIST:FUJITSU: OS100-TMGSYS:CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify the timing reference properties.</p> <p>Close the Operations dialog box.</p>

Step 6

Release the manual switch.

TL1	NETSMART 500
<p>RLS-SYNCNSW:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • OSn-TMGSYS <ul style="list-style-type: none"> • n = 10...13, 20...23, 30...33, 40...43, 100, 101, 110, 111, 120, 130, 200, 201, 210, 211, 220, 230, 300, 301, 310, 311, 320, 330, 400, 401, 410, 411, 420, 430 • ALL (null) <p>Example: RLS-SYNCNSW:FUJITSU: OS100-TMGSYS:CTAG;</p>	<p>In the tree view, select the Synchronization tab.</p> <p>Expand tree elements, if required.</p> <p>Select the appropriate TMGSYS entity.</p> <div style="border: 1px solid gray; padding: 2px; width: fit-content; margin: 5px 0;">Entity ▶ Operations Dialog</div> <p>The Operations dialog box opens.</p> <p>Click the Sync Switch tab.</p> <p>Click the Release tab.</p> <p>Click Release.</p> <p>Close the Operations dialog box.</p>

Step 7

Proceed to [Testing Automatic Equipment Protection Switching of Synchronization Units](#).

3.1.2

Testing Automatic Equipment Protection Switching of Synchronization Units

This procedure tests automatic switching to the standby timing unit upon removal (or failure) of the active Synchronization unit from a Tributary shelf.

Step 1

Determine which Synchronization plug-in unit is currently active and which is in standby.

The FAIL/SVCE indicator is lit green if the Synchronization plug-in unit is active. If the Synchronization plug-in unit is in standby, the FAIL/SVCE indicator is off.

Synchronization plug-in units are in slots 10 and 12 of the Tributary shelf.

Step 2

Unplug the active Synchronization plug-in unit from the Tributary shelf.

Step 3

Verify that the FAIL/SVCE indicator of the standby Synchronization plug-in unit lights green and an EQPT-RMVD condition is raised.

Step 4

Reinstall the Synchronization plug-in unit.

Step 5

Verify that the EQPT-RMVD condition clears. The Synchronization plug-in unit that became active in [Step 3](#) will remain active because the protection switching is nonrevertive.

Step 6

To switch back to the original active Synchronization plug-in unit, repeat [Steps 2 through 5](#).

Step 7

Repeat all subprocedures in [Test Synchronization Reference Switching](#) for each Tributary shelf containing Synchronization plug-in units.

Step 8

Proceed to [Verify Network Operation](#).

3.2

Verify Network Operation

Before accepting a newly turned-up network, you should verify its operation by provisioning representative services on the network and testing those services. Procedures for service addition and testing are given in [Service Addition](#) and [Acceptance Testing](#).

The choice of services depends on local practice and available equipment. Fujitsu recommends the following guidelines:

- Choose services that are representative of the types of services that the network is expected to support

Example:

If the network is to support OCh-DPRING-protected services, include OCh-DPRING-protected services so that protection switching is verified.

- Ensure that the services test each span within the network bidirectionally
- Ensure that services test both extremes of the DWDM spectrum: Channel 1 and Channel 40

Note: Long-term bit error rate testing can be accomplished without test sets using the PRBS test signal connection feature of certain FLASHWAVE 7500 OLCs. Refer to [Apply PRBS Test Signal Connection in Testing](#).

4

ILA Node Turn-Up

In this chapter:

- 4.1 About System Turn-up Core Configuration ILA Node
- 4.2 Apply Power and Install Fan Units
- 4.3 Install Primary NE Management Units, and Configure the ILA Shelf
- 4.4 Provision System-Level Parameters, LCN Port, and GOS
- 4.5 Provision ILA Shelf Equipment and Facilities
- 4.6 Install Intrashelf Fiber-Optic Cables
- 4.7 Connect DCMs or Install Loopback Cables

4.1


About System Turn-up Core Configuration ILA Node

This chapter describes how to turn-up a FLASHWAVE® 7500 Core Configuration in-line amplifier (ILA) node.

ILA Node Turn-Up Flowchart

The flowchart in the following figure shows the turn-up sequence for an ILA node.

Note: *This chapter does not include steps to connect the ILA node to the network. Network connections are made after all nodes are turned up as presented in [ILA Node Turn-Up Flowchart](#).*



m1718ec_10

Figure 98: ILA Node Turn-Up (Procedure Flowchart)

Prerequisites

Before proceeding with ILA node turn-up procedures, perform or verify the following:

- Review the node turn-up procedure shown in the preceding figure.
- Familiarize yourself with the provisioning hierarchy for the FLASHWAVE 7500 Core Configuration system ([Turn-Up Provisioning Hierarchy FLASHWAVE 7500–Core Configuration](#)).

- Verify that the FLASHWAVE 7500 shelves are installed and that the acceptance procedures listed in [Introduction to Equipment Installation](#), have been completed.
- Ensure that fiber has been placed between the sites.
- Familiarize yourself with the FLASHWAVE 7500 system as described in [Introduction to the FLASHWAVE 7500 All-Optical Transport Platform](#).
- Familiarize yourself with the NETSMART® 500 Element Manager for provisioning the FLASHWAVE 7500 system. Refer to *FNC-0500-0311-010, NETSMART 500 User Guide*.
- Ensure that a terminal emulator (such as a HyperTerminal emulator) is available, and familiarize yourself with its operation.
- Familiarize yourself with the FLASHWAVE 7500 access identifiers (AIDs) described in [Access Identifiers](#).
- Ensure that the craft interface device is connected, activated, and set up in the required interface modes as described in [Craft Interface Operations](#).
- Refer to [Introduction to Maintenance and Trouble Clearing](#), for general procedures and information on replacing plug-in units and handling optical units and optical fibers.
- Refer to [Introduction to TL1 Commands](#) for additional command and parameter information and typical response messages.
- Perform initial turn-up procedures locally through the craft interface provided on the front of the shelf.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Warning: When handling FLASHWAVE 7500 plug-in units, wear an ESD wrist strap with a minimum resistance of 1000 kilohms to prevent possible damage to the units. Before using the strap, check it for opens, shorts, and minimum resistance value. If the strap does not pass these checks, do not use it.



Caution: Verify that you have received a completed (COMPLD) response to each command before going to the next step. If you are unable to complete a command after several tries, call Fujitsu at 1-800-USE-FTAC for technical assistance.



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to *Fiber Cable Handling*.

Note: Until it is fully provisioned, the FLASHWAVE 7500 will generate false alarms. These alarms clear as the system is provisioned. Any remaining alarms are cleared (other than LOS, if applicable) at the end of the turn-up procedure.

Slot Labels and AIDs

The following figure shows and the following table describes plug-in unit slot labels, AIDs, locations, and equipment type and AID mapping on the ILA shelf. Refer also to [Access Identifiers](#).




Figure 99: ILA Shelf Plug-In Unit Slot Labels and Slot AIDs

Table 60: ILA Shelf Equipment Type and Slot AID Mapping

Slot Label	Slot AID	Equipment Type	Default Type
n/a	OS1	SHU3 (Shelf)	SHU3
1	OS1-1	APMA-L2C1	APMA-M2C1
2	OS1-2 (AID not used)	APMA-M2C1 APMA-ULC1 APMA-M2U1 APMA-ULU1 APMA-MHU2	
3	OS1-3	Slot not used	n/a
4	OS1-4	Slot not used	n/a
5	OS1-5	Slot not used	n/a
6	OS1-6	Slot not used	n/a

Table 60: ILA Shelf Equipment Type and Slot AID Mapping (Cont.)

Slot Label	Slot AID	Equipment Type	Default Type
7	OS1-7	Slot not used	n/a
8	OS1-8	Slot not used	n/a
9	OS1-9	SCMA-SCC4	SCMA-SCC4
10	OS1-10	Slot not used	n/a
MPMA-1	OS1-MPMA-1	MPMA-SHP3 MPMA-SHP4	MPMA-SHP3
MPMA-2	OS1-MPMA-2	Slot not used	n/a
11	OS1-11	SCMA-SCC4	SCMA-SCC4
12	OS1-12	Slot not used	n/a
13	OS1-13	Slot not used	n/a
14	OS1-14	Slot not used	n/a
15	OS1-15	Slot not used	n/a
16	OS1-16	Slot not used	n/a
17	OS1-17	Slot not used	n/a
18	OS1-18	Slot not used	n/a
19	OS1-19	APMA-L2C1 APMA-M2C1	APMA-M2C1
20	OS1-20 (AID not used)	APMA-ULC1 APMA-M2U1 APMA-ULU1 APMA-MHU2	
Leftmost fan slot	OS1-FAN-1	FAN6	FAN6
Second from left	OS1-FAN-2		
Second from right	OS1-FAN-3		
Rightmost fan slot	OS1-FAN-4		

Note: Amplifiers plug-in units in slots 1 and 19 should match in type.

4.2

Apply Power and Install Fan Units

Note: The fan plug-in units are equipped with preinstalled fan filters.

Apply power to the shelf and install fan plug-in units as follows:

Step 1

Apply power to the shelf as follows:

- a) Ensure that power is available at the rack as indicated by illumination of the green PWR indicators on the power distribution panel at the top of the rack.
- b) Set the appropriate circuit breaker at the distribution panel to the ON position to apply power to the shelf.

Step 2

Install fan plug-in units in the shelf as follows:

- a) Inspect the fan plug-in unit for possible damage or debris.
- b) Verify that a fan filter is installed in the fan plug-in unit. The following figure shows the fan filter location.




Figure 100: Fan Filter Location

- c) Slide the fan plug-in unit into one of the fan slots located at the bottom of the shelf.
- d) Ensure that the FAIL/SVCE indicator is lit green.
- e) Repeat until four fan plug-in units are installed in the shelf.

Step 3

Proceed to [Install Primary NE Management Units, and Configure the ILA Shelf.](#)

4.3

Install Primary NE Management Units, and Configure the ILA Shelf

In this section:

- 4.3.1 Install MPMA-SHPx Plug-In Unit
- 4.3.2 Verify Software Version
- 4.3.3 Change System Type
- 4.3.4 Provision Shelf Location Identifiers
- 4.3.5 Provision OSC Units

Prerequisites:

If not already done, complete the procedures in [Apply Power and Install Fan Units](#).

If using the NETSMART 500 Element Manager for provisioning, be sure the computer meets or exceeds the following system requirements (refer to *FNC-0500-0311-010, NETSMART 500 User Guide*):

- Microsoft® operating system:
 - Windows NT® 4.0 (Service Pack 5 and later)
 - Windows 2000
 - Windows XP Professional
- 250 MHz Pentium® processor (1 GHz or faster recommended)
- 128 MB RAM (512 MB RAM recommended)
- 150 MB disk space (minimum)
- CD drive
- LAN card and/or serial craft interface port and connection cable
- 8-bit color (256 colors) minimum (16-bit color recommended)
- 800 by 600 resolution (optimized for 1024 by 768 or larger resolution)
- Web browser:
 - Internet Explorer version 5.5 or later
 - Netscape® version 4.7 (complete installation) or later

Initially, due to factory default settings, the shelf does not behave as an ILA shelf. It becomes an ILA shelf after the system keyword TYPE is changed from the default value (FW7500TRIB) to FW7500U_ILA ([Step 7](#)).

The steps in [Verify Software Version](#), ensure that the NEM Shelf Processor unit (MPMA-SHPx) installed in slot MPMA-1 is running the correct software version. When additional OSC plug-in units are installed, the system will automatically update the software on these units, if necessary, to match the software running on the NEM installed in slot MPMA-1.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Note: For plug-in unit slot locations, refer to [About System Turn-up Core Configuration ILA Node](#).

Note: Default values are shown in bold.

This procedure shows how to install the NE management unit and configure the ILA shelf.

4.3.1

Install MPMA-SHPx Plug-In Unit

Step 1

Install the MPMA-SHPx plug-in unit in the shelf as follows:

- a) Inspect the unit for possible damage or debris.
- b) Install the unit into slot MPMA-1 of the shelf.

The NOT READY and FAIL/SVCE indicators should immediately light amber.

Note: If the NOT READY and FAIL/SVCE indicators do not light amber, verify that wiring to the PWR terminal in the rear of the shelf is correct, remove the plug-in unit, then repeat [Step 1](#).

After 5 to 20 minutes, the amber NOT READY and FAIL/SVCE indicators should go out, and the FAIL/SVCE indicator should light green.

Step 2

After waiting up to 20 minutes, did the FAIL/SVCE indicator on the MPMA-SHPx plug-in unit light green?

IF YES:

Proceed to [Step 3](#).

If NO:

The NEM Shelf Processor unit may be defective. Remove the unit and set it aside for repair paperwork processing. Obtain another NEM Shelf Processor plug-in unit. Return to [Step 1](#) and repeat this procedure on that NEM Shelf Processor unit.

Step 3

Establish a craft interface connection through connector TERM1 or TERM2 on the front of the shelf. Refer to the following table for set-up procedures.

Table 61: Craft Interface Set-Up Procedures

Type of User Interface	Craft Interface Connector	Set-Up Procedure
TL1 user interface	TERM1 (Serial)	Setting Up Craft Interface (TL1 Session through TERM1)
	TERM 2 (LAN, TCP/IP)	Setting Up Craft Interface (TL1 Session through TERM2)
NETSMART 500 user interface	TERM1 (Serial)	Setting Up Craft Interface (NETSMART 500 Session through TERM1)
	TERM 2 (LAN, TCP/IP)	Setting Up Craft Interface (NETSMART 500 Session through TERM2)

Note: A TERM1 (serial) connection allows for continuous connectivity between the craft interface and the NE. With a TERM2 (TCP/IP) connection, the communication link between the craft interface and the NE is severed when the INIT-SYS and INIT-OIF commands are processed. The severing of the communication link requires you to reestablish your logon session with the NE.

Step 4

Log on the NE.

Note: At this stage, you can only log on the NE using the factory default values for the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface connection, which should have been completed in the previous step.

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p> <p>ACT-USER : TID : UID : CTAG : : PID ; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value)</p> <p>Example: ACT-USER : FUJITSU : ROOT : CTAG : : ROOT ;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500
	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default⁴⁸</p> <p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p> <p>Click Logon. The NETSMART 500 NE View opens. The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>

4.3.2 Verify Software Version

Step 5
 Retrieve the software version information.

TL1	NETSMART 500
<p>RTRV-VERSION:TID::CTAG ;</p> <p>Example: RTRV-VERSION:FUJITSU::CTAG ;</p>	<p>The Shelf Provisioning Mode dialog box opens.⁴⁹ Click OK.</p> <p>In the Current Values area of the Operations⁵⁰ dialog box, determine the value of the Active GISSUE.</p> <p>Do not close the Operations dialog box.</p>

Step 6
 Is the active GISSUE correct?

⁴⁸ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

⁴⁹ The Shelf Provisioning Mode dialog only appears when logging on to a factory default shelf.

⁵⁰ Upon logging on a factory default shelf, the Operations dialog is automatically opened with the NE Type tab selected. However, if the Operations dialog box does not open automatically, select System Operations from the NE menu and, after the Operations dialog box appears, click the Attributes tab, then the NE Type tab.

The correct GISSUE value for FLASHWAVE 7500 Release 9.1 software is 09-01-1.

If YES:

Proceed to [Step 7](#).

If NO:

Upgrade the system software as described in [Upgrading System Software Using TL1 Commands](#) or [Upgrading System Software Using NETSMART 500 Software Download Wizard](#), then repeat this subprocedure.

4.3.3

Change System Type

Step 7

Change system type from FW7500TRIB to FW7500U_ILA.

Note: This command terminates the communication session and restarts the NE.

TL1	NETSMART 500
<pre>ED-SYS:TID::CTAG:::TYPE=FW7500U_ILA;</pre> <p>Example: ED-SYS:FUJITSU::CTAG::: TYPE=FW7500U_ILA;</p>	<p>In the Operations dialog box:</p> <ul style="list-style-type: none">• Select the NE Type tab• From the Type drop-down list, select FW7500U_ILA.• Click Modify. <p>The Confirmation dialog box opens. Click OK.</p>

The NOT READY indicator on the NEM Shelf Processor plug-in unit lights amber and then goes out after 5 to 20 minutes. After the NOT READY indicator goes out, the FAIL/SVCE indicator lights green on the NEM Shelf Processor unit.

Step 8

After the NOT READY indicator goes out and the FAIL/SVCE indicator lights green and stays green, proceed to [Step 9](#).

Step 9

Log on the NE.

Note: At this stage, you can only log on the NE using factory default values of the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Craft Interface Operations](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X. For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p>														
<pre>ACT-USER:TID:UID:CTAG::PID; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value) Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</pre>	<p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT</td> <td>Password: ROOT</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default⁵¹</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT	Password: ROOT	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT	Password: ROOT														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

Step 10
 Reinitialize the system software.

Note: This command automatically logs the user off the NE.

⁵¹ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<pre>INIT-SYS:TID:AID:CTAG:::LEVEL=WARM; AID: • ALL (null) Example: INIT-SYS:FUJITSU::CTAG:::LEVEL=WARM;</pre>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click Initialize tab. Click the NE tab. Select Level: WARM. Click Initialize.</p> <p>Click Yes in the pop-up window to continue.</p> <p>If a second pop-up window opens, the connection is lost, and you must log on the NETSMART 500 user interface again to continue by clicking Logon.</p>

The NOT READY indicator on the NEM Shelf Processor plug-in unit lights amber and then goes out after 5 to 20 minutes. After the NOT READY indicator goes out, the FAIL/SVCE indicator lights green on the NEM Shelf Processor unit.

Step 11



After the NOT READY indicator goes out and the FAIL/SVCE indicator lights green and stays green, proceed to [Step 12](#).

Step 12

Log on the NE.

Note: At this stage, you can only log on the NE using factory default values of the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Craft Interface Operations](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X. For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p>														
<pre>ACT-USER:TID:UID:CTAG::PID; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value)</pre>															
<p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p>														
															
	<p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p>														
	<p>The NE Logon dialog box opens. Make the following selections:</p>														
	<table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT</td> <td>Password: ROOT</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default⁵²</p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT	Password: ROOT	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT	Password: ROOT														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														
	<p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p>														
	<p>The Security Message dialog box opens. Click OK.</p>														
	<p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>														

Step 13

Following local practice, do you want to provision shelf location identifiers?

Note: Shelf location identifiers, *SHELFLBL* and *USERLBL*, are optional parameters that precisely identify the location of equipment. If provisioned, the values appear in equipment retrieval and alarm messages. The *SHELFLBL* value indicates the physical location of the bay and shelf. The *USERLBL* value indicates the frame

⁵² The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

identification code (FIC). Telcordia® NMA® OSMINE™ users should keep the SHELFLBL and USERLBL parameters values as NULL (default). For more information, refer to [Shelf Location Identifiers](#).

IF YES:
 Proceed to [Step 14](#).

IF NO:
 Proceed to [Step 16](#).

4.3.4 Provision Shelf Location Identifiers

Step 14
 Edit the values of shelf location identifiers (SHELFLBL and/or USERLBL).

TL1	NETSMART 500
<pre>ED-EQPT:TID:AID:CTAG::: KEYWORD=DOMAIN:STATE; AID: • OS1 KEYWORD=DOMAIN: • SHELFLBL = Up to 13 characters with each character an uppercase letter (A...Z), number (0...9) (null is default) • USERLBL = Up to 20 characters with each character an uppercase letter (A...Z), number (0...9), or hyphen (-) (null is default)</pre> <p>Example: <pre>ED-EQPT:FUJITSU:OS1:CTAG::: SHELFLBL=MAINSHELF,USERLBL=PLANO;</pre></p>	<p>In the tree view, click the Equipment tab.</p> <p>Expand the appropriate shelf components.</p> <p>Select the equipment component.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>In the Command Parameters area type values into the SHELFLBL and/or USERLBL fields, if required.</p> <p>Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 15
 Verify the values of the shelf location identifiers.

TL1	NETSMART 500
<pre>RTRV-EQPT:TID:AID:CTAG; AID: • As identified in previous step • ALL (null)</pre> <p>Example: <pre>RTRV-EQPT:FUJITSU:OS1:CTAG;</pre></p>	<p>In the Current Values area of the Operations dialog box, verify equipment provisioning.</p> <p>Close the Operations dialog box.</p>

4.3.5 Provision OSC Units

Step 16

Install the OSC (SCMA-SCC4) plug-in units in the appropriate slots (9 and 11) of the shelf. See [Figure 99](#) for slot locations. For each OSC plug-in unit to be installed, do the following:

The NOT READY indicators light amber and then go out after 5 to 20 minutes. Independently, the FAIL/SVCE indicators light green.

Note: The NOT READY indicator remains amber until the backup database is completely copied to the OSC unit. During this time, CPY-MEM and CPY-FILE functions are unavailable and the OSC unit should not be removed.

- a) Inspect the OSC plug-in unit for possible damage or debris.
- b) Slide the OSC plug-in unit into the shelf slot.

Note: Because autoprovisioning is on (by default), the OSC units will begin provisioning when they are inserted into the shelf.

Step 17

Wait until both of the following conditions are met, then proceed to [Step 18](#).

- NOT READY indicators on the OSC plug-in units go out.
- FAIL/SVCE indicators on the OSC plug-in units light green.


Step 18

Ensure that OSC plug-in units are properly provisioned and that the equipment state is IS, Normal (STATE=IS-NR).

TL1	NETSMART 500
<pre>RTRV-EQPT:TID:AID:CTAG; AID: • OS1-9 (slot 9) • OS1-11 (slot 11) Example: RTRV-EQPT:FUJITSU:OS1-9&OS1-11:CTAG;</pre>	<p>In the ILA shelf OS1 graphic view or tree view area, select the equipment slot.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the PRIMARY_STATE is IS.</p> <p>Verify the PRIMARY_STATE_QUALIFIER is NR.</p> <p>Close the Properties dialog box.</p>

Step 19

Proceed to [Provision System-Level Parameters, LCN Port, and GOS](#).

 This procedure is complete.

4.4

Provision System-Level Parameters, LCN Port, and GOS

In this section:

- 4.4.1 Provision System-Level Parameters
- 4.4.2 Provision LCN Port
- 4.4.3 Provision GOS

4.4.1

Provision System-Level Parameters

This subprocedure includes steps to set the NE target identifier (TID), change the date and time, and enter new users.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

If not already done, complete the procedures in [Install Primary NE Management Units, and Configure the ILA Shelf](#).

Step 2

If not already done, log on the NE.

Note: At this stage, you can only log on the NE using factory default values of the target identifier (TID), user identifier (UID), and private identifier (PID). TID, UID, and PID values are not case-sensitive.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Craft Interface Operations](#).

TL1	NETSMART 500														
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen appears. Press 3 for TL1.</p> <pre>ACT-USER:TID:UID:CTAG::PID; TID: FUJITSU (factory default value) UID: ROOT (factory default value) PID: ROOT (factory default value)</pre> <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: <i>If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</i></p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial):</td> <td>For TERM2 (TCP/IP):</td> </tr> <tr> <td>TID: FUJITSU</td> <td>TID: FUJITSU</td> </tr> <tr> <td>User ID: ROOT</td> <td>User ID: ROOT</td> </tr> <tr> <td>Password: ROOT</td> <td>Password: ROOT</td> </tr> <tr> <td>Conn. Mode: Serial</td> <td>Conn. Mode: TCP/IP</td> </tr> <tr> <td>Comm. Port: COMx (for example, COM2)</td> <td>IP Address: 192.168.1.1</td> </tr> <tr> <td></td> <td>Port: 2024</td> </tr> </table> <p>Configure: use default⁵³</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: <i>Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</i></p>	For TERM1 (Serial):	For TERM2 (TCP/IP):	TID: FUJITSU	TID: FUJITSU	User ID: ROOT	User ID: ROOT	Password: ROOT	Password: ROOT	Conn. Mode: Serial	Conn. Mode: TCP/IP	Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1		Port: 2024
For TERM1 (Serial):	For TERM2 (TCP/IP):														
TID: FUJITSU	TID: FUJITSU														
User ID: ROOT	User ID: ROOT														
Password: ROOT	Password: ROOT														
Conn. Mode: Serial	Conn. Mode: TCP/IP														
Comm. Port: COMx (for example, COM2)	IP Address: 192.168.1.1														
	Port: 2024														

Step 3

Inhibit the autonomous messages.

Note: *This step does not apply if you are using the NETSMART 500 user interface.*



Caution: *Ensure that the autonomous messages are allowed after these procedures have been completed. Failure to allow the autonomous messages could cause loss of traffic or the ability to detect remote troubles.*

⁵³ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
INH-MSG-ALL:TID::CTAG; Example: INH-MSG-ALL:FUJITSU::CTAG;	n/a

Note: Autonomous messages are inhibited until [Step 3](#), when the command is entered to allow autonomous messages.

Step 4

Change the system identifier (SID) from the default value, *FUJITSU*, to a unique identifier. This identifier acts as the shelf address in the network. The new SID must be from 7 to 20 alphanumeric characters. Hyphens are allowed.

Note: Allow approximately 20 seconds after completion of the command before verifying the new SID.

TL1	NETSMART 500
SET-SID:TID::CTAG::SID; TID: <ul style="list-style-type: none"> Existing system ID SID: <ul style="list-style-type: none"> New system ID Example: SET-SID:FUJITSU::CTAG::FUJITSU1;	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">NE ▶ System Operations</div> <p>The Operations dialog box opens. Click the Attributes tab. Click System ID tab.</p> <p>In the Command Parameters area, enter the new system identifier (SID). Click Modify.</p> <p>Click Yes in the pop-up window to continue.</p> <p>A second pop-up window will indicate that the connection has been lost. You will have to log on the NETSMART 500 user interface again to continue.</p> <p>Note: If using <i>TERM1</i> (serial connection), the second pop-up window will not appear, you will not be logged off, and you will not need to log on again. In the tree view, verify the new SID. Proceed to Step 6. Click Logon.</p>

Step 5

Verify the new SID.

Note: NETSMART 500 users should wait approximately 20 seconds before attempting to log on the NE using the new SID.

TL1	NETSMART 500		
<p>RTRV-HDR:TID::CTAG; TID:</p> <p>New system ID</p> <p>Note: The TID is the same as the SID set in the previous step.</p> <p>Example: RTRV-HDR:FUJITSU1::CTAG;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft Windows platform, select the following from the Windows task bar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard appears.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> For TERM1 (Serial): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default⁵⁴ </td> <td style="width: 50%; vertical-align: top;"> For TERM2 (TCP/IP): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024 </td> </tr> </table> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 graphical user interface.</p> <p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the System ID tab. Verify the value of SID. Close the Operations dialog box.</p>	For TERM1 (Serial): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default ⁵⁴	For TERM2 (TCP/IP): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default ⁵⁴	For TERM2 (TCP/IP): TID: Use new SID User ID: ROOT Password: ROOT Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 6

Set the system date, time, and time zone.

Note: If TZONE is set to a value with DT (that is, xxxxxDT), the time is adjusted automatically for Daylight Saving Time, and a REPT EVT COM message is generated when the adjustment occurs.

⁵⁴ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

Note: Enter the date in the format YYYYMMDD (year/month/day) and the time in the 24-hour format HHMMSS (hour/minute/second).

TL1	NETSMART 500
<pre>SET-DAT:TID::CTAG::DATE, TIME: KEYWORD=DOMAIN; DATE: • YYYYMMDD TIME: • HHMMSS KEYWORD=DOMAIN: • Refer to the following table. Example: SET-DAT:FUJITSU::CTAG:: 990727,050958:TZONE=CST6CDT;</pre>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Time tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • Enter the date (YYYYMMDD). • Enter the time (HHMMSS). • Select a time zone (Refer to the following table). <p>Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Table 62: SET-DAT Keyword and Domain Input Parameters

Keyword	Domain (Default in Bold)	Description
TZONE	NODST	Disables the Daylight Saving Time feature
	NSTNDT	Newfoundland time zone
	AST4	Atlantic time zone
	AST4ADT	
	EST5 EST5EDT ⁵⁵	Eastern time zone
	CST6 CST6CDT ⁵⁵	Central time zone
	MST7 MST7MDT ⁵⁵	Mountain time zone
	PST8 PST8PDT ⁵⁵	Pacific time zone
	AKST9 AKST9AKDT ⁵⁵	Alaska time zone
	HST10	Hawaii time zone
	GMT	Greenwich mean time

Step 7

Verify the system date, time, and time zone.

⁵⁵ Enables automatic Daylight Saving Time adjustment

TL1	NETSMART 500
RTRV-DAT:TID::CTAG; Example: RTRV-DAT:FUJITSU::CTAG;	In the Current Values area of the Operations dialog box, verify that the updated information is correct. Close the Operations dialog box.

Step 8

Do you want to change from the default basic security mode to the enhanced security mode?

Note: For more information about the basic and enhanced security modes, refer to [Security](#).

Note: Changing the security level is allowed only by Level 4 users.

IF YES:
 Continue with [Step 9](#).

IF NO:
 Proceed to [Step 14](#).

Step 9

Change the basic security mode to the enhanced security mode.

TL1	NETSMART 500
ED-DFLT-SECU:TID::CTAG::: SECULVL=ENHANCED; Example: ED-DFLT-SECU:FUJITSU::CTAG::: SECULVL=ENHANCED;	<div style="border: 1px solid gray; padding: 2px; background-color: #f0f0f0; display: inline-block;">NE ▶ System Operations</div> The Operations dialog box opens. Click the Security tab. Click the Settings tab. Select Enhanced from the SECULVL drop-down list. Click Modify. Do not close the Operations dialog box.

Step 10

Verify that the security mode has changed to the enhanced security mode.

TL1	NETSMART 500
RTRV-DFLT-SECU:TID::CTAG; Example: RTRV-DFLT-SECU:FUJITSU::CTAG;	In the Current Values area of the Operations dialog box, verify that the updated information is correct.

Step 11

Do you want to change the default Fujitsu security warning message banner to a customized warning message banner?

If YES:
 Continue with the next step.

If NO:
 Proceed to [Step 14](#).

Step 12

Enter the customized warning message banner information.

TL1	NETSMART 500
<pre>ED-DFLT-SECU:TID::CTAG:::WARN=;</pre> <p>Example: <pre>ED-DFLT-SECU:FUJITSU::CTAG::: WARN=\"THIS COMPUTER IS FOR SECURITY PERSONAL ONLY, AUTHORIZED USE REQUIRED\";</pre></p>	<p>NE ▶ Security Administration</p> <p>The Security Administration dialog box opens. Click the Settings tab.</p> <p>Click the WARN box and then enter required banner warning message in text box. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 13

Verify the warning message banner has changed.

TL1	NETSMART 500
<pre>RTRV-DFLT-SECU:TID::CTAG;</pre> <p>Example: <pre>RTRV-DFLT-SECU:FUJITSU::CTAG;</pre></p>	<p>In the Current Values area of the Operations dialog box, verify that the updated information is correct.</p> <p>Close the Operations dialog box.</p>

Step 14

If required, enter additional security information (new users and privilege levels).

Note: The maximum number of UIDs in the system is 100. This command will be denied if the number of UIDs exceeds 100.

TL1	NETSMART 500
<p>ENT-SECU-USER:TID:UID:CTAG::PID,, UPC:KEYWORD=DOMAIN; UID:</p> <ul style="list-style-type: none"> User identifier for new user (4 to 10 alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> Private identifier: <ul style="list-style-type: none"> BASIC mode—6 to 10 characters, including at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. ENHANCED mode—10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID. <p>UPC:</p> <ul style="list-style-type: none"> User privilege code (1, 2, 3, or 4, with Level 4 allowing greatest access to commands) <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> TMOUTA = Y, N (Y enables automatic logoff after the specified number of minutes of user inactivity. N disables automatic logoff.) TIMEOUT = 5...10...30...60 (time-out period in minutes when TMOUTA=Y; defaults are 30 minutes for BASIC mode and 10 minutes for ENHANCED mode.) UAGE = 1...90, 99 (The UID aging interval expressed in days. UAGE=99 disables UAGE.) PAGE = 25...90, 99 (The PID aging interval expressed in days. PAGE=99 disables PAGE.) <p>Example: ENT-SECU-USER:FUJITSU:ROOT: CTAG::NEWPID9,,2:TMOUTA=N;</p>	<p>NE ▶ Security Administration ▶ User tab ▶ Create</p> <p>Enter the new user ID in the UID field.</p> <p>Enter the password in the PID field.</p> <p>Select the user privilege code (1...4) in the UPC field.</p> <p>In the TMOUTA field, select True to enable automatic time-out or False to disable automatic time-out.</p> <p>If automatic time-out is enabled, enter the time-out period (5...60 minutes) in the TIMEOUT field.</p> <p>Select the UID aging interval (1...90, 99) from the UAGE pull-down menu.</p> <p>Select the PID aging interval (25...90, 99) from the PAGE pull-down menu.</p> <p>Click Create.</p>

Step 15

If security information was added in the previous step, verify the new users and privilege levels.

TL1	NETSMART 500
<p>RTRV-SECU-USER:TID:UID:CTAG; UID:</p> <ul style="list-style-type: none"> User identifier (4 to 10 alphanumeric characters) <p>Example: RTRV-SECU-USER:FUJITSU:BILL:CTAG;</p>	<p>In the tree view, click the Users tab.</p> <p>If necessary, expand the tree view to show the new users added. Select the new user.</p> <p>Entity ▸ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the properties for the given user.</p> <p>Close the Properties dialog box.</p>

Step 16

Set the system contact and location information, if required.

TL1	NETSMART 500
<p>ED-SYS:TID::CTAG:::KEYWORD=DOMAIN; KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> CONTACT = \"up to 40 characters\" LOCATION = \"up to 40 characters\" <p>Example: ED-SYS:FUJITSU::CTAG::: CONTACT= \"BILLJONES\" , LOCATION= \"HINSDALE\" ;</p>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab.</p> <p>In the Command Parameters area, enter required information in CONTACT and LOCATION fields. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 17

Verify the system contact and location information.

TL1	NETSMART 500
<p>RTRV-SYS:TID::CTAG;</p> <p>Example: RTRV-SYS:FUJITSU::CTAG;</p>	<p>In the Current Values area of the Operations dialog box, verify that the updated information is correct.</p> <p>Close the Operations dialog box.</p>

Step 18

Do you wish to provision the LCN port to allow remote provisioning over the data network?

If YES:

Proceed to [Provision LCN Port](#).

If NO:

Proceed to [Provision GOS](#).

4.4.2

Provision LCN Port

Provisioning the local communications network (LCN) port involves setting the IP address of the operations support system (OSS) port, placing the LCN port in service (using the ED-LAN command), and finally issuing the INIT-OIF command to enable pending provisioning changes by the system.

The following LCN provisioning restrictions apply:

- The MASK cannot take the following values: 0.0.0.0 or 255.255.255.255.
- The following IP addresses cannot be assigned as the NE IP address:
 - 0.0.0.0 (use of this IP address is allowed but will delete the IP interface)
 - 255.255.255.255
 - 127.xxx.xxx.xxx
 - 224.xxx.xxx.xxx through 239.xxx.xxx.xxx (Class D—not for normal use)
- The NE IP address cannot be the same as the one provisioned by the ENT-CIDR-ROUTE command.
- When the LCN port is used as part of the default gateway (via the ENT-CIDR-ROUTE command), its IP address cannot be changed.

Step 1

If not already done, complete the system parameter provisioning procedures in [Provision System-Level Parameters](#).

Step 2

Set the IP address and mask of the LCN port.

Note: See your System Administrator for valid IP addresses that can be used on your network.

TL1	NETSMART 500
<pre>ED-IP-ADDR:TID:LCN:CTAG::: KEYWORD=DOMAIN; KEYWORD=DOMAIN:</pre> <ul style="list-style-type: none"> MASK = xxx.xxx.xxx.xxx (xxx = 0...255), 255.255.255.0 IP = xxx.xxx.xxx.xxx (xxx = 0...255), 0.0.0.0 PORT = 1024...2024...65535 <p>Example: ED-IP-ADDR:FUJITSU:LCN:CTAG::: MASK=255.255.255.128, IP=123.255.255.121,PORT=2024;</p>	<p>In the tree view, click the Communications tab. Select <i>LCN (IP)</i>.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Enter the IP address (IP) for the NE. Enter the IP subnet mask (MASK). Enter the Transmission Control Protocol (TCP) port number (PORT). <p>Click Modify.</p> <p>A confirmation dialog box opens.</p> <p>Click Yes to close the confirmation dialog box and continue.</p> <p>Close the Operations dialog box.</p>

Step 3

Place LCN port in service (IS state).

TL1	NETSMART 500
<pre>ED-LAN:TID:LCN:CTAG:::KEYWORD=DOMAIN :IS; KEYWORD=DOMAIN:</pre> <ul style="list-style-type: none"> TARP = Y, N SIZE = 86...1518 LSAP = FE OSI = Y, N IPFWD = Y, N NETID = Character string of up to 20 alphanumeric delineated by escape quotes (\") <p>Example: ED-LAN:FUJITSU:LCN:CTAG::: SIZE=150:IS;</p>	<p>In the tree view, click the Communications tab.</p> <p>Expand the parent LCN component by clicking the plus sign (+) to the left of <i>LCN (IP)</i>.</p> <p>Select the LCN (LAN) component.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select IS from the STATE drop-down list. Make additional parameter modifications as required. <p>Click Modify.</p> <p>A confirmation dialog box opens.</p> <p>Click Yes to close the confirmation dialog box and continue.</p> <p>Close the Operations dialog box.</p>

Step 4

Enter default gateway if required.

Note: Preconditions are associated with the ENT-CIDR-ROUTE command. Refer to [Enter CIDR Route \(ENT-CIDR-ROUTE\)](#), for a list of preconditions, restrictions and keywords associated with the ENT-CIDR-ROUTE command.

TL1	NETSMART 500
<pre>ENT-CIDR-ROUTE:TID::CTAG::LCN: KEYWORD=DOMAIN; KEYWORD=DOMAIN: • DESTIP = 0.0.0.0 • DESTMASK = 0.0.0.0 • NEXTHOP = xxx.xxx.xxx.xxx (xxx = 0...255) • METRIC = 0...100...65535</pre> <p>Example: ENT-CIDR-ROUTE:FUJITSU::CTAG:: LCN:DESTIP=0.0.0.0, DESTMASK=0.0.0.0, NEXTHOP=128.167.154.170;</p> <p>Note: The NEXTHOP IP address is the same as the gateway IP address.</p>	<p>NE ▶ Create</p> <p>Select the IP Routes tab. Select the Enter tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none">• Enter the destination IP address (DESTIP).• Enter the destination IP address mask (DESTMASK).• Enter the IP address of the next system on the route (NEXTHOP).• Enter the cost metric of the route (METRIC).• Select LCN from the PORT drop-down list. <p>Click Enter.</p> <p>A confirmation dialog box opens.</p> <p>Click Yes to close the confirmation dialog box and continue.</p>

Step 5

How are you connected to the NE?

TERM1 (serial)— Go to [Step 6](#).

TERM2 (TCP/IP)— Go to [Step 8](#).

Step 6

Initialize the operation interface (OIF) through a TERM1 (serial) connection.

Note: The INIT-OIF command must be executed before the ED-IP-ADDR, ED-LAN, and ENT-CIDR-ROUTE commands become effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG;</pre> <p>Example: INIT-OIF:FUJITSU::CTAG;</p>	<p>NE ▶ System Operations</p> <p>The Operations dialog box opens. Click Initialize tab. Select the Stack tab.</p> <p>In the Command Parameters area:</p> <p>Select OIF from the STACK INIT TYPE drop-down list. Click Initialize.</p> <p>A confirmation dialog box opens.</p> <p>Note: The confirmation message refers to an Initialize Stack operation. The Initialize Stack operation is the initialization of the OSI stack that results from the processing of the INIT-OIF command. Click Yes.</p>

Step 7

Wait 2 minutes, then go to [Step 11](#).

Step 8

Initialize the operation interface (OIF) through a TERM2 connection.

Note: The INIT-OIF command must be executed before the ED-IP-ADDR, ED-LAN, and ENT-CIDR-ROUTE commands become effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID::CTAG;</pre> <p>Example: INIT-OIF:FUJITSU::CTAG;</p>	<p>NE ▸ System Operations</p> <p>The Operations dialog box opens. Click Initialize tab. Select the Stack tab.</p> <p>In the Command Parameters area:</p> <p>Select OIF from the STACK INIT TYPE drop-down list. Click Initialize.</p> <p>A confirmation dialog box opens.</p> <p>Note: The confirmation message refers to an Initialize Stack operation. The Initialize Stack operation is the initialization of the OSI stack that results from the processing of the INIT-OIF command. Click Yes.</p> <p>A connection warning dialog box opens, indicating that the connection has been lost. You will have to log on the NETSMART 500 user interface again when it is time to continue.</p> <p>Click Logon in the pop-up window to continue.</p>

Step 9

Wait 2 minutes before continuing.

Note: The NETSMART 500 software connection to the NE will be lost. After waiting 2 minutes, users should log back on the NE.

Step 10

Log on the NE.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500		
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p> <p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p> <table border="0"> <tr> <td>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</td> <td>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</td> </tr> </table> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default⁵⁶</p> <p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024
For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial	For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024		

Step 11

Verify the IP address and mask of the LCN port.

⁵⁶ The default serial port settings are recommended: baud rate— 9600, parity— none, data bits— 8, stop bits— 1.

TL1	NETSMART 500
<p>RTRV-IP-ADDR:TID:LCN:CTAG;</p> <p>Example: RTRV-IP-ADDR:FUJITSU:LCN:CTAG;</p>	<p>In the tree view, click the Communications tab. Select the <i>LCN (IP)</i> component.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens. Verify the IP address (IP), mask (MASK), and port (PORT) of the LCN port. Close the Properties dialog box.</p>

Step 12

Verify that the LAN is in service.

TL1	NETSMART 500
<p>RTRV-LAN:TID:LCN:CTAG;</p> <p>Example: RTRV-LAN:FUJITSU:LCN:CTAG;</p>	<p>In the tree view, click the Communications tab. Expand the parent LCN component by clicking the plus sign (+) to the left of <i>LCN (IP)</i>. Select the <i>LCN (LAN)</i> component.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens. Verify that the LCN port is in service (STATE: IS). Close the Properties dialog box.</p>

Step 13

Verify the default gateway.

TL1	NETSMART 500
<p>RTRV-CIDR-ROUTE:TID::CTAG::PORT: KEYWORD=DOMAIN; PORT:</p> <ul style="list-style-type: none"> • LCN (local communication network port) • ALL (default) <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> • NEXTHOP = xxx.xxx.xxx.xxx (xxx = 0...255) • ALL <p>Example: RTRV-CIDR-ROUTE:FUJITSU::CTAG;</p>	<p>In the tree view, click the Communications tab. Select the <TID> (SYSTEM) component.</p> <p>Entity ▶ Properties View</p> <p>Select the IP Routes tab. Verify current values. Close the Properties dialog box.</p>

Step 14

Proceed to [Provision GOS](#).

4.4.3

Provision GOS

The grade of service (GOS) table stores system-level default values for newly-created entities, including equipment, facility, and ports entities. It can be used to modify default provisioning in the following areas:

- Default PM threshold levels (PMs)
- Default threshold crossing alerts (TCAs)
- Default alarm severity for standing conditions (ALMs)
- Default values for certain entity attributes (keyword parameter values) of managed objects (MOs)



Attention: *GOS provisioning does not change the provisioning of existing entities (equipment, facilities, or ports). Changes are only applicable to new entities, created after the GOS table is changed. To promote uniformity, Fujitsu recommends that GOS provisioning be performed at turn-up.*

Step 1

If not already done, complete the system parameter provisioning procedures in [Provision System-Level Parameters](#).

Step 2

Do you wish to provision GOS?

Note: *If GOS provisioning is part of your local practice, Fujitsu recommends that GOS provisioning be performed at this time.*

IF YES:

Perform GOS provisioning as described in [Provisioning GOS](#), then proceed to [Step 3](#).

IF NO:

Proceed to [Step 3](#).

Step 3

Allow autonomous messages, which were inhibited in [Step 3](#).

Note: *This step does not apply if you are using the NETSMART 500 user interface.*

TL1	NETSMART 500
ALW-MSG-ALL:TID::CTAG; <i>Example:</i> ALW-MSG-ALL:FUJITSU::CTAG;	n/a

Step 4

Proceed to [Provision ILA Shelf Equipment and Facilities](#).

4.5 Provision ILA Shelf Equipment and Facilities

In this section:

- 4.5.1 Log On
- 4.5.2 Autoprovision Equipment and Facilities–ILA Shelf
- 4.5.3 Manually Provision Equipment–ILA Shelf
- 4.5.4 Manually Provision WDM and OSC Facilities–ILA Shelf
- 4.5.5 Place ODCC In Service–ILA Shelf

The flowchart in the following figure shows the subprocedures used to turn-up the ILA shelf.




Figure 101: Provision ILA Shelf Equipment and Facilities (Procedure Flowchart)

4.5.1 Log On



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

If not already done, complete the procedures in [Provision System-Level Parameters, LCN Port, and GOS](#).

Step 2

If not already done, log on the node. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values shown apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p> <p>Start ▶ All Programs ▶ Fujitsu ▶ NETSMART 500</p> <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p> <p>NE ▶ Logon</p> <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10 non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial Comm. Port: COMx (for example, COM2) Configure: use default⁵⁷</p>	<p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>
	<p>Click Logon. The NETSMART 500 NE View opens. The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	

Step 3

In provisioning the ILA shelf equipment and facilities, do you want to use the autoprovisioning feature?

If YES:

Proceed to [Autoprovision Equipment and Facilities—ILA Shelf](#).

If NO:

Proceed to [Manually Provision Equipment—ILA Shelf](#).

4.5.2

Autoprovision Equipment and Facilities ILA Shelf

This subprocedure describes one method for installing and provisioning plug-in units in the ILA shelf. Another option is to use the procedures in [Manually Provision Equipment—ILA Shelf](#), and [Manually Provision WDM and OSC Facilities—ILA Shelf](#).

Note: For plug-in unit slot locations, refer to [About System Turn-up Core Configuration ILA Node](#).

⁵⁷ The default serial port settings are recommended: baud rate—9600, parity—none, data bits—8, stop bits—1.

The FLASHWAVE 7500 system provides automatic provisioning of the equipment and facilities and also provides the automatic in-service provisioning (AISP) capability for all facility types. Autoprovisioning and AISP are the default software settings.

After the plug-in unit is seated, the equipment entity is created and placed in service. Facilities are also created and placed in an Out-of-Service (OOS), Auto In-Service (AINS) state. While in the AINS state, alarms such as LOS are not generated, and the system waits for the application of a valid signal. Upon receiving a valid signal, the system begins a time-out period and then automatically transitions to the In-Service (IS) state. The default time-out period is 8 hours and can be modified using the ED-SYS command.

Note: *Except for shelves, all equipment can be autoprovioned. Shelves require manual provisioning to place them in service.*

If the facility is lost during the time-out period because of LOF or LOS, the time-out period is reset. Normal alarm reporting begins when the time-out period has completed and the transition to the IS state has occurred.



Attention: *When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.*

To install and autoprovion the ILA shelf equipment, perform the following steps:

Enable Autoprovisioning

Note: *You should already be logged on the NE (Refer to the [Log On](#) section).*

Step 1

Retrieve the state of the autoprovioning feature.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the tree view, select the NE (the top-level system entity).</p> <p>Entity ▾ Properties View</p> <p>In the Current Values area of the Properties dialog box, determine the value of AUTOP (Yes or No).</p> <p>Close the Properties dialog box.</p>

Step 2

Is autoprovisioning already enabled? (Is the current value of AUTOP set to Yes?)

If YES:

Proceed to [Step 5](#).

If NO:

Proceed to [Step 3](#).

Step 3

Enable autoprovisioning, and provision the AISP feature and the AISP timer if necessary.

TL1	NETSMART 500
<pre>ED-SYS:TID::CTAG:::KEYWORD=DOMAIN; KEYWORD=DOMAIN:</pre> <ul style="list-style-type: none"> CONTACT = Contact information; 40-character string delineated by escape quotes ("string") LOCATION = Location information; 40-character string delineated by escape quotes ("string") AUTOP = Y, N (autoprovisioning) AISPDEFTM = 00-00...08-00...48-00 (default valid signal timer in 1-minute increments) <p>Example: <pre>ED-SYS:FUJITSU::CTAG:::AUTOP=Y, AISPDEFTM=08-00;</pre></p>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">NE ▶ System Operations</div> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab. Set AUTOP to Yes. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 4

Verify that autoprovisioning is enabled.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the Current Values area of the Operations dialog box, verify that the updated information is correct.</p> <p>Close the Operations dialog box.</p>

Install Amplifier Plug-In Units

Step 5

Install the amplifier plug-in units in the appropriate slots (1 and 19) of the shelf. See [Figure 99](#) for slot locations. For each amplifier plug-in unit to be installed, do the following:

- a) Inspect the plug-in unit for possible damage or debris.
- b) Slide the plug-in unit into the shelf slot.

Verify Amplifier Plug-In Units Are In Service

Step 6

Ensure that both amplifier plug-in units are properly provisioned. The equipment state should be IS, Normal (STATE=IS-NR).

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • OS1-1 (slot 1) • OS1-19 (slot 19) • ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS1-1&OS1-19:CTAG;</p>	<p>In the shelf OS1 graphic view or tree view, select the equipment slot.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify the PRIMARY_STATE is IS.</p> <p>Verify the PRIMARY_STATE_QUALIFIER is NR.</p> <p>Close the Properties dialog box.</p>

Install Filler Panels

Step 7

Install filler panels in any unused slots of the ILA shelf.

Verify WDM Facilities Are In Service

Step 8

Verify that the WDM facility associated with each amplifier plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> • OS1-1-PE1 (WDM facility for slot-1 amplifier) • OS1-19-PE1 (WDM facility for slot-19 amplifier) <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>In the tree view, click the Facilities tab. Select the facility.</p> <p>Entity ▶ Properties View</p> <p>The Properties dialog box opens.</p> <p>Verify that In-Service state and provisioning parameters are correct.</p> <p>Close the Properties dialog box.</p>

Step 9

Are the WDM facilities in service and provisioned correctly?

IF YES:

Proceed to [Step 10](#).

IF NO:

Correct WDM facility provisioning using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#). Then proceed to [Step 10](#).

Verify OSC Facilities Are In Service

Step 10

Verify that the OSC facility associated with each OSC plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<p>RTRV-OSC:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none">OS1-9-PE1 (OSC facility for slot-9 plug-in unit)OS1-11-PE1 (OSC facility for slot-11 plug-in unit) <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>Click the Facilities tab in the tree area.</p> <p>Expand the appropriate shelf component.</p> <p>Select the appropriate facility AIDs: OS1-9-PE1 and OS1-11-PE1.</p> <p>Note: Select more than one component using <i>CTRL+click (multiple)</i> or <i>SHIFT+click (range)</i>.</p> <p>Entity ▶ Properties View</p> <p>Verify the new facility.</p> <p>Close the Properties dialog box.</p>

Step 11

Are the OSC facilities in service and provisioned correctly?

IF YES:

Proceed to [Place ODCC In Service—ILA Shelf](#).

IF NO:

Correct OSC facility provisioning using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#), then proceed to [Place ODCC In Service—ILA Shelf](#).



This procedure is complete.

4.5.3

Manually Provision Equipment ILA Shelf

This subprocedure describes one method for installing and provisioning plug-in units in the ILA shelf. For an alternative method, refer to [Autoprovision Equipment and Facilities—ILA Shelf](#).

Note: For plug-in unit slot locations, refer to [About System Turn-up Core Configuration ILA Node](#).

Note: This procedure includes steps to install plug-in units in the appropriate slots in the shelf. However, if certain plug-in units are not available, you can complete the procedure without installing them. This is called preprovisioning the slot. In this case, the unit will assume the specified provisioning when the unit is eventually installed in the slot. Note that an unequipped alarm will be raised until the unit is installed.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

To install and manually provision equipment in the ILA shelf, perform the following steps:

Disable Autoprovisioning

Note: You should already be logged on the NE (refer to [Step 2](#)).

Step 1

Retrieve the state of the autoprovisioning feature.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the tree view, select the NE (the top-level system entity).</p> <p>Entity ▾ Properties View</p> <p>The Properties dialog box opens.</p> <p>In the Current Values area of the Properties dialog box, determine the value of AUTOP (Yes or No).</p> <p>Close the Properties dialog box.</p>

Step 2

Is autoprovisioning already disabled? (Is the current value of AUTOP set to No?)

IF YES:

Proceed to [Step 5](#).

IF NO:

Proceed to [Step 3](#).

Step 3

Disable the autoprovisioning feature.

Note: If autoprovisioning is already disabled, this command will fail.

TL1	NETSMART 500
<pre>ED-SYS:TID::CTAG::AUTOP=N;</pre> <p>Example: <pre>ED-SYS:FUJITSU::CTAG::AUTOP=N;</pre></p>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">NE ▶ System Operations</div> <p>The Operations dialog box opens. Click the Attributes tab. Click the Modify tab. Set AUTOP to No. Click Modify.</p> <p>Do not close the Operations dialog box.</p>

Step 4

Verify that the autoprovisioning feature is disabled.

TL1	NETSMART 500
<pre>RTRV-SYS:TID::CTAG;</pre> <p>Example: <pre>RTRV-SYS:FUJITSU::CTAG;</pre></p>	<p>In the Current Values area of the Operations dialog box, verify that the value of AUTOP is No.</p> <p>Close the Operations dialog box.</p>

Install and Provision Amplifier Units

Step 5

Install amplifier (APMA-xxxx) plug-in units in the appropriate slots (1 and 19) of the ILA shelf. See [Figure 99](#) for slot locations. For each amplifier plug-in unit to be installed, do the following:

- a) Inspect the amplifier plug-in unit for possible damage or debris.
- b) Slide the amplifier plug-in unit into the appropriate shelf slot.

Step 6

For each amplifier plug-in unit, create the amplifier equipment entity, and place it in service.

TL1	NETSMART 500
<p>ENT-EQPT:TID:AID:CTAG::TYPE::IS; AID:</p> <ul style="list-style-type: none"> OS1-1 (slot 1) OS1-19 (slot 19) <p>TYPE:</p> <ul style="list-style-type: none"> APMA-L2C1 APMA-M2C1 APMA-ULC1 APMA-M2U1 APMA-ULU1 <p>Example: ENT-EQPT:FUJITSU:OS1-1:CTAG:: APMA-L2C1::IS;</p>	<p>In the tree view, select the Equipment tab. Expand the shelf. Select slot 1 or 19.</p> <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click the State tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> At New Prov. State, select In Service (ENT-IS). Click the Type tab. Select the appropriate equipment type. Click Modify. <p>Do not close the Operations dialog box.</p>

Step 7

For each equipment entity created in the previous step, verify that it is in service.

TL1	NETSMART 500
<p>RTRV-EQPT:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> OS1-1 (slot 1) OS1-19 (slot 19) ALL (null) <p>Example: RTRV-EQPT:FUJITSU:OS1-1&OS1-19:CTAG;</p>	<p>In the Current Values of the Operations dialog box, verify that the Provisioned State is In Service and that the Type is the appropriate equipment type.</p> <p>Close the Operations dialog box.</p>

Install Filler Panels

Step 8

Install filler panels in any unused slots of the shelf.

Step 9

Proceed to [Manually Provision WDM and OSC Facilities—ILA Shelf](#).

 This procedure is complete.

4.5.4

Manually Provision WDM and OSC Facilities ILA Shelf

The following steps are used to manually create the WDM and OSC facilities associated with the ILA shelf and place them in service.

Note: If you have autoprovisioned the ILA shelf (refer to [Autoprovision Equipment and Facilities—ILA Shelf](#)), WDM and OSC facilities have already been created. Skip this procedure and continue to [Place ODCC In Service—ILA Shelf](#).

Note: Default values are shown in bold>.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

To manually provision WDM and OSC facilities associated with the ILA shelf, perform the following steps:

Manually Provision WDM Facilities

Note: You should already be logged on the NE ([Step 2](#)).

Step 1

Two amplifier (APMA-xxxx) plug-in units were installed in [Step 5](#). Amplifier plug-in units are located in slots 1 and 19. For each amplifier plug-in unit, create the associated WDM facility, and place it in service.

TL1	NETSMART 500
<pre>ENT-WDM:TID:AID:CTAG:::KEYWORD=DOMAIN:IS; AID: • OS1-1-PE1 (WDM facility associated with slot-1 amplifier) • OS1-19-PE1 (WDM facility associated with slot-1 amplifier) KEYWORD=DOMAIN: • VSTIMER = hh-mm Example: ENT-WDM:FUJITSU:OS1-1-PE1:CTAG:::IS;</pre>	<div style="background-color: #666; color: white; padding: 2px; display: inline-block; margin-bottom: 5px;">NE ▶ Create</div> <p>Click the Facility tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> • Select type WDM. • Select the appropriate facility AIDs: OS1-1-PE1 and OS1-19-PE1. • Select In Service (IS). • Select the desired VSTIMER value. <p>Click Create.</p> <p>Close the Operations dialog box.</p>

Step 2

Verify that the WDM facility associated with each amplifier plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<p>RTRV-WDM:TID:AID:CTAG; AID:</p> <ul style="list-style-type: none"> OS1-1-PE1 (WDM facility for slot-1 amplifier) OS1-19-PE1 (WDM facility for slot-19 amplifier) ALL (null) <p>Example: RTRV-WDM:FUJITSU:OS1-1-PE1:CTAG;</p>	<p>Click the Facilities tab in the tree area.</p> <p>Expand the appropriate shelf component.</p> <p>Select the appropriate facility AIDs: OS1-1-PE1 and OS1-19-PE1.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▶ Properties View</p> <p>Verify the new facility.</p> <p>Close the Properties dialog box.</p>

Step 3

Are the WDM facilities in service and provisioned correctly?

If YES:

Proceed to [Step 4](#).

If NO:

Correct WDM facility provisioning by using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#). Then proceed to [Step 4](#).

Manually Provision OSC Facilities

Step 4

For each OSC plug-in unit, create the OSC facility, and place it in service.

Note: Two OSC plug-in units (SCMA-SCC4) were installed in [Step 16 of Install Primary NE Management Units, and Configure the ILA Shelf](#). OSC plug-in units are located in slots 9 and 11 of the shelf.

TL1	NETSMART 500
<p>ENT-OSC:TID:AID:CTAG:::KEYWORD=DOMAIN:IS; AID:</p> <ul style="list-style-type: none"> OS1-9-PE1 (OSC facility for slot-9 plug-in unit) OS1-11-PE1 (OSC facility for slot-11 plug-in unit) <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> VSTIMER = hh-mm JOSECTRC = Y, N TRC = \"up to 62 ASCII characters\" EXPTRC = \"up to 62 ASCII characters\" <p>Example: ENT-OSC:FUJITSU:OS1-9-PE1:CTAG::: VSTIMER=04-00:IS;</p>	<p>NE ▶ Create</p> <p>Click the Facility tab.</p> <p>In the Command Parameters area:</p> <ul style="list-style-type: none"> Select type OSC. Select the appropriate facility AIDs: OS1-9-PE1 and OS1-11-PE1. Select In Service (IS). Select the appropriate provisioning options. <p>Click Create.</p> <p>Close the Operations dialog box.</p>

Step 5

Verify that the OSC facility associated with each OSC plug-in unit is in service and provisioned correctly.

TL1	NETSMART 500
<pre>RTRV-OSC:TID:AID:CTAG; AID:</pre> <ul style="list-style-type: none">OS1-9-PE1 (OSC facility for slot-9 plug-in unit)OS1-11-PE1 (OSC facility for slot-11 plug-in unit)ALL (null) <p>Example: RTRV-OSC:FUJITSU:OS1-9-PE1:CTAG;</p>	<p>Click the Facilities tab in the tree area.</p> <p>Expand the appropriate shelf component.</p> <p>Select the appropriate facility AIDs: OS1-9-PE1 and OS1-11-PE1.</p> <p>Note: Select more than one component using CTRL+click (multiple) or SHIFT+click (range).</p> <p>Entity ▾ Properties View</p> <p>Verify the new facility.</p> <p>Close the Properties dialog box.</p>

Step 6


Are the OSC facilities in service and provisioned correctly?

If YES:

Proceed to [Place ODCC In Service—ILA Shelf](#).

If NO:

Correct OSC facility provisioning using procedures described in [Editing Facility State](#), or [Editing Facility Parameters](#). Then proceed to [Place ODCC In Service—ILA Shelf](#).

 This procedure is complete.

4.5.5

Place ODCC In Service ILA Shelf

An optical data communications channel (ODCC) can be assigned to every OSC facility up to a maximum of two channels per ILA shelf. The ODCC is used for communication with network-side NEs.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Step 1

Two OSC plug-in units (SCMA-SCC4) are installed and the OSC facility associated with each OSC plug-in unit has been created and is in service. The OSC plug-in units are located in slots 9 and 11 of shelf OS1. For each OSC plug-in unit, create the associated ODCC and place it in service.

TL1	NETSMART 500
<pre>ENT-SDCC:TID:AID:CTAG::: KEYWORD=DOMAIN:IS;</pre> <p>AID (matching OSC facility AID):</p> <ul style="list-style-type: none"> OS1-9-PE1 (ODCC facility for slot-9 plug-in unit) OS1-11-PE1 (ODCC facility for slot-11 plug-in unit) <p>KEYWORD=DOMAIN:</p> <ul style="list-style-type: none"> K = 1...7, 8 L2CR = PLUS-R, NTWK, USER, PLUS-C T200 = 50...200...5000 T203 = 2...10...300 N200 = 2, 3...16 N201 = 260...1024 SRV = AIMS, UITS NETID = User-defined network identifier. Character string of up to 20 alphanumeric delineated by escape quotes (""). INSTID = Identifies the NLP (ISIS) management-port instance. Refer to command ENT-SDCC for more information about keyword INSTID. <p>Example: <pre>ENT-SDCC:FUJITSU:OS1-9-PE1:CTAG::: K=8,SRV=UITS:IS;</pre></p>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 10px;">NE ▶ Create</div> <p>The Operations dialog box opens. Click the DCC tab.</p> <p>Select ODCC from the TYPE drop-down list in the Command Parameters area.</p> <p>Additional parameter choices appear:</p> <ul style="list-style-type: none"> From the AID drop-down list, select the ODCC facility AIDs: OS1-9-PE1 and OS1-11-PE1. From the STATE drop-down list, select IS. If required, use the additional fields to set KEYWORD=DOMAIN values. <p>Click Create.</p> <p>A confirmation dialog box opens. Click Yes.</p> <p>Close the Operations dialog box.</p>

Step 2

Initialize the operation interface (OIF).

Note: The *INIT-OIF* command must be executed before the *ENT-SDCC* command becomes effective.

TL1	NETSMART 500
<pre>INIT-OIF:TID:::CTAG;</pre> <p>Example: <pre>INIT-OIF:FUJITSU:::CTAG;</pre></p>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 10px;">NE ▶ System Operations</div> <p>The Operations dialog box opens. Click Initialize tab. Select the Stack tab.</p> <p>In the Command Parameters area:</p> <p>Select OIF from the STACK INIT TYPE menu. Click Initialize.</p> <p>A Confirmation dialog box opens. Click Yes. Click Logon.</p>

Step 3

Wait 2 minutes before continuing.

Note: The NETSMART 500 software connection to the NE will be lost. After waiting 2 minutes, users should log back on the NE.

Step 4

Verify the ODCC.

TL1	NETSMART 500
<p>RTRV-SDCC:TID:AID:CTAG;</p> <p>AID (matching OSC facility AID):</p> <ul style="list-style-type: none">OS1-9-PE1 (ODCC facility for slot-9 plug-in unit)OS1-11-PE1 (ODCC facility for slot-11 plug-in unit)ALL (null) <p>Example: RTRV-SDCC:FUJITSU:ALL:CTAG;</p>	<p>Restart the NETSMART 500 user interface, and log back on the NE.</p> <p>Note: Refer to Step 2.</p> <p>In the tree view, select the Communications tab.</p> <p>Expand the ILA shelf OS1 and OSC facility to locate the ODCC entity. Select the ODCC entity.</p> <p>Entity ▸ Properties View</p> <p>The Properties dialog box opens. Verify that the State is IS.</p> <p>Close the Properties dialog box when done.</p>

Step 5

Proceed to [Install Intrashelf Fiber-Optic Cables](#).

4.6

Install Intrashelf Fiber-Optic Cables

There are two types of ILA nodes. The following figures shows the fiber-optic cable connections that need to be installed for each node. The first ILA node, the following figure, uses type APMA-xxC1 amplifiers and does not support in-service upgrade to OADM.




Figure 102: Cables for ILA Node with APMA-xxC1 Amplifiers

The second ILA node, the following figure, uses Universal Amplifiers (APMA-xxU1) and does support in-service upgrade to OADM.




Figure 103: Cables for ILA Node with APMA-xxU1 Amplifiers

Note: For rules and precautions regarding handling, storing, cleaning, connecting, and disconnecting fiber-optic cables, refer to *Fiber Cable Handling*.



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.



Danger: Never look into the end of a fiber-optic cable. Permanent eye damage or blindness can occur very quickly if the laser light is present. Follow local safety precautions regarding fiber.



Warning: To avoid damage to the equipment when connecting fibers, always verify the optical specifications. Verify that the optical signal into a receiver meets the appropriate optical specifications listed in [Optical Specifications](#).



Caution: Before installing fiber-optic cables, always verify that the fiber connectors are free of contamination by visually inspecting with a fiber scope and cleaning the connectors at both ends of the fiber, if necessary. Refer to *Fiber Cable Handling*.

Install intrashelf fiber-optic cables as follows:

Step 1

Install slot-1 amplifier connections to OSC as follows:

- a) Obtain and clean two LC-LC fiber-optic cables.
- b) Connect the cable ends to the appropriate plug-in units and connectors as shown in the following figure and listed in the following table.




Figure 104: Slot-1 Amplifier Connections to OSC

Table 63: Slot-1 Amplifier Connections to OSC

From Amplifier (APMA-xxxx)		To OSC Unit (SCMA-SCC4)	
Shelf Slot	Connector	Shelf Slot	Connector
1	OSC IN	9	NTKW OUT-1

Table 63: Slot-1 Amplifier Connections to OSC (Cont.)

From Amplifier (APMA-xxxx)		To OSC Unit (SCMA-SCC4)	
Shelf Slot	Connector	Shelf Slot	Connector
1	OSC OUT	9	NTWK IN-1

Step 2

Install slot-19 amplifier connections to OSC as follows:

- a) Obtain and clean two LC-LC fiber-optic cables.
- b) Connect the cable ends to the appropriate plug-in units and connectors as shown in the following figure and listed in the following table.



Figure 105: Slot-19 Amplifier Connections to OSC

Table 64: Slot-19 Amplifier Connections to OSC

From Amplifier (APMA-xxxx)		To OSC Unit (SCMA-SCC4)	
Shelf Slot	Connector	Shelf Slot	Connector
19	OSC IN	11	NTWK OUT-1
19	OSC OUT	11	NTWK IN-1

Step 3

Are the amplifiers type APMA-xxU1?

If YES:

Proceed to [Step 6](#).

If NO:

Proceed to [Step 4](#).

Step 4

Install pass-through connections between APMA-xxC1 amplifiers as follows:




Figure 106: Pass-Through Connections between APMA-xxC1 Amplifiers

Table 65: Pass-Through Connections between APMA-xxC1 Amplifiers

From Amplifier (APMA-xxC1)		To Amplifier (APMA-xxC1)	
Shelf Slot	Connector	Shelf Slot	Connector
1	RAMP OUT-1	19	TAMP IN
1	TAMP IN	19	RAMP OUT-1

- Connect a 14 dB optical attenuator (FC9682PAD1) to the TAMP IN connectors of the two amplifier plug-in units.
- Obtain and clean two LC-LC fiber-optic cables.
- Connect the cable ends to the appropriate plug-in units and connectors as shown in the following figure and listed in the following table.

Note: At the TAMP IN connection, the cable connects to the optical attenuator.

Step 5

Proceed to [Connect DCMs or Install Loopback Cables](#).

Step 6

Install pass-through connections between APMA-xxU1 amplifiers as follows:




Figure 107: Pass-Through Connections between APMA-xxU1 Amplifiers

Table 66: Pass-Through Connections between APMA-xxU1 Amplifiers

From Amplifier (APMA-xxU1)		To Amplifier (APMA-xxU1)	
Shelf Slot	Connector	Shelf Slot	Connector
1	RAMP OUT-2	19	TAMP IN-2

Table 66: Pass-Through Connections between APMA-xxU1 Amplifiers (Cont.)

From Amplifier (APMA-xxU1)		To Amplifier (APMA-xxU1)	
Shelf Slot	Connector	Shelf Slot	Connector
1	TAMP IN-2	19	RAMP OUT-2

- a) Obtain and clean two LC-LC fiber-optic cables.
- b) Connect the cable ends to the appropriate plug-in units and connectors as shown in the following figure and listed in the following table.

Step 7

Proceed to [Connect DCMs or Install Loopback Cables](#).

4.7

Connect DCMs or Install Loopback Cables

In this section:

- 4.7.1 Overview DCM or Loopback Cabling Core Configuration ILA Node
- 4.7.2 Connect Amplifiers to DCMs or Install Loopback Cables

As explained in [Overview DCM or Loopback Cabling Core Configuration ILA Node](#), each amplifier (APMA-xxxx) plug-in unit must be connected to a Dispersion Compensation Module (DCM), or a loopback fiber must be installed in place of the DCM. The procedure in [Connect Amplifiers to DCMs or Install Loopback Cables](#), guides you in connecting DCMs and installing loopback cables as required.

Before performing the procedure in [Connect Amplifiers to DCMs or Install Loopback Cables](#), you should know whether or not a DCM is required for each amplifier (APMA-xxxx) plug-in unit in the node. For each amplifier that requires a DCM, you should also know where it has been installed. If uncertain, contact your Network Design/ Planning organization.

4.7.1

Overview DCM or Loopback Cabling Core Configuration ILA Node

Generally, as shown in the following figure, a Dispersion Compensation Module (DCM) is used with each amplifier (APMA-xxxx) plug-in unit to overcome the effects of chromatic dispersion. However, depending on network design, the DCM is not always required.




Figure 108: Fiber-Optic Cable Connections to DCMs

If a DCM is not used, a loopback fiber-optic cable should be installed in place of the DCM. The following figure shows an example in which loopback cables are used with both amplifiers. If the amplifier is type APMA-L2C1 or APMA-U1C1, an 11 dB attenuator with LC connector type is required. Otherwise an optical attenuator is not required.




Figure 109: Fiber-Optic Loopback Cable Connections

4.7.2 Connect Amplifiers to DCMs or Install Loopback Cables

Note: For rules and precautions regarding handling, storing, cleaning, connecting, and disconnecting fiber-optic cables, refer to *Fiber Cable Handling*.

To connect amplifiers to DCMs or install loopback cables, perform the following steps:

Step 1

Does the amplifier (APMA-xxxx) plug-in unit installed in slot 1 require connection to a DCM?

If YES:
 Proceed to [Step 2](#).

If NO:
 Proceed to [Step 6](#).

Connect DCM to Slot-1 Amplifier

Step 2

Obtain and clean two LC-SC fiber-optic cables.

Step 3

If an in-line optical attenuator is required by the network engineering design specification, clean the attenuator, and connect it to the receiving end of the cable.

Step 4

Connect the cable ends (with the optical attenuator, if used) to the plug-in units and connectors listed in the following table.

Table 67: Slot-1 Amplifier-to-DCM Fiber-Optic Cable Connections

From APMA-xxxx		To DCM ⁵⁸	
Shelf Slot	Connector	Shelf Slot	Connector
1	to DCF	DCM-1	OPT In ⁵⁹
1	from DCF	DCM-1	OPT Out

Step 5

Proceed to [Step 9](#).

Install Slot-1 Loopback Cable

Step 6

Is the amplifier in slot 1 type APMA-L2C1 or APMA-ULC1?

If YES: from DCF

Connect a 12 dB optical attenuator, part number 956-130-5x12, to the **from DCF** connector of the amplifier plug-in unit. Then proceed to [Step 7](#).

If NO:

An optical attenuator is not required. Proceed to [Step 7](#).

Step 7

Obtain and clean one LC-LC fiber-optic cable.

⁵⁸ DCMs are housed in the SFD3 dispersion compensation shelf (FC9512SFD3).

⁵⁹ If an in-line optical attenuator is required by the network engineering design specification, it is placed at the **OPT In** connector to the DCM unit.

Step 8

Connect the cable ends to the plug-in unit connectors listed in the following table.

Table 68: Slot-1 Amplifier Loopback Cable Connections

From APMA-xxxx		To APMA-xxxx	
Shelf Slot	Connector	Shelf Slot	Connector
1	to DCF	1	from DCF ⁶⁰

Step 9

Does the amplifier (APMA-xxxx) plug-in unit installed in slot 19 require connection to a DCM?

If YES:

Proceed to [Step 10](#).

If NO:

Proceed to [Step 14](#).

Connect DCM to Slot-19 Amplifier

Step 10

Obtain and clean two LC-SC fiber-optic cables.

Step 11

If an in-line optical attenuator is required by the network engineering design specification, clean the attenuator, and connect it to the receiving-end of the cable.

Step 12

Connect the cable ends (with the optical attenuator, if used) to the plug-in units and connectors listed in the following table.

Table 69: Slot-19 Amplifier-to-DCM Fiber-Optic Cable Connections

From APMA-xxxx		To DCM ⁶¹	
Shelf Slot	Connector	Shelf Slot	Connector
19	to DCF	DCM-2	OPT In ⁶²

⁶⁰ If an in-line optical attenuator is required, it is placed at the **from DCF** connector.

⁶¹ **DCMs are housed in the SFD3 dispersion compensation shelf (FC9512SFD3).**

⁶² If an in-line optical attenuator is required, it is placed at the **OPT In** connector to the DCM unit.

Table 69: Slot-19 Amplifier-to-DCM Fiber-Optic Cable Connections (Cont.)

From APMA-xxxx		To DCM ⁶¹	
Shelf Slot	Connector	Shelf Slot	Connector
19	from DCF	DCM-2	OPT Out

Step 13

Proceed to [Step 17](#).

Install Slot-19 Loopback Cable

Step 14

Is the amplifier in slot 19 type APMA-L2C1 or APMA-ULC1?

If YES: from DCF

Connect a 12 dB optical attenuator, part number 956-130-5x12, to the **from DCF** connector of the amplifier plug-in unit. Then proceed to [Step 15](#).

If NO:

An optical attenuator is not required. Proceed to [Step 15](#).

Step 15

Obtain and clean one LC-LC fiber-optic cable.

Step 16

Connect the cable ends to the plug-in unit connectors listed in the following table.

Table 70: Slot-19 Amplifier Loopback Cable Connections

From APMA-xxxx		To APMA-xxxx	
Shelf Slot	Connector	Shelf Slot	Connector
19	to DCF	19	from DCF ⁶³

⁶¹ DCMs are housed in the SFD3 dispersion compensation shelf (FC9512SFD3).

⁶³ If an in-line optical attenuator is required, it is placed at the **from DCF** connector.

Step 17

Are all NEs in the network turned up?


If YES:

Proceed to [Make Network Connections](#).

Note: *You have completed the turn-up for the ILA node, but have not connected it to the network. Network connections are made after all nodes are turned up. Refer to [Figure 98](#).*

If NO:

Repeat the turn-up procedures for the next NE. If the next NE is another ILA node, start at [Apply Power and Install Fan Units](#). Otherwise, start at [Apply Power and Install Fan Units](#).

 This procedure is complete.

5

Nodal Test Tool

In this chapter:

- 5.1 About the Nodal Test Tool
- 5.2 Nodal Test Tool Prerequisites
- 5.3 Using Nodal Test Tool for In-Service Testing
- 5.4 Using Nodal Test Tool for System Turn-Up

This chapter provides procedures to use the Nodal Test Tool for the FLASHWAVE® 7500 Core and ETSI Configuration applications.

5.1

About the Nodal Test Tool

Note: *Applies to: Core and ETSI Configurations*

This section provides information regarding the Nodal Test Tool for Release 7.1 and later.

The FLASHWAVE 7500 Nodal Test Tool is used to test for fiber connection loss and establish a baseline for the optical power levels using a wavelength transmitted through plug-in units in the optical shelves of Core or ETSI Configurations. Refer to [Nodal Test Tool Prerequisites](#) for specific configurations that support the Nodal Test Tool.

The Nodal Test Tool detects dirty fibers by taking power measurements from port to port. The tool measures the light power at both ends of the fibers to calculate the insertion fiber loss by subtracting OPR from OPT. The calculated insertion fiber loss value is compared with an expected deviation range to judge the fiber connectivities (from port to port). If the insertion fiber loss is within the expected deviation range, the test is judged successful (that is, the fiber is healthy). If the insertion fiber loss is not within the expected deviation range, the test is judged failed (fiber is not healthy).

Note: *Power levels (too low or too high) outside the acceptable deviation range are often an indication of dirty or misconnected fibers.*

The OPR-TEST-PATH command starts the Nodal Test Tool function. The RTRV-TEST-PATH command retrieves the fiber loss report after the Nodal Test Tool function has completed. Alternatively, the NETSMART® 500 Nodal Fiber Test wizard can be used in place of the commands.

The Nodal Test Tool can be used at system turn-up (when the NE is not in service) or for in-service testing (traffic exists on the NE). The following table shows a summary of the system turn-up and in-service Nodal Test Tool requirements.

Note: *Refer to [Nodal Test Tool Prerequisites](#) for more information on requirements for the Nodal Test Tool.*

Table 71: Requirements for System Turn-Up or In-Service Testing with Nodal Test Tool

Testing Situation	Requirements
System turn-up (NE not in service)	<ul style="list-style-type: none"> Shelves are installed and connected according to work order and local practices. At least one NEM plug-in unit is installed. One or two amplifier plug-in units are installed (depending on configuration). Amplifiers on the network side have loopback cables. At least one OLC is installed. At least one wavelength (cross-connect) is provisioned.
In-service (traffic exists on NE)	<ul style="list-style-type: none"> The NE is provisioned and is in a working state. System should be in an alarm free state. The NE is handling traffic.

5.2

Nodal Test Tool Prerequisites



Caution: Read the prerequisites section and the entire procedure before beginning the procedure. If you have any questions, call 1-800-USE-FTAC (1-800-873-3822).

Supported Configurations

The following table shows the configurations that support the Nodal Test Tool and the type of testing that can be done with the Nodal Test Tool.


Note: The Extension Configuration (Stand Alone Shelf [SAS]) does not support the Nodal Test Tool.

Table 72: Configurations That Support Nodal Test Tool

Shelf Type	Supported Configurations	Supported Testing with Nodal Test Tool	
		System Turn-Up Test	In-Service Test
23-inch Universal Shelf (FC9682SHU3)	Core 2D-ROADM	Yes	Yes
	Core WSS ROADM	Yes	Yes
	Core WSS ROADM Multi-degree HUB (up to 8-degree)	Yes	Yes
	Core WSS ROADM Asymmetrical HUB (up to 12-degree)	No	Yes
	Core ILA	No	Yes
	Core Express	No	Yes
19-inch ETSI Front Access Shelf (FC9682SHU4)	ETSI 2D-ROADM	Yes	Yes
	ETSI WSS ROADM	Yes	Yes
	ETSI WSS ROADM Multi-degree HUB (up to 8-degree)	Yes	Yes
	ETSI ILA	No	Yes
	ETSI Express	No	Yes

Supported Fiber Connections

The following figures show the fiber connections for a Core/ETSI WSS ROADM configuration. The following table provides an index for the fiber connections shown in the figure and the fiber connections that support the Nodal Test Tool.



mn1730bn_1

Figure 110: Fiber Connections for Core/ETSI WSS ROADM Configuration (Ring)




Figure 111: Fiber Connections for Core/ETSI WSS ROADM Configuration (Terminal)

Table 73: Supported Fiber Connections for Core/ETSI WSS ROADM Configuration

Fiber Connection Index for Core/ETSI WSS ROADM Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D1/A5	APMA-xxxx	E1	APMA-xxxx ⁶⁴	E1	No
D2	APMA-xxxx ⁶⁴	C4	SCMA-SCC4	E1	No
D3	APMA-xxxx ⁶⁴	C5	DCF	n/a	No
D4	DCF ⁶⁶	n/a	APMA-xxxx ⁶⁴	E2	Yes
D5	APMA-xxxx ⁶⁴	C2	MDMA-RMC1	E1	Yes

⁶⁴ Refer to [General Requirements for the Nodal Test Tool](#) for the amplifier units that support the Nodal Test Tool.


⁶⁵ The SCMA-SCC4 unit does not have monitor points.

⁶⁶ The DCF does not have monitor points.

Table 73: Supported Fiber Connections for Core/ETSI WSS ROADM Configuration (Cont.)

Fiber Connection Index for Core/ETSI WSS ROADM Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D6	MDMA-RMC1	MPOn (n = 1... 10)	IFMA-Uxxx (Transponder)	E1/E2	No
T1	APMA-xxxx ⁶⁴	C1	SFMA-CMC1	E9	Yes
A1	IFMA-Uxxx (Transponder)	E1/E2	MDMA-RMC1	MPOn (n = 1... 10)	No
A2	MDMA-RMC1	E1	SFMA-CMC1	C1	Yes
A3	SFMA-CMC1	E1	APMA-xxxx ⁶⁴	C1	Yes
A4	SCMA-SCC4 ⁶⁵	E1	APMA-xxxx ⁶⁴	C4	No

The following figures show the fiber connections for a Core/ETSI 2D-ROADM configuration. The following table provides an index for the fiber connections shown in the figure and the fiber connections that support the Nodal Test Tool.



mm1730bpr_1

Figure 112: Fiber Connections for Core/ETSI 2D-ROADM Configuration (Ring)




Figure 113: Fiber Connections for Core/ETSI 2D-ROADM Configuration (Terminal)

Table 74: Supported Fiber Connections for Core/ETSI 2D-ROADM Configuration

Fiber Connection Index for Core/ETSI 2D-ROADM Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D1/A5	APMA-xxxx	E1	APMA-xxxx ⁶⁷	E1	No
D2	APMA-xxxx ⁶⁷	C4	SCMA-SCC4	E1	No
D3	APMA-xxxx ⁶⁷	C5	DCF	n/a	No
D4	DCF ⁶⁹	n/a	APMA-xxxx ⁶⁷	E2	Yes
D5	APMA-xxxx ⁶⁷	C2	MDMA-RDC1	E1	Yes

⁶⁷ Refer to [General Requirements for the Nodal Test Tool](#) for the amplifier units that support the Nodal Test Tool.

⁶⁸ The SCMA-SCC4 unit does not have monitor points.

⁶⁹ The DCF does not have monitor points.

Table 74: Supported Fiber Connections for Core/ETSI 2D-ROADM Configuration (Cont.)

Fiber Connection Index for Core/ETSI 2D-ROADM Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D6	MDMA-RDC1	MPOn (n = 1... 10)	IFMA-Uxxx (Transponder)	E1/E2	No
T1	APMA-xxxx ⁶⁷	C3	MDMA-RDC1	C0	Yes
A1	IFMA-Uxxx (Transponder)	E1/E2	MDMA-RDC1	MPOn (n = 1... 10)	No
A3	MDMA-RDC1	E1	APMA-xxxx ⁶⁷	C1	Yes
A4	SCMA-SCC4 ⁶⁸	E1	APMA-xxxx ⁶⁷	C4	No

The following figure shows the fiber connections for a Core/ETSI ILA configuration. The following table provides an index for the fiber connections shown in the figure and the fiber connections that support the Nodal Test Tool.




Figure 114: Fiber Connections for Core/ETSI ILA Configuration

Table 75: Supported Fiber Connections for Core/ETSI ILA Configuration

Fiber Connection Index for Core/ETSI ILA Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D1/A5	APMA-xxxx	E1	APMA-xxxx ⁷⁰	E1	No
D2	APMA-xxxx ⁷⁰	C4	SCMA-SCC4	E1	No
D3	APMA-xxxx ⁷⁰	C5	DCF	n/a	No

⁷⁰ Refer to [General Requirements for the Nodal Test Tool](#) for the amplifier units that support the Nodal Test Tool.

⁷¹ The SCMA-SCC4 unit does not have monitor points.

⁷² The DCF does not have monitor points.

Table 75: Supported Fiber Connections for Core/ETSI ILA Configuration (Cont.)

Fiber Connection Index for Core/ETSI ILA Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D4	DCF ⁷²	n/a	APMA-xxxx ⁷⁰	E2	Yes
T1	Release 4.3 APMA-xxxx ⁷⁰	C1	Release 4.3 APMA-xxxx ⁷⁰	C1	Yes
	Release 4.3 APMA-xxxx ⁷⁰	C1	Release 5.1 APMA-xxxx ⁷⁰ (operating in Rel. 4.3 mode)	C1	Yes
	Release 5.1 APMA-xxxx ⁷⁰ (operating in Rel. 4.3 mode)	C1	Release 4.3 APMA-xxxx ⁷⁰	C1	Yes
	Release 5.1 APMA-xxxx ⁷⁰ (operating in Rel. 4.3 mode)	C1	Release 5.1 APMA-xxxx ⁷⁰ (operating in Rel. 4.3 mode)	C1	Yes
	Release 5.1 APMA-xxxx ⁷⁰ (operating in Rel. 5.1 mode)	C2	Release 5.1 APMA-xxxx ⁷⁰ (operating in Rel. 5.1 mode)	C6	Yes
	Release 6.1 or later APMA-xxxx	C1	Release 6.1 or later APMA-xxxx	C1	Yes
A4	SCMA-SCC4 ⁷¹	E1	APMA-xxxx	C4	No

The following figure shows the fiber connections for a Core/ETSI Express configuration. The following table provides an index for the fiber connections shown in the figure and the fiber connections that support the Nodal Test Tool.




Figure 115: Fiber Connections for Core/ETSI Express Configuration

Table 76: Supported Fiber Connections for Core/ETSI Express Configuration


Fiber Connection Index for Core/ETSI Express Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D1/A5	APMA-xxxx	E1	APMA-xxxx ⁷³	E1	No
D2	APMA-xxxx ⁷³	C4	SCMA-SCC4	E1	No
D3	APMA-xxxx ⁷³	C5	DCF	n/a	No
D4	DCF ⁷⁵	n/a	APMA-xxxx ⁷³	E2	Yes
T1	APMA-xxxx ⁷³	C1	SFMA-CMC1	C9	Yes
A3	SFMA-CMC1	E1	APMA-xxxx ⁷³	C1	Yes
A4	SCMA-SCC4 ⁷⁴	E1	APMA-xxxx ⁷³	C4	No

The following figure shows the fiber connections for a Core/ETSI Multi-degree HUB configuration. The following table provides an index for the fiber connections shown in the figure and the fiber connections that support the Nodal Test Tool.

⁷³ Refer to [General Requirements for the Nodal Test Tool](#) for the amplifier units that support the Nodal Test Tool.

⁷⁴ The SCMA-SCC4 unit does not have monitor points.

⁷⁵ The DCF does not have monitor points.



mt1730bt_1

Figure 116: Fiber Connections for Core/ETSI Multi-Degree HUB Configuration

Table 77: Supported Fiber Connections for Core/ETSI Multi-Degree HUB Configuration

Fiber Connection Index for Core/ETSI Multi-Degree HUB Configuration	Fiber Connections				Supported by Nodal Test Tool
	From		To		
	Equipment Name	Port Number	Equipment Name	Port Number	
D1/A5	APMA-xxxx	E1	APMA-xxxx ⁷⁶	E1	No
D2	APMA-xxxx ⁷⁶	C4	SCMA-SCC4	E1	No
D3	APMA-xxxx ⁷⁶	C5	DCF	n/a	No
D4	DCF ⁷⁸	n/a	APMA-xxxx ⁷⁶	E2	Yes
D5	APMA-xxxx ⁷⁶	C2	MDMA-RMC1	E1	Yes
D6	MDMA-RMC1	MPO _n (n = 1...10)	IFMA-Uxxx (Transponder)	E1/E2	No
T1	APMA-xxxx ⁷⁶	C1	SFMA-CMC1	C9	Yes
T2	APMA-xxxx ⁷⁶	C3	SFMA-CDC1	E1	Yes
T3	SFMA-CDC1	C1...C6	SFMA-CMC1	C3...C8	Yes
A1	IFMA-Uxxx (Transponder)	E1/E2	MDMA-RMC1	MPO _n (n = 1...10)	No
A2	MDMA-RMC1	E1	SFMA-CMC1	C1	Yes
A3	SFMA-CMC1	E1	APMA-xxxx ⁷⁶	C1	Yes
A4	SCMA-SCC4 ⁷⁷	E1	APMA-xxxx ⁷⁶	C4	No

General Requirements for the Nodal Test Tool

- The FLASHWAVE 7500 node is running Release 7.1 or later.
- The optical shelf or shelves to be tested are installed and equipped, including the following plug-in units:
 - Two OSC plug-in units (SCMA-SCC4) for ROADM configuration. The OSC units occupy slots 9 and 11. When testing in the FLASHWAVE 7500 ETSI shelf, OSC units are placed in slots 13 and 15.
 - Two SCMA-SCC4 units can be used in a linear end node configuration; however, the SCMA-SCC4 unit on the unpopulated side of the shelf provides additional nonvolatile memory storage. Refer to your company's

⁷⁶ Refer to [General Requirements for the Nodal Test Tool](#) for the amplifier units that support the Nodal Test Tool.

⁷⁷ The SCMA-SCC4 unit does not have monitor points.

⁷⁸ The DCF does not have monitor points.

recommended practices for populating SCMA-SCC4 units for linear end nodes since these nodes may be populated with one or two units.

- LAM units FC9682LAMx, 2 for terminal and 4 for full OADM shelf.

Note: In Linear end node configurations, unused slots should be equipped with filler panels.



Warning: The Nodal Test Tool must **NOT** be used to test Raman amplifiers (APMA-DRC1). Attempting to use this tool with these units will damage the laser on the APMA-DRC1 amplifiers.

- Two amplifier plug-in units are required for ROADM testing. In the Core configuration, the amplifiers populate slots 1 and 19. In the FLASHWAVE 7500 ETSI configuration, the amplifiers are in slots 1 and 11. One amplifier plug-in unit is used in the linear test configuration. Only the following amplifiers are supported:
 - APMA-M2C1 (FC9682M2C1-I02 or later)
 - APMA-L2C1 (FC9682L2C1-I03 or later)
 - APMA-ULC1 (FC9682ULC1 all issues)
 - APMA-ULU1 (FC9682ULU1 all issues)
 - APMA-M2U1 (FC9682M2U1 all issues)
 - APMA-MHU1 (FC9682MHU1 all issues)
 - APMA-MHU2 (FC9682MHU2 all issues)
- Fan units are installed.
- MPO cables FC9682MP11, 2 for terminal and 4 for OADM shelf.

ROADM/ HUB Configuration Requirements for the Nodal Test Tool

- Two WSS Switch plug-in units (SFMA-CMC1) are needed for ROADM configuration. In the 23-inch (or ANSI) shelf, the SFMA-CMC1 units occupy slots 3 and 17. In the FLASHWAVE 7500 ETSI shelf, the WSS Switch is in slots 3 and 9. One WSS Switch plug-in units is needed for Linear end node configurations.
- Two Mux/Demux plug-in units (MDMA-RMC1) for ROADM configuration. In the 23-inch (or ANSI) shelf, the MDMA-RMC1 units occupy slots 5 and 15. In the ETSI configuration, these units are in slots 5 and 7. One mux/demux plug-in unit is required for Linear configuration. One Mux/Demux plug-in unit is needed for linear end node configuration.
- If the node is equipped with SFMA-CDC1 HUB drop units, the user can run the HUB connectivity test to verify optical connections between the optical Core shelves and the subtended optical Core shelves. This same test option is available to verify the connections in ETSI HUB configurations. These tests should be run after verifying the optical shelves.

2D-ROADM Configuration Requirements for the Nodal Test Tool

The 2D-ROADM configuration replaces the separate Mux/Demux and switch units with an SFMA-RDC1 (2D-ROADM unit). Two SFMA-RDC1 units in slots 3 and 17 are required for the 2D-ROADM configuration. In the FLASHWAVE 7500 ETSI shelf, the SFMA-RDC1 units occupy slots 3 and 9. One SFMA-RDC1 is required in slot 3 or 17 for linear applications, or slots 3 or 9 in a FLASHWAVE 7500 ETSI shelf.

Additional Equipment Requirements

The following table lists additional FLASHWAVE 7500 Release 7.1 and later system components required to use the Nodal Test Tool.

Table 78: Additional Equipment Requirements for Nodal Test Tool

Equipment	Part Number	Description	Quantity
IFMA-xxxx	FC9682xxxx	Any OLC unit applicable for the configuration Note: Refer to Optical Line Cards and SFP/XFP Modules for information on applicable OLC units.	1 (minimum requirement)
LAM units	FC9682LAMx	LAM plug-in units Note: The LAM units are used to connect the IFMA-xxxx to the system.	2 (linear) 4 (full OADM shelf)
MPO cables	FC9682MP11	MPO cables Note: The MPO cables are used to connect the IFMA-xxxx to the system.	2 (linear) 4 (full OADM shelf)
LC-to-LC cable assembly	27-100-00.5	LC-to-LC cable assembly (0.5 meter) for amplifier OPT OUT and OPT IN connectors	2 (as required)
Attenuator, 20 dB	37-466-612	20 dB attenuator (LC connectors) required for loopback of APMA-L2C1, APMA-ULU1, and APMA-MHU1 amplifier plug-in units. For loopback of APMA-ULC1 amplifier plug-in units, combine with 10 dB attenuator for a total of 30 dB attenuation. For loopback of APMA-M2C1/M2U1 or APMA-L2C1 plug-in units, no attenuation is required.	2 (as required)
Attenuator, 10 dB	37-465-612	10 dB attenuator (LC connectors) used with 20 dB attenuator (for 30 dB total attenuation) for loopback of APMA-ULC1 amplifier plug-in units.	2 (as required)

Documentation Requirements

The following documentation should be on-site and available when performing this procedure:

- FLASHWAVE 7500 Release 9.1 documentation set, FNC-7500-0091-010

If using for system turn-up, the following documents are required to complete this procedure:

- Core configuration—[Introduction to System Turn-Up Core Configuration](#)
- ETSI configuration—[Introduction to System Turn-Up Small and ETSI Configuration](#)
- Core and ETSI configuration—[Introduction to System Operations Service Provisioning](#)
- Core and ETSI configuration—[Responding to Alarms and Conditions](#)
- NETSMART® 500 Version 4.3 User Guide, FNC-0500-0043-010
- [Fiber Cable Handling](#)
- Engineering Work Order (referred to as Work Order) as required by local practices and standards

5.3 Using Nodal Test Tool for In-Service Testing

Perform the following procedure to test fiber connections and baseline the optical power levels for a in-service node using the Nodal Test Tool.



Step 1

Log on the NE. If already logged on, proceed to the next step.

Note: Up to 11 users (including operations support system [OSS]) can log on a single node for monitoring or provisioning purposes.

Note: The target identifier (TID), user identifier (UID), and private identifier (PID) values apply to initialized (factory default) systems. Consult your Network System Administrator for specific TID, UID, and PID values.

Note: The following table includes brief instructions for setting up the craft interface. For detailed information, refer to [Setting Up Craft Interface \(TL1 Session through TERM1\)](#) through [Setting Up Craft Interface \(NETSMART 500 Session through TERM2\)](#).

TL1	NETSMART 500
<p>Start a terminal or terminal emulator program (for example, HyperTerminal).</p> <p>For TERM1 (Serial): Press CTRL+X.</p> <p>For TERM2 (TCP/IP): Establish a Telnet session using IP address 192.168.1.1 and default port 23.</p> <p>The Welcome screen opens. Press 3 for TL1.</p>	<p>To launch the NETSMART 500 user interface from a Microsoft® Windows® platform, select the following from the Windows taskbar:</p>  <p>The NETSMART 500 Dashboard opens.</p> <p>Click the Logon icon, or select :</p>  <p>Note: If this is an Enhanced Security System, a warning message appears. You must read and agree to the conditions to access the system. Click I Agree to continue.</p> <p>The NE Logon dialog box opens. Make the following selections:</p>

TL1	NETSMART 500	
<p>ACT-USER:TID:UID:CTAG::PID; TID:</p> <ul style="list-style-type: none"> FUJITSU (Target identifier of the node; 7 to 20 non-case-sensitive, alphanumeric characters) <p>UID:</p> <ul style="list-style-type: none"> ROOT (User identifier; 4 to 10non-case-sensitive, alphanumeric characters) <p>PID:</p> <ul style="list-style-type: none"> ROOT/(Route66K) (Private identifier associated with the UID. For the basic mode, the PID must have 6 to 10 characters with at least one non-case-sensitive, alphabetic character and one nonalphabetic character such as a number or ! @ # \$ % ^ () _ + ~ { } [] ? or -. For the enhanced security mode, the PID must have 10 to 20 characters with at least two characters from each of four groups: lowercase letters, uppercase letters, numbers, and special characters ! @ # \$ % ^ & () or *. The enhanced security PID can also include special characters _ + { } [] or ~. The PID must not contain the associated UID.) <p>Example: ACT-USER:FUJITSU:ROOT:CTAG::ROOT;</p>	<p>For TERM1 (Serial): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: Serial</p> <p>Comm. Port: COMx (for example, COM2)</p> <p>Configure: use default⁷⁹</p>	<p>For TERM2 (TCP/IP): TID: FUJITSU User ID: ROOT Password: ROOT/(Route66K) Conn. Mode: TCP/IP IP Address: 192.168.1.1 Port: 2024</p>
	<p>Click Logon.</p> <p>The NETSMART 500 NE View opens.</p> <p>The Security Message dialog box opens. Click OK.</p> <p>Note: Refer to FNC-0500-0311-010, NETSMART 500 User Guide, for complete instructions on starting the NETSMART 500 user interface.</p>	

Step 2

Retrieve all alarms and conditions.

TL1	NETSMART 500	
<p>RTRV-COND-ALL:TID::CTAG;</p> <p>Example: RTRV-COND-ALL:FUJITSU::CTAG;</p>	<p>NE ▸ Alarms</p> <p>The Active Alarms window opens.</p> <p>View ▸ Filter</p> <p>The Alarm Filter dialog box opens.</p> <p>Ensure that all Fault Types and Severity Levels are selected in the Alarm Filter dialog box. Click Close.</p> <p>Verify the condition in the Active Alarms window. Close the Active Alarms window.</p>	

⁷⁹ The default serial port settings are recommended: baud rate– 9600, parity– none, data bits–8, stop bits– 1.

Step 3

Are any active alarms or conditions being reported on the NE?

IF YES:

Clear all alarms and standing conditions before continuing this procedure. Refer to the *Maintenance and Trouble Clearing* practice. After the alarms and conditions are cleared, go to the next step.

Note: If the provided procedures do not clear an alarm or condition, contact the Fujitsu Technical Assistance Center at 1-800-USE-FTAC (1-800-873-3822).

IF NO:

Go to the next step.

Step 4

Retrieve and verify that the cross-connects have been provisioned for the fiber connections.

Note: At least one cross-connect is required to be provisioned on the fiber to use the Nodal Test Tool.

TL1	NETSMART 500
<p>RTRV-CRS-WCH:TID:fromAID,toAID:CTAG; fromAID,toAID:</p> <p>The AID parameters can be one of the following:</p> <ul style="list-style-type: none">• ALL, ALL• ALL, toAID• fromAID, ALL• fromAID, toAID <p>Refer to the Retrieve Cross-Connect, WCH (RTRV-CRS-WCH) for a description of the AID values.</p> <p>Example: RTRV-CRS-WCH:FUJITSU:ALL:CTAG;</p>	<p>NE ▸ <i>Graphical Cross-Connects</i></p> <p>The Cross-Connects window opens.</p> <p>In the Cross-Connects window, verify that the cross-connect lines are solid.</p> <p>Close the Cross-Connects window.</p>

Step 5

Have cross-connects been provisioned for the fiber connections?

Note: Any channel can be used for cross-connects in the Nodal Test Tool.

IF YES:


Go to the next step.

IF NO:

Go to [Introduction to System Operations Service Provisioning](#) to provision cross-connects for the fiber connection.


Step 6

Start the nodal fiber test.

TL1	NETSMART 500
<p><code>OPR-TEST-PATH: [TID]: [fromAID] [, toAID]:CTAG;</code> <code>fromAID, toAID:</code></p> <p>The AID parameters can be one of the following:</p> <ul style="list-style-type: none">• ALL, ALL• ALL, toAID• fromAID, ALL• fromAID, toAID <p>Refer to the Operate Test Path (OPR-TEST-PATH) for a description of the AID values.</p> <p>Example: <code>OPR-TEST-PATH: FUJITSU: :CTAG;</code></p>	<p></p> <p>The Fiber Test report window opens.</p>

Step 7

Retrieve the fiber loss report.

TL1	NETSMART 500
<p><code>RTRV-TEST-PATH: [TID]: [fromAID] [, toAID]:CTAG;</code> <code>fromAID, toAID:</code></p> <ul style="list-style-type: none">• As identified in previous step• ALL (null) <p>Example: <code>RTRV-TEST-PATH: FUJITSU: :CTAG;</code></p>	<p></p> <p>The Fiber Test report window opens.</p> <p>If fiber baseline test is required for a specific connection, highlight a connection in the Fiber Test report window, right-click, and select Operations Dialog from the pop-up menu.</p> <p>The Operations dialog box opens.</p> <p>Select the desired connections. Click Operate.</p> <p>Close the Operations dialog box.</p>

Step 8

Review the fiber loss report for fiber connections that failed the test. The following figures provide an example of the fiber loss report generated by the Nodal Test Tool.




Figure 117: NETSMART 500 Fiber Loss Test Results Screen




Figure 118: TL-1 Fiber Loss Test Results Screen

Step 9

Did any fibers fail the test?

IF YES:

Go to the next step.

IF NO:

This procedure is complete.



Danger: Never look into the end of a fiber-optic cable. The equipment contains high-power optical laser devices that transmit light at a dangerous level. Permanent eye damage or blindness could occur. Follow local safety precautions regarding fiber-optic cables.



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.

Step 10

For each fiber connection that failed the test, clean the optical connectors on the fiber cable (refer to *Fiber Cable Handling*), verify that the fiber is properly connected to the plug-in unit, and then repeat the test beginning with [Step 6](#).

If cleaning the optical connectors and verifying that the fiber is properly connected to the plug-in unit do not resolve the fiber failure, call 1-800-USE-FTAC (1-800-873-3822) for technical assistance.

5.4 Using Nodal Test Tool for System Turn-Up

In this section:

- 5.4.1 Prepare and Configure the Node for Fiber Testing (If Necessary)
- 5.4.2 Install Loopback Cables on Slot 1 Amplifier (If Installed)
- 5.4.3 Install Loopback Cables on Slot 19 or 11 Amplifier (If Installed)
- 5.4.4 Start Nodal Fiber Test
- 5.4.5 Remove Loopback Cables

This procedure applies to: Core and ETSI Configurations



Warning: Follow all admonishments (Dangers, Warnings, and Cautions) in this procedure and the associated documentation listed in [Nodal Test Tool Prerequisites](#) to prevent service interruptions (if applicable), damage to equipment, or harm to personnel.



Warning: The Nodal Test Tool must **NOT** be used to test Raman amplifiers (APMA-DRC1). Attempting to run this procedure with these units will damage the laser on the APMA-DRC1 amplifiers.



Attention: When entering TL1 commands or NETSMART 500 steps, refer to [Introduction to TL1 Commands](#) for information about preconditions, postconditions, AIDs, and parameters.

Perform the following procedure to test fiber connections and baseline the optical power levels at system turn-up using the Nodal Test Tool.

5.4.1 Prepare and Configure the Node for Fiber Testing (If Necessary)

Step 1

Has the node already been equipped and fibered according to a work order, and is fiber testing the only required task?

If YES:

Go to the next step.

If NO:

Go to [Step 3](#).

Step 2

Does the equipped and fibered NE meet the prerequisites listed in [Nodal Test Tool Prerequisites?](#)

IF YES:

Go to [Install Loopback Cables on Slot 1 Amplifier \(If Installed\)](#).

IF NO:

Go to the next step.

Step 3

Follow the procedures listed in the following table to prepare and configure the node for fiber testing.

Note: Some procedures listed in the table may have been performed previously because of a work order.

Table 79: Configuration Procedures to Provision Node

Task No.	Task Name	Document and Procedure	
		Core Configuration	ETSI Configuration
1	Verify shelf labeling and intershelf connections.	Verify Shelf Labeling, Verify LAN and RICC Cable Connections, Apply Power, and Install Fan Units	Verify Shelf Labeling, Verify LAN and RICC Cable Connections, and Install Fan Units
2	Install shelf processors.	Install Primary NE Management Units in Shelf OS1, and Configure Shelf OS1 as the Main Optical Shelf	Install NEM Units and Configure Main Optical Shelf
3	Create Auxiliary shelf, and install shelf processors.	Create Subtending Shelves and Install Shelf Processors	Create Subtending Shelves and Install Shelf Processors
4	Provision optical equipment.	Provision Optical Shelf Equipment and Facilities	Provision Optical/ILA Shelf Equipment and Facilities
5	Install intrashelf fiber-optic cables.	Install Intrashelf Fiber-Optic Cables	Interconnect Amplifier and OSC Units
			Install WSS System Cables
			Install 2D-ROADM System Cables
6	Install LAMs and MPO connections.	Install LAMs and MPO Connections	Install LAMs and MPO Connections
7	Install and provision the required OLC plug-in unit. <i>Note: If you have not received a work order that specifies an OLC, use any OLC unit applicable for the configuration.</i>	Install and Manually Provision the OLC	

Table 79: Configuration Procedures to Provision Node (Cont.)

Task No.	Task Name	Document and Procedure	
		Core Configuration	ETSI Configuration
8	Create the service facility for OLC. <i>Note: If you have not received a work order that specifies a facility, any facility is applicable for fiber testing.</i>	Create the OLC Facilities Manually	
9	Create cross-connect for the OLC. <i>Note: If you have not received a work order that specifies a wavelength/channel, any wavelength/channel is applicable for fiber testing.</i>	Provision OLC Adds and Drops <i>Attention: If the Nodal Fiber Test Wizard will be used for testing do not perform task 9 (creating cross-connects).</i>	

5.4.2

Install Loopback Cables on Slot 1 Amplifier (If Installed)

Step 1

Obtain and clean an LC-LC fiber-optic cable?

Step 2

Is an Amplifier installed in slot 1 of the shelf?

If YES:

Go to [Step 3](#).

If NO:

Go to [Install Loopback Cables on Slot 19 or 11 Amplifier \(If Installed\)](#).

Step 3

Is the Amplifier in slot 1 an APMA-L2C1, APMA-ULC1, APMA-MHU1, or APMA-ULU1 unit?

If YES:

Attenuation is required. Go to [Step 4](#).

If NO:

Attenuation is not required. Go to [Step 5](#).

Step 4

Install the loopback cable with attenuation as follows:

- a) Obtain and clean attenuators (if attenuators are required).

Insert one 20 dB attenuator when testing with the APMA-L2C1, APMA-ULU1, and APMA-MHU1 amplifiers. Insert the attenuator(s) into the OPT IN connector of the APMA-xxxx plug-in unit in slot 19 or 11 of the shelf under test (OSn, n = 1...4). When testing with the APMA-ULC1 amplifier, insert one 20 dB attenuator into the OPT IN port and one 10 dB attenuator into the OPT OUT port. No attenuator is required for APMA-M2C1/M2U1 or APMA-L2C1 plug-in units.

- b) Using LC-LC fiber-optic cable, connect the attenuator to connector OPT OUT of the same APMA-xxxx plug-in unit.
- c) Go to [Install Loopback Cables on Slot 19 or 11 Amplifier \(If Installed\)](#).

Step 5

Install one LC-LC loopback cable (without attenuation) as follows:

- a) Connect one end of the cable to connector OPT IN of the amplifier plug-in unit in slot 1 of the shelf under test (OSn, n = 1...4).
- b) Connect the other end of the cable to connector OPT OUT of the same amplifier plug-in unit.
- c) Go to [Install Loopback Cables on Slot 19 or 11 Amplifier \(If Installed\)](#).

5.4.3

Install Loopback Cables on Slot 19 or 11 Amplifier (If Installed)

Note: Use slot 19 for Core configuration and slot 11 for ETSI configuration.

Step 1

Obtain and clean an LC-LC fiber-optic cable?

Step 2

Is an Amplifier installed in slot 19 or 11 of the shelf?

If YES:

Go to [Step 3](#).

If NO:

Go to [Step 6](#).

Step 3

Is the Amplifier in slot 19 or 11 an APMA-L2C1, APMA-ULC1, APMA-MHU1, or APMA-ULU1 unit?

If YES:

Attenuation is required. Go to [Step 4](#).

If NO:

Attenuation is not required. Go to [Step 5](#).

Step 4

Install the loopback cable with attenuation as follows:

a) Obtain and clean attenuators (if attenuators are required).

Insert one 20 dB attenuator when testing with the APMA-L2C1, APMA-ULU1, and APMA-MHU1 amplifiers. Insert the attenuator(s) into the OPT IN connector of the APMA-xxxx plug-in unit in slot 19 or 11 of the shelf under test (OSn, n = 1...4). When testing with the APMA-ULC1 amplifier, insert one 20 dB attenuator into the OPT IN port and one 10 dB attenuator into the OPT OUT port. No attenuator is required for APMA-M2C1/M2U1 or APMA-L2C1 plug-in units.

b) Using LC-LC fiber-optic cable connect attenuator to connector OPT OUT of the same APMA-xxxx plug-in unit.

c) Go to [Step 6](#).

Step 5

Install one LC-LC loopback cable (without attenuation) as follows:

a) Connect one end of the cable to connector OPT IN of the amplifier plug-in unit in slot 1 of the shelf under test (OSn, n = 1...4).

b) Connect the other end of the cable to connector OPT OUT of the same amplifier plug-in unit.

Step 6

Repeat steps in [Prepare and Configure the Node for Fiber Testing \(If Necessary\)](#) through [Step 5](#) in this subprocedure for each shelf equipped with amplifier units and fibered for testing. Then proceed to the next step.

Step 7

Do you want to use the NETSMART 500 Nodal Fiber Test Wizard to perform the fiber testing?

Note: NETSMART® 500 Version 4.3 or later is required to use the Nodal Test Tool.

IF YES:

Go to [Nodal Fiber Test Wizard](#).

IF NO:

Proceed to [Step 8](#).

Step 8

Was an OLC installed and provisioned in [Step 3](#) in [Prepare and Configure the Node for Fiber Testing \(If Necessary\)](#) or previously provisioned according to a work order?

Note: At least one OLC must be installed and provisioned to use the Nodal Test Tool.

IF YES:

Proceed to [Step 9](#).

IF NO:

Go to [Table 79](#), and perform task number 7 to install and provision the OLC. Then proceed to [Step 9](#).

Step 9

Were a service facility and wavelength provisioned in [Step 3](#) in [Prepare and Configure the Node for Fiber Testing \(If Necessary\)](#) or previously provisioned according to a work order for the OLC?

Note: At least one wavelength must be provisioned to use the Nodal Test Tool.

IF YES:

Proceed to [Step 10](#).

IF NO:

Go to [Table 79](#), and perform task numbers 8 and 9 to provision a service facility and wavelength for the OLC. Then proceed to the next step.



Attention: Installing the LC-LC loopback cable causes the FLASHWAVE 7500 platform to raise an OSC MISCON alarm on each OSC facility. Failure to resolve these alarms will prevent the Nodal Test Tool from successfully completing testing.

Step 10

Clear the OSC MISCON alarms by performing the following task:

- a) Take the applicable OSC facility out of service.

TL1	NETSMART 500
<p>ED-OSC::AID:CTAG::::OOS;</p> <p>Refer to the Edit OSC Facility (ED-OSC) for a description of the AID values.</p> <p>Example: ED-OSC:FUJITSU:OS1-9-PE1:CTAG::::OOS;</p>	<p>In the Tree view or shelf OSn graphic view.</p> <p>Expand the appropriate shelf, and select the applicable slot:</p> <ul style="list-style-type: none"> • Select slot 9 or 11 for Core configuration. • Select slot 13 or 15 for ETSI configuration. <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click Start tab.</p> <p>Select Out of Service (ED-OOS). Click Modify.</p> <p>Do not close the Operations dialog box.</p>

b) Change remote OSC connection to SAME.

TL1	NETSMART 500
<p>ED-OSC:TID:AID:CTAG::::REMOTE=SAME;</p> <p>Refer to the Edit OSC Facility (ED-OSC) for a description of the AID values.</p> <p>Example: ED-OSC:FUJITSU:OS1-9- PE1:CTAG::::REMOTE=SAME;</p>	<p>Modify ▶ Command Parameters</p> <p>Select the REMOTE check box.</p> <p>From the drop down tab (to the right) select SAME. Click Modify.</p>

c) Place the OSC facility back into service.

TL1	NETSMART 500
<p>ED-OSC:TID:AID:CTAG::::IS;</p> <p>Refer to the Edit OSC Facility (ED-OSC) for a description of the AID values.</p> <p>Example: ED-OSC:FUJITSU:OS1-9-PE1:CTAG::::IS;</p>	<p>Click Start tab. Select In Service (ED-IS). Click Modify.</p> <p>Close the Operations dialog box.</p>

Step 11

Repeat [Step 10](#) for each OSC unit in slots in slot 9 and 11 for 23" Core shelf (SHU3) and slots 13 and 15 of the ETSI shelf (SHU4). Then go to [Start Nodal Fiber Test](#).

5.4.4

Start Nodal Fiber Test

Step 1

Start the nodal fiber test.

TL1	NETSMART 500
<pre>OPR-TEST-PATH: [TID]: [fromAID][, toAID]:CTAG;</pre> <p>fromAID, toAID:</p> <p>The AID parameters can be one of the following:</p> <ul style="list-style-type: none"> • ALL, ALL • ALL, toAID • fromAID, ALL • fromAID, toAID <p>Refer to the Operate Test Path (OPR-TEST-PATH) for a description of the AID values.</p> <p>Example: <pre>OPR-TEST-PATH: FUJITSU::CTAG;</pre></p>	<div style="background-color: #808080; color: white; padding: 2px; display: inline-block;">Reports ▶ Fiber Test</div> <p>The Fiber Test report window opens.</p>

Step 2

Retrieves the fiber loss report.

TL1	NETSMART 500
<pre>RTRV-TEST-PATH: [TID]: [fromAID][, toAID]:CTAG;</pre> <p>fromAID, toAID:</p> <ul style="list-style-type: none"> • As identified in previous step • ALL (null) <p>Example: <pre>RTRV-TEST-PATH: FUJITSU::CTAG;</pre></p>	<div style="background-color: #808080; color: white; padding: 2px; display: inline-block;">Reports ▶ Fiber Test</div> <p>The Fiber Test report window opens.</p> <p>If fiber baseline test is required for a specific connection,</p> <p>highlight a connection in the Fiber Test report window, right-click, and select Operations Dialog from the pop-up menu.</p> <p>The Operations dialog box opens.</p> <p>Select the desired connections. Click Operate.</p> <p>Close the Operations dialog box.</p>

Step 3

Repeat [Steps 1 through 2](#) for each fiber connection required. Then proceed to the next step.

Step 4

Review the fiber loss report for fiber connections that failed the test. The following figures provide an example of the fiber loss report generated by the Nodal Test Tool.




Figure 119: NETSMART 500 Fiber Loss Test Results Screen




Figure 120: TL-1 Fiber Loss Test Results Screen

Step 5

Did any fibers fail the test?

If YES:

Go to [Step 6](#).

If NO:

Go to [Step 7](#).



Danger: Never look into the end of a fiber-optic cable. The equipment contains high power optical laser devices that transmit light at a dangerous level. Permanent eye damage or blindness could occur. Follow local safety precautions regarding fiber-optic cables.



Danger: Never handle exposed fiber with bare hands or touch it to your body. A fiber fragment could enter the skin and be very difficult to detect and remove. Follow local safety precautions regarding fiber.

Step 6

For each fiber connection that failed the test, clean the optical connectors on the fiber cable (refer to *Fiber Cable Handling*), verify that the fiber is properly connected to the plug-in unit, and then repeat the test beginning with [Step 1](#).

If cleaning the optical connectors and verifying that the fiber is properly connected to the plug-in unit do not resolve the fiber failure, call 1-800-USE-FTAC (1-800-873-3822) for technical assistance.

Step 7

Return OSC unit remote connection to DIFF by performing the following task:

- a) Take the applicable OSC facility out of service.

TL1	NETSMART 500
<p>ED-OSC::AID:CTAG::::OOS;</p> <p>Refer to the Edit OSC Facility (ED-OSC) for a description of the AID values.</p> <p>Example: ED-OSC:FUJITSU:OS1-9-PE1:CTAG::::OOS;</p>	<p>In the Tree view or shelf OSn graphic view.</p> <p>Expand the appropriate shelf, and select the applicable slot:</p> <ul style="list-style-type: none"> Select slot 9 or 11 for Core configuration. Select slot 13 or 15 for ETSI configuration. <p>Entity ▶ Operations Dialog</p> <p>The Operations dialog box opens. Click Start tab.</p> <p>Select Out of Service (ED-OOS). Click Modify.</p> <p>Do not close the Operations dialog box.</p>

- b) Change remote OSC connection to DIFF.

TL1	NETSMART 500
<pre>ED-OSC:TID:AID:CTAG:::REMOTE=DIFF;</pre> <p>Refer to the Edit OSC Facility (ED-OSC) for a description of the AID values.</p> <p>Example: <pre>ED-OSC:FUJITSU:OS1-9-PE1:CTAG:::REMOTE=DIFF;</pre></p>	<div style="background-color: #cccccc; padding: 2px; margin-bottom: 5px;">Modify ▶ Command Parameters</div> <p>Select the REMOTE check box.</p> <p>From the drop down tab (to the right) select DIFF. Click Modify.</p>

c) Place the OSC facility back into service.

TL1	NETSMART 500
<pre>ED-OSC:TID:AID:CTAG::::IS;</pre> <p>Refer to the Edit OSC Facility (ED-OSC) for a description of the AID values.</p> <p>Example: <pre>ED-OSC:FUJITSU:OS1-9-PE1:CTAG::::IS;</pre></p>	<p>Click Start tab. Select In Service (ED-IS). Click Modify.</p> <p>Close the Operations dialog box.</p>

Step 8

Proceed to [Remove Loopback Cables](#).

5.4.5

Remove Loopback Cables

Step 1

Remove the loopback cables attached to the amplifier units in slots 1 and 19 (or 11).

Step 2

If attenuators were used for testing, remove them from the amplifiers.

Step 3

Place port covers in the amplifier ports.

This procedure is complete.

A

Data Record Forms

In this appendix:

- A.1 Shelf Voltage Measurement Record
- A.2 Network-Side Optical Power Measurement Record
- A.3 Client-Side Optical Power Measurement Record

This appendix provides the forms to aid engineers and technicians during installation, turn-up, and acceptance testing procedures.

A.1

Shelf Voltage Measurement Record

The following table provides a form to record voltages while verifying power connections to the Optical and Tributary shelves. For more information, refer to [Checking Power at Optical/Tributary Shelf](#).

Table 80: Shelf Voltage Measurements Record

Optical Shelf AID	Measurement		Tributary Shelf AID	Measurement	
	MAIN A	MAIN B		MAIN A	MAIN B
OS1	_____ V DC	_____ V DC	OS10	_____ V DC	_____ V DC
OS2	_____ V DC	_____ V DC	OS11	_____ V DC	_____ V DC
OS3	_____ V DC	_____ V DC	OS12	_____ V DC	_____ V DC
OS4	_____ V DC	_____ V DC	OS13	_____ V DC	_____ V DC
OS25	_____ V DC	_____ V DC	OS20	_____ V DC	_____ V DC
OS26	_____ V DC	_____ V DC	OS21	_____ V DC	_____ V DC
			OS22	_____ V DC	_____ V DC
			OS23	_____ V DC	_____ V DC
			OS30	_____ V DC	_____ V DC
			OS31	_____ V DC	_____ V DC
			OS32	_____ V DC	_____ V DC
			OS33	_____ V DC	_____ V DC
			OS40	_____ V DC	_____ V DC
			OS41	_____ V DC	_____ V DC
			OS42	_____ V DC	_____ V DC
			OS43	_____ V DC	_____ V DC
			OS100	_____ V DC	_____ V DC
			OS200	_____ V DC	_____ V DC
			OS300	_____ V DC	_____ V DC
			OS400	_____ V DC	_____ V DC

A.2

Network-Side Optical Power Measurement Record

The following table provides a form to record network-side optical power levels. This form can be used with the following procedures:

- [Connect Network Fiber-Optic Cables](#)
- [Measuring Optical Tributary Power](#)

Table 81: Network-Side Optical Power Level Record

WDM Facility	Transmit	Receive		
	Optical Power	Optical Power	Attenuation	Optical Power with Attenuation
OS1-1-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS1-19-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS2-1-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS2-19-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS3-1-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS3-19-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS4-1-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS4-19-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS25-1-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS25-19-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS26-1-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS26-19-PE1	_____ dBm	_____ dBm	_____ dBm	_____ dBm

A.3

Client-Side Optical Power Measurement Record

The following table provides a form to record client-side optical power levels. This form can be used with the following procedures:

- [Connect Revenue Traffic](#)
- [Measuring Optical Tributary Power](#)

Table 82: Client-Side Optical Power Level Record (Tributary Shelf OS__)

OLC AID	Client		Transmit	Receive		
			Optical Power	Optical Power	Attenuation	Optical Power with Attenuation
OS__-1	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-2	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-3	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-4	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-5	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm

Table 82: Client-Side Optical Power Level Record (Tributary Shelf OS___) (Cont.)

OLC AID	Client		Transmit	Receive		
			Optical Power	Optical Power	Attenuation	Optical Power with Attenuation
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-6	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-7	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm		
OS__-8	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-13	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm		
OS__-14	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-15	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm

Table 82: Client-Side Optical Power Level Record (Tributary Shelf OS__) (Cont.)

OLC AID	Client		Transmit	Receive		
			Optical Power	Optical Power	Attenuation	Optical Power with Attenuation
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-16	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-17	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm		
OS__-18	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
OS__-19	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm
	Muxponder/ Flexponder™	TRIB 1	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 2	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 3	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 4	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 5	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 6	_____ dBm	_____ dBm	_____ dBm	_____ dBm
		TRIB 7	_____ dBm	_____ dBm	_____ dBm	_____ dBm
TRIB 8	_____ dBm	_____ dBm	_____ dBm	_____ dBm		
OS__-20	Transponder		_____ dBm	_____ dBm	_____ dBm	_____ dBm

Index

A

- acceptance testing
 - Core Configuration [313](#), [386](#)
- Asymmetric HUB node
 - provisioning [233](#)
- automatic
 - provisioning
 - Core Configuration [105](#)
- Auxiliary Optical shelf
 - entities, creating [88](#)

C

- connecting
 - DCM [191](#), [379](#)
 - LAM [183](#)
 - network cables [247](#)
- control plane
 - optical reach data [300](#)
 - provisioning [277](#)
- Core Configuration
 - acceptance testing [313](#), [386](#)
 - ILA node turn-up [320](#)
 - provisioning [13](#), [356](#)
 - provisioning hierarchy [38](#)
 - turn-up [13](#)
- creating
 - Auxiliary Optical shelf entities [88](#)
 - Tributary shelf entities [93](#)

D

- data record forms
 - client-side optical power [423](#)
 - network-side optical power [422](#)
 - shelf voltage [421](#)
- DCM
 - connecting [191](#), [379](#)
 - inventory information [197](#), [199](#)

F

- facilities
 - provisioning

- ODCC [125](#)
- OSC [122](#)
- WDM [122](#)

- fan unit
 - installation [42](#), [326](#)
- fiber-optic cable
 - connecting
 - internal/intrashelf cables [146](#), [371](#)
 - network cables [247](#)
 - verifying connections [258](#)
- forms, data records [420](#)

G

- GOS
 - provisioning at turn-up [84](#), [354](#)

H

- hierarchy of provisioning
 - Core Configuration [38](#)
- HUB nodes
 - asymmetric
 - provisioning interconnections [233](#)
 - changing HUBMODE to MANUAL [65](#)
 - symmetric
 - provisioning interconnections [202](#), [204](#)

I

- ILA node
 - turn-up [320](#)
- installing
 - fan units [42](#), [326](#)
 - internal/intrashelf fiber cables [146](#), [371](#)
 - LAMs [183](#)
 - loopback cables, DCM [191](#), [379](#)
 - shelf processor [57](#), [87](#), [327](#)

L

- LAMs
 - connecting MPO fiber-optic ribbon cables [183](#)
- LAN cable
 - verifying connections [42](#)

LCN (local communication network)

provisioning [78, 347](#)

loopback cables, DCM

installing [191, 379](#)

M

manual

provisioning

Optical shelf [111](#)

MPMA-SHPx

installing [57, 87, 327](#)

MPO fiber-optic ribbon cable

installing [183](#)

N

NE

provisioning

date, time, ID, and users [69, 338](#)

LCN port [69, 338](#)

NETSMART 500

network topology view [297](#)

network

cables, connecting [247](#)

topology view [297](#)

verification [319](#)

nodal test tool

in-service testing [403](#)

overview [387](#)

prerequisites [388](#)

system turn-up testing [409](#)

O

ODCC (optical data communications channel)

facility provisioning [125](#)

optical reach

control plane provisioning [300](#)

Optical shelf

interconnect HUB nodes [202](#)

optical power measurement record

client side [423](#)

network side [422](#)

provisioning [105, 111](#)

OSC (optical supervisory channel)

provisioning [122](#)

OSPF

provisioning [297](#)

OSS

operations

entering IP address [285](#)

P

provisioning

automatic [105](#)

date, time, ID, and users

system turn-up (core) [69](#)

facilities

ODCC [125](#)

OSC [122](#)

WDM [122](#)

GOS [84, 354](#)

ILA shelf equipment and facilities [356](#)

LCN port [78, 347](#)

manual [111](#)

Optical shelf equipment and facilities [102](#)

OSPF [287](#)

shelf location identifier [66](#)

synchronization [129](#)

system-level parameters

system turn-up (core) [69](#)

Tributary shelf equipment [93](#)

provisioning hierarchy

Core Configuration turn-up [38](#)

R

records, shelf voltage measurement [421](#)

resetting SLV alarm reference See SLV (alarm condition).

S

shelf

labeling [42](#)

location identifiers [66](#)

voltage measurement records [421](#)

slot labels and AIDs [28](#)

SLV (alarmed condition)

resetting system reference [267](#)

software

verifying [60, 330](#)

span loss variation [267](#)

Symmetric HUB node

converting to an Asymmetric HUB node [65](#)

synchronization

provisioning [129](#)

reference switching test [314](#)

switch

external timing [314](#)

testing [314](#)

Synchronization unit See TCMA-ST31.

SYSREF (system reference value for SLV alarm) [267](#)

system

turn-up [13](#)

type, changing [61](#)

T

TCMA-ST31

protection switching [317](#)provisioning [129](#)testing [317](#)

testing

automatic switching

synchronization unit [317](#)

manual switching

external timed node [314](#)

nodal test tool

in-service testing [403](#)overview [387](#)prerequisites [388](#)system turn-up testing [409](#)synchronization reference switching [314](#)topology view [297](#)

Tributary shelf

entities, creating [93](#)

turn-up

Core Configuration

ILA node [320](#)**V**

verifying

fiber connections [258](#)LAN connections [42](#)network operation [319](#)RICC cable connections [42](#)shelf labeling [42](#)software version [60](#), [330](#)voltage measurement record, shelf [421](#)**W**

WDM

facility

provisioning [122](#)